



***ForeRunner™* ATM Switch**

User's Manual

MANU0149-01 - March, 1997

Software Version 4.1.x

FORE Systems, Inc.

1000 FORE Drive
Warrendale, PA 15086
Phone: 412-742-4444
FAX: 412-772-6500

<http://www.fore.com>

Legal Notices

Copyright © 1995-1997 FORE Systems, Inc. All rights reserved. FORE Systems is a registered trademark, and *ForeRunner*, *ForeView*, *ForeThought*, *ForeRunnerLE*, *PowerHub*, and *CellPath* are trademarks of FORE Systems, Inc. All other brands or product names are trademarks of their respective holders.

U.S. Government Restricted Rights. If you are licensing the Software on behalf of the U.S. Government (“Government”), the following provisions apply to you. If the Software is supplied to the Department of Defense (“DoD”), it is classified as “Commercial Computer Software” under paragraph 252.227-7014 of the DoD Supplement to the Federal Acquisition Regulations (“DFARS”) (or any successor regulations) and the Government is acquiring only the license rights granted herein (the license rights customarily provided to non-Government users). If the Software is supplied to any unit or agency of the Government other than DoD, it is classified as “Restricted Computer Software” and the Government’s rights in the Software are defined in paragraph 52.227-19 of the Federal Acquisition Regulations (“FAR”) (or any successor regulations) or, in the cases of NASA, in paragraph 18.52.227-86 of the NASA Supplement to the FAR (or any successor regulations).

Printed in the USA.

No part of this work covered by copyright may be reproduced in any form. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

This publication is provided by FORE Systems, Inc. “as-is” without warranty of any kind, either express or implied, including, but not limited to, the implied warranties or conditions of merchantability or fitness for a particular purpose. FORE Systems, Inc. shall not be liable for any errors or omissions which may occur in this publication, nor for incidental or consequential damages of any kind resulting from the furnishing, performance, or use of this publication.

Information published here is current or planned as of the date of publication of this document. Because we are improving and adding features to our products continuously, the information in this document is subject to change without notice.

RESTRICTED RIGHTS LEGEND. Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 (October 1988) and FAR 52.227-19 (June 1987).

The VxWorks software used in the Mini Loader is licensed from Wind River Systems, Inc., Copyright © 1984-1996.

FCC CLASS A NOTICE

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void this user’s authority to operate this equipment.

NOTE: The ASX-200, the ASX-200WG, the ASX-200BX and the ASX-1000 have been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of the equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

DOC CLASS A NOTICE

This digital apparatus does not exceed Class A limits for radio noise emission for a digital device as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le present appareil numerique n’emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la class A prescrites dans le reglement sur le brouillage radioelectrique edicte par le ministere des Communications du Canada.

VCCI CLASS 1 NOTICE

この装置は、第一種情報処理装置（商工業地域において使用されるべき情報処理装置）で商工業地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会(VCCI)基準に適合しております。

従って、住宅地域またはその隣接した地域で使用すると、ラジオ、テレビジョン受信機等に受信障害を与えることがあります。

取扱説明書に従って正しい取り扱いをして下さい。

This equipment is in the Class 1 category (Information Technology Equipment to be used in commercial and/or industrial areas) and conforms to the standards set by the Voluntary Control Council For Interference by Information Technology Equipment aimed at preventing radio interference in commercial and/or industrial areas. Consequently, when used in a residential area or in an adjacent area thereto, radio interference may be caused to radios and TV receivers, etc. Read the instructions for correct handling.

FCC REQUIREMENTS (Notice to Users of DS1 Service)

The following instructions are provided to ensure compliance with the Federal Communications Commission (FCC) Rules, Part 68.

- (1) This device must only be connected to the DS1 network connected behind an FCC Part 68 registered channel service unit. Direct connection is not allowed.
- (2) Before connecting your unit, you must inform the telephone company of the following information:

Port ID	REN/SOC	FIC	USOC
NM-6/DS1C	6.0N	04DU9-BN, 04DU9-DN,	RJ48C
NM-2/DS1C	6.0N	04DU9-1ZN, and 04DU9-1SN	RJ48C

- (3) If the unit appears to be malfunctioning, it should be disconnected from the telephone lines until you learn if your equipment or the telephone line is the source of the trouble. If your equipment needs repair, it should not be reconnected until it is repaired.
- (4) If the telephone company finds that this equipment is exceeding tolerable parameters, the telephone company can temporarily disconnect service, although they will attempt to give you advance notice if possible.
- (5) Under the FCC Rules, no customer is authorized to repair this equipment. This restriction applies regardless of whether the equipment is in or out of warranty.
- (6) If the telephone company alters their equipment in a manner that will affect use of this device, they must give you advance warning so as to give you the opportunity for uninterrupted service. You will be advised of your right to file a complaint with the FCC.

CANADIAN IC CS-03 COMPLIANCE STATEMENT

NOTICE: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Industry Canada label does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

E1 AND E3 NOTICE

The E1 (NM-6/E1C and NM-2/E1C) and E3 (NM-4/E3C and NM-2/E3C) network modules that are described in this manual are approved for use in FORE Systems' host systems providing that the instructions below are strictly observed. Failure to follow these instructions invalidates the approval.

Pan European Approval - CE Marking

Pan European approval of the E1 network module was issued by BABT following assessment against CTR12. This means that it can be connected to ONP and unstructured PTO-provided private circuits with 120 Ω interfaces in all European countries, according to Telecommunications Terminal Equipment (TTE) Directive 91/263/EEC. Thus, the following CE mark applies:

CE168X

The E1 and E3 network modules conform to safety standard EN60950 1992 following the provisions of Low Voltage Product Safety Directive 73/23/EEC and CE Marking Directive 93/68/EEC, and can be marked accordingly with the CE symbol.

The E1 and E3 network modules conform to EN55022 1994 and EN50082-1 1992 following the provisions of the EMC Directive 89/336/EEC, and can be marked accordingly with the CE symbol.

National Approvals

UK

Network Module	Connects to	Approval Number
E1	Structured and unstructured PTO-provided private circuits with 75 Ω interfaces	AA60953
E3	PTO-provided private circuits with 75 Ω interfaces	NS/4387/1/T/605954

Germany

Network Module	Connects to	Approval Number
E3	Structured PTO-provided private circuits with 75 Ω interfaces	A127535H for the ASX-1000 A127534H for the ASX-200BX or ASX-200WG

Switzerland

Network Module	Connects to	Approval Number
E1	Structured PTO-provided private circuits with 120 Ω interfaces	96.0872.J.N
E3	Structured PTO-provided private circuits with 75 Ω interfaces	96.0873.J.N

Required User Guide Statements - UK Installation

The use of auxiliary products not authorized by FORE Systems in FORE Systems ATM Switches may cause the power specification to be exceeded and is a potential safety hazard.

The equipment must be installed such that with the exception of the connections to the host, clearance and creepage distances shown in the table below are maintained between the network module and any other assemblies which use or generate a voltage shown in the table below. The larger distance shown in brackets applies where the local environment within the host is subject to conductive pollution or dry non-conductive pollution which could become conductive due to condensation. Failure to maintain these minimum distances invalidates the approval.

Clearance (mm)	Creepage (mm)	Voltage Used or Generated by Host or by Network Modules
2.0	2.4 (3.8)	Up to 50 V_{rms} or V_{dc}
2.6	3.0 (4.8)	Up to 125 V_{rms} or V_{dc}
4.0	5.0 (8.0)	Up to 250 V_{rms} or V_{dc}
4.6	6.4 (10.0)	Up to 300 V_{rms} or V_{dc}
For a host or other expansion card fitted in the host, using or generating voltages greater than 300V (rms or dc), advice from a competent telecommunications engineer must be obtained before installation of the relevant equipment.		Above 300 V_{rms} or V_{dc}

NOTE: Installing the network modules in the appropriate FORE Systems hosts, according to the installation instructions provided, satisfies the requirements listed above.

The following tables show the available ports and their safety status:

NM-6/E1C and NM-2/E1C

Ports	Safety Status
E1 Ports	TNV operating at SELV
Bus Connector	SELV

NM-4/E3C and NM-2/E3C

Ports	Safety Status
E3 Ports	TNV operating at SELV
Bus Connector	SELV

CE NOTICE

Marking by the symbol **CE** indicates compliance of this system to the EMC (Electromagnetic Compatibility) directive of the European Community and compliance to the Low Voltage (Safety) Directive. Such marking is indicative that this system meets or exceeds the following technical standards:

- EN 55022 - “Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment.”
- EN 50082-1 - “Electromagnetic compatibility - Generic immunity standard Part 1: Residential, commercial, and light industry.”
- IEC 1000-4-2 - “Electromagnetic compatibility for industrial-process measurement and control equipment Part 2: Electrostatic discharge requirements.”
- IEC 1000-4-3 - “Electromagnetic compatibility for industrial-process measurement and control equipment Part 3: Radiate electromagnetic field requirements.”
- IEC 1000-4-4 - “Electromagnetic compatibility for industrial-process measurement and control equipment Part 4: Electrical fast transient /burst requirements.”

SAFETY CERTIFICATIONS

ETL certified to meet Information Technology Equipment safety standards UL 1950, CSA 22.2 No. 950, and EN 60950.

Table of Contents

Preface

Chapter Summaries.....	i
Technical Support	ii
Typographical Styles	iii
Important Information Indicators	iv
Laser Notice	v
Safety Precautions.....	vi
Modifications to Equipment	vi
Placement of a FORE Systems Product	vi
Power Cord Connection	vii

CHAPTER 1 Switch Hardware

1.1	Switch Hardware Configurations	1 - 2
1.2	Switch Hardware Components.....	1 - 4
1.2.1	Switch Board	1 - 4
1.2.2	Switch Control Processor	1 - 4
1.2.2.1	SPARC RISC Switch Control Processor	1 - 4
1.2.2.1.1	RESET Switch	1 - 5
1.2.2.1.2	ABORT Switch	1 - 5
1.2.2.1.3	RUN/RESET LED	1 - 5
1.2.2.1.4	VME BM LED	1 - 5
1.2.2.1.5	STATUS LED	1 - 5
1.2.2.1.6	Diagnostics Display	1 - 5
1.2.2.1.7	RS-232 Serial Ports	1 - 5
1.2.2.1.8	Ethernet AUI Port	1 - 6
1.2.2.2	i960 Switch Control Processor	1 - 6
1.2.2.2.1	RESET Button	1 - 6
1.2.2.2.2	RS-232 Serial Port	1 - 6
1.2.2.2.3	Ethernet 10BaseT Port.....	1 - 7
1.2.2.2.4	CTL Port	1 - 8
1.2.2.2.5	NEXT Pushbutton	1 - 8
1.2.2.2.6	SELECT Pushbutton.....	1 - 8
1.2.2.2.7	Display LED	1 - 8
1.2.2.2.8	Power LED	1 - 9

Table of Contents

1.2.3	Dual SCP Setup	1 - 9
1.2.3.1	Adding a Standby SCP	1 - 10
1.2.3.2	Rebooting the Controlling SCP	1 - 11
1.2.3.3	Ethernet Connection	1 - 11
1.2.4	Network Modules	1 - 11
1.2.4.1	Port Numbering	1 - 12
1.2.5	Power Supply Modules	1 - 13
1.2.5.1	ASX-200BX AC Power Supply	1 - 13
1.2.5.2	ASX-200BX -48 Volt DC Power Supply	1 - 14
1.2.5.3	ASX-1000 AC Power Supply (Model A)	1 - 16
1.2.5.3.1	Power Supply LEDs	1 - 16
1.2.5.3.2	Shutdown Conditions	1 - 17
1.2.5.4	ASX-1000 AC Power Supply (Model B)	1 - 18
1.2.5.4.1	Power Supply LEDs	1 - 18
1.2.5.4.2	Shutdown Conditions	1 - 19
1.2.5.5	ASX-1000 -48 Volt DC Power Supply	1 - 20
1.2.6	ASX-1000 Fan Tray	1 - 21
1.2.7	ASX-1000 Temperature Sensing	1 - 21
1.2.8	ASX-1000 Common Equipment Card (CEC)	1 - 22
1.2.8.1	CEC Front Panel	1 - 22
1.2.8.2	Alarm Relay Contacts	1 - 23
1.2.8.3	CEC Status LEDs	1 - 25
1.2.8.3.1	Alarm LEDs	1 - 26
1.2.8.3.2	Power Supply LEDs	1 - 27
1.2.8.3.3	Switch Board LEDs	1 - 27
1.2.8.4	Ethernet Port	1 - 27
 CHAPTER 2 Switch Setup		
2.1	Introduction	2 - 1
2.2	Unpacking	2 - 2
2.2.1	Inventorying the Unit	2 - 2
2.3	Electrical Considerations	2 - 3
2.4	Rack-Mounting an ASX-200, 200WG, or 200BX	2 - 4
2.4.1	Required Tools	2 - 4
2.4.2	Installing the Rack-mount Brackets	2 - 5
2.5	Rack-Mounting an ASX-1000	2 - 7
2.5.1	Installing the ASX-1000	2 - 8
2.6	Installing the Serial Cable	2 - 9

2.7	Modem Configuration	2 - 10
2.7.1	Serial Port Configuration for an ASX-200.	2 - 10
2.7.2	Modem Parameters	2 - 11
2.8	Configuring IP Addresses.	2 - 12
2.9	AMI Security	2 - 13
2.10	Subsequent Operation	2 - 14
2.11	Verifying the Installation	2 - 15
2.12	Product Registration Information	2 - 15

CHAPTER 3 Hardware Maintenance Procedures

3.1	Network Module Replacement	3 - 1
3.1.1	Overview.	3 - 1
3.1.2	Multicast Mode	3 - 2
3.1.3	Hot-swapping Network Modules.	3 - 3
3.2	Power Supply Module Replacement.	3 - 4
3.2.1	ASX-200BX Power Supply Module Replacement	3 - 4
3.2.1.1	Replacing an ASX-200BX AC Power Supply.	3 - 4
3.2.1.2	Replacing an ASX-200BX DC Power Supply	3 - 6
3.2.2	ASX-1000 Power Supply Module Replacement	3 - 8
3.2.2.1	Replacing an ASX-1000 AC Power Supply (Model A).	3 - 8
3.2.2.2	Replacing an ASX-1000 AC Power Supply (Model B).	3 - 11
3.2.2.3	Replacing an ASX-1000 DC Power Supply	3 - 14
3.3	ASX-1000 Fan Tray Replacement.	3 - 17
3.4	Switch Control Processor Replacement.	3 - 18
3.5	Switch Board Replacement	3 - 20

CHAPTER 4 Software Upgrade Instructions

4.1	Obtaining the Software Upgrade File	4 - 2
4.1.1	Obtaining the Software Upgrade File via FTP	4 - 2
4.1.2	Obtaining the Software Upgrade File via Diskette	4 - 4
4.2	Requirements for Upgrading an ASX-200WG	4 - 6
4.2.1	Downloading the Mini Loader Software	4 - 6
4.2.2	Emptying the FLASH	4 - 7
4.2.3	Upgrading the Switch to Mini Loader	4 - 7
4.2.4	Deleting the Active Switch Software.	4 - 8
4.3	Performing the Software Upgrade	4 - 9
4.4	Loading the New Software Image onto the ASX-200.	4 - 12
4.5	Changing between Multiple Versions of Software	4 - 14

Table of Contents

4.6	Bootting and Upgrading with Mini Loader	4 - 16
4.6.1	Setting the IP Address of the Switch	4 - 18
4.6.2	Setting the Gateway Address	4 - 18
4.6.3	Performing the Upgrade	4 - 19
4.7	Using bootp to Download Software to the Switch	4 - 21
4.7.1	Overview	4 - 22
4.7.2	Setting Up a bootp Server	4 - 22
4.7.3	Adding a Switch Entry in the bootptab File	4 - 23
4.7.4	Setting Up a TFTP Server	4 - 25
 APPENDIX A Troubleshooting		
A.1	Adapter Hardware Troubleshooting	A - 1
A.1.1	Run Looptest	A - 3
A.1.2	Check Self-Test (Automatically Performed)	A - 4
A.1.3	Firmware Download (Automatically Performed)	A - 4
A.1.4	Hardware Detected by Driver	A - 4
A.1.5	Check Firmware	A - 5
A.1.6	Check Physical Link	A - 6
A.2	Testing Network Connectivity Using PVCs	A - 7
A.2.1	Verifying the Outgoing ATM ARP Entry	A - 9
A.2.2	atmstat	A - 10
A.2.2.1	No Cells Received by Remote End	A - 11
A.2.2.2	Cells and VPI/VCI Errors Received by Remote	A - 11
A.2.2.3	Cells and AAL* Errors Received by Remote	A - 11
A.2.2.4	Cells and No Errors Received by Remote and Transmitting No Cells	A - 12
A.2.2.5	Cells and No Errors Received by Remote and Transmitting Cells	A - 12
A.3	Collecting Additional Information	A - 13
A.3.1	Basic Information	A - 13
A.3.2	Adapter Information	A - 13
A.3.3	Switch Information	A - 16

APPENDIX B SCP Diagnostics

B.1	ASX-200WG, ASX-200BX, ASX-1000 Diagnostics	B - 1
B.1.1	Accessing the Monitor Mode	B - 2
B.1.2	Running the Hardware Tests	B - 4
B.1.2.1	Clock Test	B - 4
B.1.2.2	DRAM Test	B - 4
B.1.2.3	DRAM Chip Test	B - 5
B.1.2.4	Ethernet Test	B - 5
B.1.2.5	FLASH Test	B - 5
B.1.2.6	FLASH Chip Test	B - 6
B.1.2.7	Serial Port Test	B - 7
B.1.2.8	SRAM Test	B - 7
B.1.2.9	Timer Test	B - 7
B.1.2.10	Hardware Test	B - 7
B.1.2.11	Complete Hardware Test	B - 8
B.2	SCP-ASXHA Diagnostics	B - 9
B.3	ASX-200 Diagnostics	B - 10

APPENDIX C Hardware Specifications

C.1	<i>ForeRunner</i> ATM Switches	C - 1
C.1.1	<i>ForeRunner</i> ASX-200	C - 2
C.1.2	<i>ForeRunner</i> ASX-200WG	C - 3
C.1.3	<i>ForeRunner</i> ASX-200BX	C - 4
C.1.4	<i>ForeRunner</i> ASX-1000	C - 5
C.2	<i>ForeRunner</i> ATM Network Modules	C - 6
C.2.1	100 Mbps TAXI Module	C - 6
C.2.2	155 Mbps OC-3c/STM-1 MM Module	C - 7
C.2.3	155 Mbps STS-3c/STM-1 UTP Module	C - 8
C.2.3.1	155 Mbps UTP Pinout Specifications	C - 9
C.2.3.2	Connecting Switches with 155 Mbps UTP Network Modules	C - 9
C.2.4	622 Mbps OC-12c/STM-4c MM Module	C - 10
C.2.5	1.5 Mbps DS1 Module	C - 11
C.2.6	1.5 Mbps DS1 Circuit Emulation Services Module	C - 12
C.2.6.1	DS1 Pinout Specifications	C - 13
C.2.7	2 Mbps E1 Module	C - 14
C.2.7.1	E1 Pinout Specifications	C - 15
C.2.8	6 Mbps J2 Module	C - 16

Table of Contents

C.2.9	25 Mbps TP25 Module	C - 17
C.2.9.1	Connecting Switches with TP25 Network Modules	C - 18
C.2.9.2	Connecting Switches with Token Ring Pinouts to <i>ForeRunner</i> Switches	C - 18
C.2.9.3	Connecting Adapters with Token Ring Pinouts to <i>ForeRunner</i> Switches	C - 19
C.2.10	34 Mbps E3 Module	C - 20
C.2.11	45 Mbps DS3 Module	C - 21
C.2.12	155 Mbps OC-3c/STM-1 SM Module	C - 22
C.2.13	155 Mbps OC-3c/STM-1 3MM/1SM Module	C - 23
C.2.14	622 Mbps OC-12c/STM-4c SM Module	C - 25

Acronyms

Glossary

Index

Preface

This manual provides the technical information needed to install *ForeRunner*[™] ATM Switches, *ForeRunner* LAN and WAN network modules, and the accompanying *ForeThought*[™] software. This document also provides safety instructions, general product information, diagnostic information, and troubleshooting information. This document was created for users with various levels of experience. If you have any questions or problems with the installation, please contact FORE Systems' Technical Support.

Chapter Summaries

Chapter 1 - Switch Hardware - Provides a description of the various *ForeRunner* ATM switch hardware components.

Chapter 2 - Switch Setup - Provides information for the installation of a switch and how to verify a successful installation.

Chapter 3 - Hardware Maintenance Procedures - Describes the hot-swap replacement procedures for the switch and network modules.

Chapter 4 - Software Upgrade Instructions - Describes how to configure a TFTP server, upgrade switch software, and change between multiple versions of software.

Appendix A - Troubleshooting - Contains basic troubleshooting information for switches and adapters.

Appendix B - SCP Diagnostics - Describes the diagnostic software for the SCP.

Appendix C - Hardware Specifications - Provides cabling, pinout, hardware, and general operating specifications for *ForeRunner* ATM switches and network modules.

Technical Support

In the U.S.A., you can contact FORE Systems' Technical Support using any one of the following methods:

1. If you have access to the Internet, you may contact FORE Systems' Technical Support via e-mail at:

support@fore.com

2. You may FAX your questions to "support" at:

412-742-7900

3. You may send questions, via U.S. Mail, to:

**FORE Systems, Inc.
1000 FORE Drive
Warrendale, PA 15086**

4. You may telephone your questions to "support" at:

800-671-FORE (3673) or 412-635-3700

Technical support for non-U.S.A. customers should be handled through your local distributor.

No matter which method is used for support, please be prepared to provide your support contract ID number, the serial number(s) of the product(s), and as much information as possible describing your problem/question.

Typographical Styles

Throughout this manual, all specific commands meant to be entered by the user appear on a separate line in bold typeface. In addition, use of the Enter or Return key is represented as <ENTER>. The following example demonstrates this convention:

```
cd /usr <ENTER>
```

File names that appear within the text of this manual are represented in the following style: “...the `fore_install` program installs this distribution.”

Command names that appear within the text of this manual are represented in the following style: “...using the **flush-cache** command clears the bridge cache.”

Subsystem names that appear within the text of this manual are represented in the following style: “...to access the **bridge** subsystem...”

Parameter names that appear within the text of this manual are represented in the following style: “...using `<seg-list>` allows you to specify the segments for which you want to display the specified bridge statistics.”

Any messages that appear on the screen during software installation and network interface administration are shown in **Courier** font to distinguish them from the rest of the text as follows:

```
.... Are all four conditions true?
```

Important Information Indicators

To call your attention to safety and otherwise important information that must be reviewed to ensure correct and complete installation, as well as to avoid damage to the FORE Systems product or to your system, FORE Systems utilizes the following **WARNING/CAUTION/NOTE** indicators.

WARNING statements contain information that is critical to the safety of the operator and/or the system. Do not proceed beyond a **WARNING** statement until the indicated conditions are fully understood or met. This information could prevent serious injury to the operator, damage to the FORE Systems product, the system, or currently loaded software, and is indicated as follows:

WARNING!



Hazardous voltages are present. To reduce the risk of electrical shock and danger to personal health, follow the instructions carefully.

CAUTION statements contain information that is important for proper installation/operation. Compliance with **CAUTION** statements can prevent possible equipment damage and/or loss of data and are indicated as follows:

CAUTION



You risk damaging your equipment and/or software if you do not follow these instructions.

NOTE statements contain information that has been found important enough to be called to the special attention of the operator and is set off from the text as follows:



If you change the value of the LECS control parameters while the LECS process is running, the new values do not take effect until the LECS process is stopped, and then restarted.

Laser Notice

Class 1 Laser Product:
This product conforms to
applicable requirements of
21 CFR 1040 at the date of
manufacture.

Class 1 lasers are defined as products which do not permit human access to laser radiation in excess of the accessible limits of Class 1 for applicable wavelengths and durations. These lasers are safe under reasonably foreseeable conditions of operation.

Every FORE Systems network module having a fiber optic interface contains a Class 1 laser.

NOTE

The Laser Notice section only applies to products or components containing Class 1 lasers.

Safety Precautions

For your protection, observe the following safety precautions when setting up equipment:

- Follow all warnings and instructions marked on the equipment.
- Ensure that the voltage and frequency of your power source matches the voltage and frequency inscribed on the equipment's electrical rating label.
- Never push objects of any kind through openings in the equipment. Dangerous voltages may be present. Conductive foreign objects could produce a short circuit that could cause fire, electric shock, or damage to your equipment.

Modifications to Equipment

Do not make mechanical or electrical modifications to the equipment. FORE Systems, Inc., is not responsible for regulatory compliance of a modified FORE product.

Placement of a FORE Systems Product

CAUTION



To ensure reliable operation of your FORE Systems product and to protect it from overheating, openings in the equipment must not be blocked or covered. A FORE Systems product should never be placed near a radiator or heat register.

Power Cord Connection

WARNING!



FORE Systems products are designed to work with single-phase power systems having a grounded neutral conductor. To reduce the risk of electrical shock, do not plug FORE Systems products into any other type of power system. Contact your facilities manager or a qualified electrician if you are not sure what type of power is supplied to your building.

WARNING!



Your FORE Systems product is shipped with a grounding type (3-wire) power cord. To reduce the risk of electric shock, always plug the cord into a grounded power outlet.

Preface

CHAPTER 1

Switch Hardware

FORE Systems offers a full line of *ForeRunner*TM ATM products that work together to provide a complete ATM network solution. The *ForeRunner*TM ASX-200 ATM switch and the *ForeRunner*TM ASX-200WG ATM switch provide high-performance ATM connectivity for LAN workgroup and desktop applications. The *ForeRunner*TM ASX-200BX ATM switch and the *ForeRunner*TM ASX-1000 ATM switch offer high reliability and port density for LAN backbone and LAN/WAN internetworking applications. Together with the *ForeRunner* series of ATM LAN and WAN Network Modules, these switches meet the networking demands of today's distributed, time-critical applications.

All of the *ForeRunner* ATM switches deliver high-performance switching capacity and speed for ATM applications. A non-blocking switching capacity of 2.5 Gbps is continually available on the ASX-200, the ASX-200WG, and the ASX-200BX. Each switch provides up to 4 ports of connectivity, each running at speeds up to 622 Mbps; or up to 16 ports, each running at speeds up to 155 Mbps; or up to 24 ports, each running at speeds up to 100 Mbps. The ASX-1000 provides 10 Gbps of switching capacity for up to 16 ports of connectivity, each running at speeds up to 622 Mbps; or up to 64 ports, each running at speeds up to 155 Mbps; or up to 96 ports, each running at speeds up to 100 Mbps.

Wide-area network (WAN) connectivity is seamlessly integrated into the ASX-200BX and the ASX-1000 for connection to private networks or ATM SONET, DS3, DS1, E3, E1, or J2 services.

Interconnecting multiple *ForeRunner* switches at various speeds is simple. Once a new switch is added to the network, all other switches recognize its presence and dynamically establish connections to ports on the new switch. Furthermore, scaling the network is accomplished without costly and time consuming address reconfiguration and LAN segmentation.

This chapter provides an overview of the FORE Systems' family of *ForeRunner* ATM switches. It details the hardware requirements necessary to use these switches and also provides information on the contents of each of the switch packages.

1.1 Switch Hardware Configurations



For information about the technical and operating specifications for all of the *ForeRunner* ATM switches, see Appendix C, “*ForeRunner* Hardware Specifications,” in this manual.

The ASX-200, as shown in Figure 1.1, is a self-contained ATM switch that provides an Ethernet connection for network management access. The ASX-200 hardware consists of a single switch board, a SPARC RISC switch control processor (SCP), network modules, and fans housed in a rack-mount 19-inch horizontal enclosure. These components work together to provide ATM switching capabilities, as well as distributed connection setup and management.



Figure 1.1 - ASX-200 Switch Configuration

The ASX-200WG, as shown in Figure 1.2, is a self-contained ATM switch that provides an Ethernet connection for network management access. The ASX-200WG ATM switch hardware consists of a single switch board with an i960 SCP, network modules, and fans. These components work together to provide ATM switching capabilities, as well as distributed connection setup and management.



Figure 1.2 - ASX-200WG Switch Configuration

The ASX-200BX, as shown in Figure 1.3, is a self-contained ATM switch that provides an Ethernet connection for network management access. The ASX-200BX hardware consists of a single switch board with an i960 SCP, network modules, redundant power supplies, and fans. These components work together to provide ATM switching capabilities, as well as distributed connection setup and management.



Figure 1.3 - ASX-200BX Switch Configuration

The ASX-1000, as shown in Figure 1.4, is a self-contained ATM switch that provides an Ethernet connection for network management access. The hardware for the ASX-1000 consists of up to four switch boards, each with an i960 SCP; network modules; redundant power supplies; a Common Equipment Card (CEC); and a removable fan tray. These components work together to provide ATM switching capabilities, as well as distributed connection setup and management.



Figure 1.4 - ASX-1000 Switch Configuration

1.2 Switch Hardware Components

1.2.1 Switch Board

The switch board (also referred to as the “switch fabric”) contains the VPI/VCI lookup tables and routing circuitry to ensure that a cell received from an input port is correctly switched to one or more output ports. The ASX-200, the ASX-200WG, and the ASX-200BX each come with one switch board. The ASX-1000 can be populated with as many as four switch boards. Each switch board can accept up to four network modules, which themselves can contain up to six ports each. The switch board also has an interface, controlled by the SCP, that is functionally equivalent to an ATM host interface.

1.2.2 Switch Control Processor

The SPARC RISC SCP in the ASX-200 and the i960 SCP in the ASX-200WG, ASX-200BX, and the ASX-1000 provide the distributed connection setup for a network of ATM switches. The SCP primarily provides management access through SNMP and is responsible for storing and updating all SNMP management information. Additionally, the SCP has direct access to the switch board. The SCP, and associated software, manages the behavior of the switch board (i.e., connection setup), but is not involved in the actual cell switching.

1.2.2.1 SPARC RISC Switch Control Processor

The front panel of the ASX-200’s SPARC RISC SCP includes a RESET switch; an ABORT switch; three single LEDs: the RUN/RESET LED, the VME BM (Bus Master) LED, and the STATUS LED; a diagnostics display; two serial ports (labeled A and B); and an Ethernet port. All of the features are illustrated in Figure 1.5 and are described in the subsections that follow.



Figure 1.5 - ASX-200 SPARC RISC Switch Control Processor Front Panel

1.2.2.1.1 RESET Switch

The RESET switch on the SPARC RISC SCP allows the user to reset the SCP. After a reset, all open ATM Management Interface (AMI) sessions are ended on the SCP, and all ports on the switch board lose any active sessions and initially go off-line. The ports then return to the configuration stored in the configuration database (CDB).

1.2.2.1.2 ABORT Switch

When activated, the ABORT switch on the ASX-200 causes the SCP to go into Open Boot PROM mode. This mode allows the user to run diagnostics on the controller hardware from a terminal connected to Serial Port A. The SCP halts normal switch operations when in the Open Boot PROM mode.

1.2.2.1.3 RUN/RESET LED

The RUN /RESET LED is red when any reset signal on the switch is active. It is off when the switch itself is not active. In all other cases, it is green.

1.2.2.1.4 VME BM LED

The VME BM LED on the ASX-200 reflects all accesses from the SCP to the ASX-200 switch board. When the SCP accesses the switch, this LED illuminates green. In all other cases, it is off.

1.2.2.1.5 STATUS LED

The STATUS LED on the ASX-200 indicates that the SCP is functional by illuminating green. In all other cases, it is off.

1.2.2.1.6 Diagnostics Display

The diagnostics display on the ASX-200 performs a count during a boot as part of normal power-up diagnostics. A short LED test causes the display to flash a series of numbers indicating that the switch is booting properly. This display is only functional during the boot-up process.

1.2.2.1.7 RS-232 Serial Ports

The RS-232 serial ports (A and B) on the ASX-200 provide terminal access for any VT100 (or similar) terminal or terminal emulation package to the SCP.



Hardware/software flow control is not supported on the RS-232 serial ports of the SPARC RISC SCP.

1.2.2.1.8 Ethernet AUI Port

The Ethernet AUI port on the front panel of the ASX-200's SCP has a standard DB-15 female connector to provide Ethernet access to the switch.

1.2.2.2 i960 Switch Control Processor

The front panel of an i960 SCP for the ASX-200WG, ASX-200BX, and the ASX-1000 includes the following features: a RESET button, an RS-232 serial port, an Ethernet 10BaseT port, a NEXT pushbutton, a SELECT pushbutton, a display LED, and a power LED. All of the features are illustrated in Figure 1.6 and are described in detail in the subsections that follow.



Figure 1.6 - i960 Switch Control Processor Front Panel

1.2.2.2.1 RESET Button

The RESET button allows the user to reset the switch control software on the SCP. Using RESET “soft boots” the SCP and runs the initial power-on diagnostics. All open AMI sessions are ended by the SCP, and all ports lose any active sessions and initially go off-line after a reset. The ports then return to the configuration stored in the CDB. Because the RESET button is small (to avoid accidental resets), it is recommended that you use a straightened paper clip to push the RESET button.

1.2.2.2.2 RS-232 Serial Port

The RS-232 serial port provides terminal access for any VT100 (or similar) terminal or terminal emulation package to the SCP. The serial port has a standard DB-9 female connector as shown in Figure 1.7.




Figure 1.7 - RS-232 Serial Port Pinouts

Table 1.1 describes the RS-232 serial port pinouts that are illustrated in Figure 1.7.

Table 1.1 - RS-232 Serial Port Pinouts

Pin Number	Signal Mnemonic	Signal Name
1	DCD	Data Carrier Detect
2	RXD	Receive Data
3	TXD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Signal Ground
6	DSR	Data Set Ready
7	RTS	Request to Send
8	CTS	Clear to Send
9		Not Used

1.2.2.2.3 Ethernet 10BaseT Port

The Ethernet 10BaseT port on the front panel of the SCP has a standard RJ45 connector. There is a transmit LED to the left of this port and a receive LED to the right of this port. Table 1.2 and Table 1.2 describe the states of the LEDs and their meanings.

Table 1.2 - Ethernet 10BaseT Transmit LED Description

LED Color	Meaning
red	There is a collision on the port.
green	The port is transmitting normally.

Table 1.3 - Ethernet 10BaseT Receive LED Description

LED Color	Meaning
red	The port is failing link integrity.
green	The port is receiving normally.

1.2.2.2.4 CTL Port

A control port inside the SCP, referred to in the switch software as the CTL port, is a logical (not physical) location where cells that are directed to the SCP itself are sent. The CTL port has two roles, serving as both a host and a switch board controller. All signalling from the switch host and every attached host must interact with the switch board controller.

1.2.2.2.5 NEXT Pushbutton

The NEXT pushbutton lets you scroll through the menu that is shown on the display LED after the power is turned on or after the SCP is reset/rebooted.

1.2.2.2.6 SELECT Pushbutton

The SELECT pushbutton lets you choose an option from the menu that is shown on the display LED after the power is turned on or after the SCP is reset/rebooted.

1.2.2.2.7 Display LED

During the boot process and the initial power-on diagnostics, the display LED shows messages about what is happening to the SCP. It is also used to show the menu choices for the NEXT and SELECT pushbuttons after the power is turned on or after the SCP is reset/rebooted. The choices shown on the display LED are as follows:

Flash ?	When chosen, the SCP will attempt to boot from the FLASH file.
Ethernet ?	When chosen, the SCP boots from the network.
Monitor ?	When chosen, the user can connect a terminal to the serial port and run hardware self-diagnostics.
Auto ?	When chosen, the SCP will attempt to boot from the FLASH. If this is unsuccessful, then the SCP will perform an Ethernet boot.

To access the modes listed above, press the NEXT pushbutton while the switch is booting until the mode you want to access is displayed LED. Then, press the SELECT pushbutton.

After the boot process and self-diagnostics are complete, the name of the SCP is shown in the display LED during normal operations, if an SCP name has been assigned. If an SCP name has not been assigned, it will display **ATM SWITCH**. For information on creating or modifying the SCP name, please refer to the section on configuring the SCP name in the *ATM Management Interface Manual*.

1.2.2.2.8 Power LED

The power LED that is located to the right of the display LED on the front panel of the SCP reflects the current state of power to the SCP. Table 1.2 lists the states of the power LED and their meanings.

Table 1.4 - Power LED Description

LED Color	Meaning
red	The SCP has power, but has failed. (The individual SCP, not the entire switch, has not passed self-diagnostics.)
green	The SCP is powered up and is in good status.
off	There is no power to the SCP.

A power switch is located on the upper right-hand corner of the ASX-200WG. When the power is turned on, the power LED, located to the right of the display LED, illuminates green and the initial power-on diagnostics are run. When the power is turned off, the power LED is extinguished.

1.2.3 Dual SCP Setup

This section explains SCP failover support, available when two SCPs are installed in a single ASX-200BX or ASX-1000 switch fabric. For more information about configuring dual SCP's via AMI, see the *ATM Management Interface Manual*.



Only SCP-ASXHAs, or later, support the dual SCP configuration. Using an earlier version SCP in a redundant configuration can cause irreparable damage to your switch fabric.

When two SCPs are installed in a switch fabric, the switch recognizes their presence and automatically runs in dual SCP mode. When the switch boots, the SCP which resides in slot X is designated as the primary SCP by default. However, this designation can be altered via AMI. The SCP which resides in slot Y is designated as the standby SCP by default.

While in dual SCP mode, the controlling SCP emits a “heartbeat” at regular intervals. This heartbeat is monitored by the standby SCP. In the event of a hardware failure on the controlling SCP, the heartbeat disappears and the standby SCP takes over.

Switch configuration information (i.e., CDB configuration, FLASH configuration, etc.) can be synchronized between the controlling and standby SCP so that this information is maintained if SCP failover occurs.

If a failure is detected on the controlling SCP, the standby SCP takes control of the fabric. At this point, PVC connections are dropped, and any SVCs that had been established are torn down at the switch. Once the standby SCP takes control of the switch fabric, PVCs will be re-established (according to the “last-synchronized” CDB), and end-stations will signal the switch to create new SVCs. The larger the CDB (e.g., number of PVCs), the longer the standby SCP will take to fully restore the switch.

The failed SCP can then be removed and replaced with another HA-based SCP.



A standby SCP (SCP-ASXHA or later) can be hot-inserted into the slot from which a failed SCP has been removed.

Repeated and successive hot-insertion or removal of a standby SCP can potentially cause a reset on the primary SCP. This occurrence is intermittent, but will result in cell loss if it does occur.



For proper synchronization of information between SCPs, ensure that the amount of free space on both SCPs is roughly equal before performing these commands.

1.2.3.1 Adding a Standby SCP

If only one SCP is installed in the switch fabric, it automatically assumes itself to be the controlling SCP. In this case, the SCP periodically checks the fabric for the presence of a second SCP. If a second SCP is detected, the switch will begin to run in dual SCP mode.

While in dual mode, the controlling SCP continually monitors the presence of the standby SCP. If the controlling SCP fails to detect a second SCP, the controlling SCP disables all synchronization and runs in standalone mode (not dual).

1.2.3.2 Rebooting the Controlling SCP

When the switch is running in dual mode, a reboot request on the controlling SCP (i.e., after a software upgrade) will not cause the standby SCP to take control of the switch. Instead, the controlling SCP will send a pause signal to the standby SCP.

This pause request will force the standby SCP to disregard the absence of the controlling SCP for two minutes. Once the controlling SCP comes back up, both SCPs will assume normal, dual mode operation.

1.2.3.3 Ethernet Connection

When two SCPs are installed in an ASX-200BX, Ethernet connectivity is only available if the Ethernet port on each SCP is physically connected to the network. If dual SCP mode is utilized on an ASX-1000, the Ethernet connection can be made using the individual SCPs or the Ethernet port on the ASX-1000's Common Equipment Card (CEC).

If the SCP is accessed via ATM, the Ethernet connection is not necessary.

NOTE

If two SCPs are installed in a switch fabric, each SCP must have its own entry in the bootptab file (used for network booting) to assign each SCP a unique IP address. Using only one entry (i.e., the same IP address) causes unpredictable Ethernet ARP behavior (see Chapter 4 for more information).

1.2.4 Network Modules

The network modules in a *ForeRunner* switch board act as the physical input/output ports to the switch board. A network module may have one, two, four, or six physical ports, depending on its configuration.

1.2.4.1 Port Numbering

The individual ports on a network module are numbered according to the Board-Network Module-Port (BNP) notation.

Board Refers to the number of the switch board that contains the port being numbered. “Board” is always 1 in an ASX-200, ASX-200BX, or an ASX-200WG, since these switches each contain only one switch board. “Board” can be 1, 2, 3, or 4 in an ASX-1000, depending on the number of the physical switch board that contains the port being numbered.

Network Module Refers to the slot (A, B, C, or D) in the switch board that contains the port being numbered.

Port Refers to the physical port (1 - 6) being numbered on the individual network module.

For example, according to this notation, the fourth port on a network module in slot B of switch board #2 is port 2B4.

Figure 1.8 illustrates how the ports of various network modules, located in switch board #4 of an ASX-1000, for example, would be numbered.




Figure 1.8 - Network Module Port Numbering



For information about the technical and operating specifications for all *ForeRunner* ATM network modules, see Appendix C, “*ForeRunner* Hardware Specifications,” in this manual.

1.2.5 Power Supply Modules

The ASX-200BX and the ASX-1000 each come with two removable power supply modules, either AC or DC. In the event of a single power supply failure, the power supply indicator LED(s) on the front panel of the supplies will indicate the failed supply. The failed power supply can be removed and replaced while the other supply continues to provide power to the enclosure. In this manner, a single power supply failure will not cause the switch to stop functioning.

WARNING!



The ASX-200 and the ASX-200WG come with internal, non-removable power supplies. Attempting to remove these power supplies could result in serious injury or may cause permanent damage to the unit.

1.2.5.1 ASX-200BX AC Power Supply

The ASX-200BX has two power supply LEDs, one for each removable, hot-swappable power supply. Each LED is located to the left of the power switch on the front panel for that supply. On the AC power supply for the ASX-200BX, the LED is green under normal circumstances, indicating that the 5-volt supply coming from that particular power supply is functioning properly.

CAUTION



If the power supply LED is red, the faulty supply should be turned off as soon as possible, using the single power switch which controls power to that supply. The problem should then be diagnosed and repaired. Please refer to Chapter 3, Hardware Maintenance Procedures, for details about how to hot-swap a power supply in the ASX-200BX.

NOTE



A replacement AC power supply will not function in a DC-equipped ASX-200BX, and vice-versa. However, no damage will be done if this occurs.

1.2.5.2 ASX-200BX -48 Volt DC Power Supply

On the back of the DC-equipped ASX-200BX, there are two three-terminal barrier terminal strips, one for each -48 volt DC power supply, as shown in Figure 1.9. The screw terminals are #6 screws. The -48 volt feed wires should be attached to the terminal strips using wire terminals designed to fit #6 studs. FORE Systems recommends using either ring terminals or locking forked tongue terminals. Wire gauge should be AWG #16 or larger.




Figure 1.9 - Rear Panel of a DC-powered ASX-200BX

CAUTION



Be sure to observe polarity. Failure to do so may cause permanent damage to the unit.

The higher potential wire should be connected to the positive (+) terminal, and the lower potential wire to the negative (-) terminal. The chassis ground wire also should be connected to the center terminal ($\perp$) and connected to an earth ground.




Figure 1.10 - Front View of an ASX-200BX's DC Power Supplies

The ASX-200BX has two power supply LEDs, one for each removable, hot-swappable power supply. Each LED is located to the left of the power switch on the front panel for that supply as shown in Figure 1.10. On the DC power supply for the ASX-200BX, the LED is green under normal circumstances, indicating that the 5-volt supply coming from that particular power supply is functioning properly.

CAUTION



If the power supply LED is red, the faulty supply should be turned off as soon as possible, using the single power switch which controls power to that supply. The problem should then be diagnosed and repaired. Please refer to Chapter 3, Hardware Maintenance Procedures, for details about how to hot-swap a power supply in the ASX-200BX.



A replacement DC power supply will not function in an AC-equipped ASX-200BX, and vice-versa. However, no damage will be done if this occurs.

1.2.5.3 ASX-1000 AC Power Supply (Model A)

The model A AC power supply for an ASX-1000 is shown in Figure 1.11.




Figure 1.11 - Model A ASX-1000 AC Power Supply

1.2.5.3.1 Power Supply LEDs

There are four status LEDs on the front panel of the model A ASX-1000 AC power supply. The LEDs and their functions are described in Table 1.5.

Table 1.5 - ASX-1000 Power Supply LED Descriptions

LED	Color	Meaning
AC OK	Green	Input voltage is OK
	extinguished	No input voltage or unit has shut down
DC OK	Green	Backplane output is OK
	extinguished	Backplane output is not present or out of range
5VDC OK	Green	Backplane standby voltage is OK
	extinguished	Backplane standby voltage not present or out of range
SHUTDOWN	Yellow	Supply is in shutdown
	extinguished	Supply is operating correctly or is OFF

1.2.5.3.2 Shutdown Conditions

To avoid damaging itself or the switch, the model B ASX-1000 AC power supply shuts itself down under the following condition:

Overload The power supply is overloaded or the AC input is out of specification, and the supply voluntarily shuts down to avoid damage to the system.



The ASX-1000 CEC can not shut down the model A power supply. Only the power supply can shut itself down in an overload state.

If a model A power supply goes into shutdown, it will remain shut down until the power switch is turned off and turned on again (power cycle). The power switch must remain off long enough for the SHUTDOWN LED to extinguish (this allows the capacitors to discharge).

WARNING!



A replacement AC power supply should never be placed in an ASX-1000 that already contains a DC power supply, and vice-versa. If these instructions are not heeded, there is a risk of electrical shock, danger to personal health, and serious damage to the equipment.

If the power supply needs to be replaced, please refer to Chapter 3 for hot-swap information.

1.2.5.4 ASX-1000 AC Power Supply (Model B)

The model B AC power supply for an ASX-1000 is shown in Figure 1.12.




Figure 1.12 - Model B ASX-1000 AC Power Supply

1.2.5.4.1 Power Supply LEDs

There are four LEDs on the front panel of the model B ASX-1000 AC power supply which indicate the status of the power supply. The LEDs and their functions are described in Table 1.6:

Table 1.6 - ASX-1000 Power Supply LED Descriptions

LED	Color	Meaning
PWR OK	Green	Input voltage is OK
	extinguished	No input voltage or unit has shut down
FAULT	Yellow	Power supply has faulted
	extinguished	No faults detected in power supply
TEMP	Yellow	Operating temperature out of range
	extinguished	Running within safe temperature range
I LIM	Yellow	Overload condition
	extinguished	Load in range

1.2.5.4.2 Shutdown Conditions

To avoid damaging itself or the switch, the model B ASX-1000 AC power supply shuts itself down under the following error conditions:

- Input undervoltage

The AC line voltage is below 87 ±5VAC RMS.
- Output undervoltage

Output 1 is 42 ±2 VDC or Output 2 is below 4.5 ±0.25 VDC. Shutdown from undervoltage is defeated during power-up period (2 seconds maximum) to allow slow-start.
- Output overvoltage

The voltage at Output 1 or Output 2 is above 125% ±8% of the nominal voltage.
- Overtemperature

Any power semiconductor has reached 90% of its maximum junction temperature.



The ASX-1000 CEC can not shut down the model B power supply. Only the power supply can shut down and restart itself.

If a model B power supply goes into shutdown, it remains turned off until the fault condition is rectified. At that point, the power supply restarts itself, except in the case of an overvoltage condition.

To recover from a shutdown caused by an overvoltage state, the AC line input must be turned off for at least one second.

WARNING!



A replacement AC power supply should never be placed in an ASX-1000 that already contains a DC power supply, and vice-versa. If these instructions are not heeded, there is a risk of electrical shock, danger to personal health, and serious damage to the equipment.

If the power supply needs to be replaced, please refer to Chapter 3, Hardware Maintenance Procedures, for hot-swap information.

1.2.5.5 ASX-1000 -48 Volt DC Power Supply

On the front of the -48 volt ASX-1000 power supply, there are two three-terminal barrier terminal strips, one for each power supply. The screw terminals are #6 screws. The -48 volt feed wires should be attached to the terminal strips using wire terminals designed to fit #6 studs. FORE Systems recommends using either ring terminals or locking forked tongue terminals. Wire gauge should be AWG #12 or larger.

WARNING!



Be sure to observe polarity when attaching the wire leads to the terminals. Failure to observe polarity may result in injury or cause permanent damage to the unit.

The higher potential wire should be connected to the positive (+) terminal, and the lower potential wire to the negative (–) terminal. The chassis ground wire should be connected to the center terminal ($\underline{\underline{\perp}}$) and connected to an earth ground.

The ASX-1000 has a single power supply LED on the front panel of each -48V DC power supply module. Under normal conditions, the LED is green, indicating that the voltage supplied to the module is above 40 volts DC. If the LED is red or is extinguished, the power supply module should be removed and examined for defect. However, the LED may turn red because the voltage being supplied to the module is insufficient. If the power supply itself is found to be defective, please refer to Chapter 3, Hardware Maintenance Procedures, for information about how to hot-swap the failed power supply.

WARNING!

A replacement DC power supply should never be placed in an ASX-1000 that already contains an AC power supply, and vice-versa. If these instructions are not heeded, there is a risk of electrical shock, danger to personal health, and serious damage to the equipment.

1.2.6 ASX-1000 Fan Tray

The ASX-1000 comes with a removable fan tray. The speed of each fan is monitored by circuitry in the CEC, and is available via SNMP. In this manner, the failure of any fan can be detected immediately. The fan tray is hot-swappable, and the entire tray may be replaced in the event of single or multiple fan failure. For information about how to hot-swap a fan tray, refer to Chapter 3, "Hardware Maintenance Procedures."

NOTE

The fans in the ASX-200, the ASX-200WG, and the ASX-200BX are not removable.

1.2.7 ASX-1000 Temperature Sensing

In the ASX-1000, a built-in thermal temperature sensor resides on each switch board and reads out the board's local temperature. By default, the switch control software will trigger an alarm at 65°C and will reset the alarm when the temperature drops back down to 60°C or lower. However, the user can configure these alarm and reset thresholds in the software on an individual board via AMI. Please refer to the *ATM Management Interface Manual* for more information about configuring these thresholds. If the temperature of an individual switch board were to reach 75°C, the switch board would shut itself down immediately.

CAUTION

This overtemperature condition is detectable by software, and will trigger an alarm condition which is visible through *ForeView* Network Management. Upon detection of an overtemperature condition, the ASX-1000 should be turned off to avoid damage to internal components.

1.2.8 ASX-1000 Common Equipment Card (CEC)

The CEC provided with the ASX-1000 performs several functions. Because each SCP contains an Ethernet port, a major function of the CEC is to provide a single, unified Ethernet port connection for all of the SCPs. The CEC is also responsible for monitoring the environmental conditions of the switch and reporting this information to the SCPs. The CEC reports conditions such as malfunctioning fans, overheated power supplies, and an overheated enclosure.

Two different CECs currently exist, model A and B. Both CECs operate in exactly the same way, and both are inserted/removed in the same way. The only difference between the model A and model B CEC is in the front panel labelling. On the model B card, component labels are read left to right with the CEC installed (vertically) in the switch. Also, the alarm relay contacts and alarm LEDs are labelled individually for easier identification.

1.2.8.1 CEC Front Panel

The front panel of the ASX-1000 CEC includes the following features: alarm relay contacts, CEC status LEDs, and an Ethernet port with four LEDs. These features are illustrated in Figure 1.13 (model A) and Figure 1.14 (model B). Refer to the following subsections for detailed descriptions of these features.




Figure 1.13 - CEC Front Panel Status Indicators (Model A)




Figure 1.14 - CEC Front Panel Status Indicators (Model B)

1.2.8.2 Alarm Relay Contacts

Pins 1 and 2 are the contacts for AL1, and pins 3 and 4 are the contacts for AL2. Although the pins are not actually labeled on an ASX-1000 CEC, they will be referred to sequentially from top to bottom (i.e., pin 1 is the top pin when the CEC is installed in the switch, and pin 4 is the bottom pin).




Figure 1.15 - Alarm Relay Contacts for AL1 and AL2

The alarm relay contacts are normally closed when there is no power to the switch. The user can attach alarm circuits to these contacts to trigger an external alarm in the case of an alarm condition on the switch.

The user can define AL1 and AL2 as major and minor alarm indicators and can display which condition is alarming through the use of AMI. For more information, please refer to the alarm configuration section in the *ATM Management Interface Manual*.

Table 1.7 - Alarm Relay Contact Status During Major and Minor Alarms


Condition	Pins 1 and 2	Pins 3 and 4
Switch Powered OFF	Jumped	Jumped
During Boot	Indeterminate	Indeterminate
Normal Operation	Open	Open
Minor Alarm Only	Jumped	Open
Major Alarm Only	Open	Jumped
Major and Minor Alarms	Jumped	Jumped



In Table 1.7, “Jumped” indicates that the circuit between the indicated pins has been closed (i.e., an external alarm would be triggered if connected to the pins).

1.2.8.3 CEC Status LEDs

This subsection discusses the meaning of the status LEDs on the CEC of the ASX-1000 switch. The LEDs have been designed to provide information pertaining to the state of the switch at a glance.

**Figure 1.16 - CEC Status LEDs (Model A)**




Figure 1.17 - CEC Status LEDs (Model B)

There are eight status LEDs located on the front panel of the CEC in a 2 x 4 arrangement. On the model A CEC, the only LEDs that are actually labeled are AL1 and AL2, but for the purposes of discussion, the other LEDs will be referred to as labeled in Figure 1.16. The LEDs have been broken down into the following function groups: alarm LEDs, power supply LEDs, and switch board LEDs.



On the model B CEC, the status LEDs are labelled the same from top to bottom as discussed here (see Figure 1.17).

1.2.8.3.1 Alarm LEDs

The LEDs labeled AL1 and AL2 are alarm relay LEDs. During boot-up, AL1 and AL2 are in an indeterminate state. During normal operation, they will be off. During a state of alarm, they will illuminate red. By default, AL1 is the major alarm indicator for fan failure, an overtemperature condition, or a power supply failure. By default, AL2 is the minor alarm indicator for SPANS failure and for link failure. The user may display and/or change these configurations through the use of AMI. For more information, please refer to the *ATM Management Interface Manual*.

1.2.8.3.2 Power Supply LEDs

There are two power supply LEDs on the front panel of the CEC, one for each power supply. The LEDs for the two power supplies should be illuminated yellow, indicating that the CEC is on and that the power supply corresponding to that LED is functioning correctly. The LED for a failed power supply will be extinguished. On an ASX-1000, power supply “1” is in the slot labeled PS1 on the enclosure, while power supply “2” is in the slot labeled PS2 on the enclosure.

1.2.8.3.3 Switch Board LEDs

There are four switch board LEDs on the front panel of the CEC, one for each possible switch board. These LEDs should be blinking, indicating that the switch has booted and is operating correctly. If the SCP is removed, the LEDs may remain in a steady-on or steady-off state. Even if the SCP has booted correctly, the LEDs will not illuminate if the SCP is running a software version prior to *ForeThought* 3.2.0. If the switch board in the slot corresponding to the LED is not intended for an ASX-1000 (e.g., it is an ASX-200BX board), or if the entire switch board corresponding to that LED is removed, then that LED will be extinguished. On an ASX-1000, the SW1 LED corresponds to switch board “1,” which is in the slot labeled 1 on the enclosure, and so on.

1.2.8.4 Ethernet Port

The Ethernet port located on the CEC of the ASX-1000 has a standard RJ-45 female connector and is designed to provide a single, unified Ethernet connection. It is connected via the back-plane and simple Ethernet repeater to each SCP's Ethernet port, thus eliminating the need to attach each SCP individually. This Ethernet port has four LEDs which indicate its current status as shown in Figure 1.18. These LEDs are described in Tables 1.8 through 1.11.




Figure 1.18 - CEC Ethernet Port and LEDs

NOTE

The Ethernet port on the model B CEC is rotated 180 degrees, but the Ethernet port LEDs are in the same relative location as before.

Table 1.8 - CEC Receive (RX) LED Description

LED Color	Meaning
green	The Ethernet port is receiving traffic normally.
off	The Ethernet port is NOT receiving traffic.

Table 1.9 - CEC Link Integrity (LI) LED Description

LED Color	Meaning
green	The status of the twisted pair cable connected to the CEC Ethernet port is OK.
off	The Ethernet port is NOT receiving link integrity pulses. Check the integrity of the connection.

Table 1.10 - CEC Collision (COL) LED Description

LED Color	Meaning
red	An Ethernet collision has been detected on the CEC Ethernet port.
off	No Ethernet collisions have been detected.

Table 1.11 - CEC Polarity (POL) LED Description

LED Color	Meaning
amber	A reverse polarity condition has been detected on the twisted pair cable connected to the CEC Ethernet port. The polarity is automatically corrected, but the amber light will remain illuminated until a corrected twisted pair cable is inserted into the Ethernet port.
off	The polarity of the twisted pair cable connected to the CEC Ethernet port is OK.

CHAPTER 2

Switch Setup

This chapter contains the following information about setting up a *ForeRunner* ATM switch:

- **Section 2.1** - Introduction
- **Section 2.2** - Unpacking
- **Section 2.3** - Electrical Considerations
- **Section 2.4** - Rack-Mounting an ASX-200, 200WG, or 200BX
- **Section 2.5** - Rack-Mounting an ASX-1000
- **Section 2.6** - Installing the Serial Cable
- **Section 2.7** - Modem Configuration
- **Section 2.8** - Configuring IP Addresses
- **Section 2.9** - AMI Security
- **Section 2.10** - Subsequent Operation
- **Section 2.11** - Verifying the Installation
- **Section 2.12** - Product Registration Information

2.1 Introduction

Before installing a *ForeRunner* ATM switch, there are several important factors that must be taken into consideration, depending on the type of installation site. The following sections discuss in detail how to install a *ForeRunner* ATM switch and any prerequisites to the installation.

NOTE

It is important to read through the ENTIRE installation procedure before attempting to turn on the power to the unit.

2.2 Unpacking

Upon receipt of, and before opening your *ForeRunner* ATM switch, inspect the package for any damage that may have occurred during shipping. If the package shows any signs of external damage or rough handling, notify your carrier's representative.

When unpacking your *ForeRunner* ATM switch, be sure to keep all original packing materials. They may be needed for storing, transporting, or returning the product.

CAUTION



All products returned to FORE Systems, under warranty, must be packed in their original packing materials.

2.2.1 Inventorying the Unit

An inventory of the switch package should be performed before supplying power to the unit. The *ForeRunner* ATM switch package should contain the following:

- *ForeRunner* ATM switch
- *ForeRunner* ATM Switch User's Manual (this manual)
- *ForeRunner* ATM Switch Configuration Manual
- ATM Management Interface Manual
- Power cords¹
- Modem serial cable
- Anti-static grounding strap
- Product registration card
- Rack-mount kit² containing:
 - 1 left rack-mount bracket
 - 1 right rack-mount bracket
 - 1 cable strain relief rail
 - 6 Phillips-head screws

If any of the items listed above are missing or damaged, please contact FORE Systems' Technical Support immediately.

¹ The ASX-200 and the ASX-200WG each come with one power cord. The ASX-200BX and the ASX-1000 each come with two power cords.

² The rack-mount kit is not applicable to the ASX-200 or to the ASX-1000. The rack-mount kit is optional for the ASX-200WG and may be purchased separately.

2.3 Electrical Considerations

The following items should be considered when setting up the switch:

CAUTION



Consideration should be given to the connection of the equipment to the supply circuit and the effect that the overloading of circuits could have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

CAUTION



Reliable grounding of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch (i.e., use of power strips).

2.4 Rack-Mounting an ASX-200, 200WG, or 200BX



This section applies only to the ASX-200, ASX-200WG, and ASX-200BX. See Section 2.5 for information about rack-mounting an ASX-1000.

The ASX-200, ASX-200WG, and ASX-200BX are designed to be installed as stand-alone units placed on the desktop or as rack-mounted units. The ASX-200 chassis can be rack-mounted without modification; however, rack-mount brackets must be attached to the ASX-200WG and ASX-200BX before they can be installed in a rack (refer to Section 2.2.1). The following items should be addressed when rack-mounting a switch:

WARNING!



When rack-mounting equipment, make sure that a hazardous condition is not created due to uneven weight distribution.

CAUTION



FORE Systems recommends that the maximum operating temperature not exceed 40°C. Consideration must be made if the switch is to be installed in a closed or multi-unit rack assembly, because the ambient temperature of the rack environment may be greater than the room ambient temperature.

CAUTION



Take care not to block the air vents of the switch, as this would compromise the amount of air flow required for proper cooling.

2.4.1 Required Tools

Rack-mounting equipment, a cable relief strain rail, and 6 Phillips-head screws are supplied with each switch for rack-mounting the unit. You will need to supply a Phillips screwdriver.

WARNING!

To prevent user injury and possible damage to equipment, FORE Systems recommends that at least two people be present when rack-mounting a switch.

2.4.2 Installing the Rack-mount Brackets



Steps 1 - 3 apply only to the ASX-200WG and ASX-200BX. If you are mounting an ASX-200, move on to Step 4.

To install the rack-mount brackets and cable relief strain rail, use the following procedure:

1. Carefully place the switch unit upside down on a clean, flat, sturdy work surface with the front of the unit still facing front.
2. Using a Phillips screwdriver, remove the four feet from the bottom of the unit.
3. Each rack-mount bracket has three screws that secure the bracket to the bottom of the unit. The holes that run along the bottom of the switch are used to secure the bracket to the bottom of the unit. Tighten the three screws to secure the left bracket, marked HWST0027-0001, to the left side of the unit. Tighten the three screws to secure the right bracket, marked HWST0027-0002, to the right side of the unit.

CAUTION

When attaching the rack-mount brackets, the use of screws other than those provided could result in damage to the unit.

4. Once the brackets are secure, choose a rack position for the switch. The switch should be placed right side up in the rack with the front of the unit facing forward.

CAUTION

When it is mounted in the equipment rack, do not use the switch chassis to support other equipment. This could overload the mounting brackets and cause damage to the unit.

5. Once the switch is mounted in the rack, you can attach the cable strain relief rail if you wish. Line up the holes in the rail with a set of holes directly above or below the switch rack-mount brackets, then secure the rail using the enclosed screws.



The switch is an operational ATM switch at this point if used with other *ForeRunner* switches or with *ForeRunner* ATM interface cards. However, if other vendor equipment is connected, you may have to complete an initial user configuration.



If you wish to have remote access to the switch, you must first install a serial cable and configure a modem. Please refer to Section 2.6 and Section 2.7 for more information.

2.5 Rack-Mounting an ASX-1000

The ASX-1000 switch is designed to be rack-mounted. The following items should be addressed when rack-mounting this switch:

WARNING!



When rack-mounting equipment, make sure that a hazardous condition is not created due to uneven weight distribution.

CAUTION



FORE Systems recommends that the maximum operating temperature not exceed 40°C. Consideration must be made if the switch is to be installed in a closed or multi-unit rack assembly, because the ambient temperature of the rack environment may be greater than the room ambient temperature.

CAUTION



Take care not to block the air vents of the switch, as this would compromise the amount of air flow required for proper cooling.

CAUTION



Ensure that any unpopulated switch board slots are covered with a blank panel before turning on your ASX-1000. Operating the switch with any of these slots left open can cause a significant temperature rise in a very short time.

2.5.1 Installing the ASX-1000

To install the ASX-1000 in the equipment rack, use the following procedure:

1. Choose a rack position for the ASX-1000.

WARNING!



Because of the unit's weight, two people should lift the unit to place it in the equipment rack.

2. Place the ASX-1000 in the rack with the front of the unit facing forward.

CAUTION



When it is mounted in the equipment rack, do not use the ASX-1000 chassis to support other equipment. This could overload the mounting brackets and cause damage to the unit.

3. After mounting the enclosure, verify that the enclosure is screwed tightly to the rack to ensure that proper grounding is maintained. Additionally, the rack should be connected to an earth ground.



The ASX-1000 is an operational ATM switch at this point if used with other *ForeRunner* switches or with *ForeRunner* ATM interface cards. However, if other vendor equipment is connected, you may have to complete an initial user configuration.



If you wish to have remote access to the switch, you must first install a serial cable and configure a modem. Please refer to Section 2.6 and Section 2.7 for more information.

2.6 Installing the Serial Cable

Connect the serial cable (supplied with the switch) from the switch's serial port to any tty-type device (such as a terminal, or the serial port of a workstation or PC running a terminal emulation program).

NOTE

The switch's serial port comes configured at 9600 baud, 8 bits, no parity and 1 stop bit.

When you turn on the switch, you should see the switch boot on the tty device connected to the switch's serial port.

NOTE

The switch is ready for user configuration as soon as it is connected to a tty-type device. To access the switch, enter `asx` at the prompt of the tty device.

2.7 Modem Configuration

All *ForeRunner* ATM switches support modem access. This may be useful if a switch is installed in a remote location where direct, physical access to the switch is not possible or practical. Keep the following in mind when using a modem to access a *ForeRunner* ATM switch:

- To allow the *ForeRunner* ATM switch to communicate with the modem, a Null-Modem Adapter must be installed on the factory-supplied serial cable.
- The *ForeRunner* ATM switch will not disconnect an ATM Management Interface (AMI) session on loss-of-carrier; therefore, you must ensure that you have completely exited from an open AMI session before disconnecting the modem session.



The following two items apply **ONLY** to a *ForeRunner* ASX-200 ATM switch.

- On an ASX-200, do not attempt to send a <BREAK> character through the modem to the ASX-200. A <BREAK> character may force an abnormal halt of the ASX-200.
- On an ASX-200, power cycling a modem while it is attached to the ASX-200 may force an abnormal halt of the switch.

To allow a modem to work with a *ForeRunner* ATM switch, you must complete two sets of configurations. First, the speed of the serial port on the *ForeRunner* ATM switch must be set to match that of the attached modem and, second, the modem parameters must be configured correctly.

2.7.1 Serial Port Configuration for an ASX-200

The ASX-200 supports three modem speeds: 1200, 2400, and 9600 baud. To match the speed of the modem you have installed, log in to AMI on the switch. Enter the following parameters to change the serial port speed:

```
configuration rs232> speed (A|B) <speed>
```

The (A|B) variable indicates the port letter of the serial port that is to be modified. On a local session on an ASX-200, the port may be A or B. The <speed> variable indicates the speed at which the serial port will run. The default is set to 9600.



Once the speed of the serial port has been altered, the speed of the attached serial device must be altered in order to access the ASX-200 through the serial port.



The ASX-200WG, ASX-200BX, and ASX-1000 only support a modem speed of 9600 baud.

2.7.2 Modem Parameters

You should use a Hayes-compatible modem, as the configuration parameters supplied here are applicable to this type of modem. The following parameters should be applied to your Hayes-compatible modem to allow it to function properly with the switch’s serial port. You may attach a tty device to the modem to set these parameters.

Setting	Comment
ATE0	Turn off Echoing
ATQ1	No Return Codes
AT&C0	Force Carrier Detect (CD) High
AT&D0	Ignore Data Terminal Ready (DTR)
AT&W	Save Modem Configuration

2.8 Configuring IP Addresses

The recommended configuration for a *ForeRunner* ATM switch is to assign an IP address to its network interfaces. This allows you to communicate with the switch from any workstation connected to your ATM LAN. IP addresses must be assigned to the network interfaces in order to perform any SNMP functions. Additionally, if you intend to connect the switch to an Ethernet, you should assign an IP address to the switch's Ethernet network interface.

To configure the IP addresses, log in to an AMI session on the switch. To modify the IP address of the SCP's IP interfaces, enter the following parameters:



On an ASX-1000, the IP address must be configured individually for each SCP.

```
configuration ip address <interface> <address>
```

The *<interface>* variable indicates the name of the IP interface to be managed. The *<address>* variable indicates the IP address for this interface.

To modify the IP subnet mask, enter the following parameters:

```
configuration ip mask <interface> <mask>
```

The *<interface>* variable indicates the name of the IP interface. The *<mask>* variable indicates the subnet mask for this IP interface.

The IP address that you assign for the switch's ATM interface must be an address within a subnet that is assigned to your ATM LAN. In general, the entire ATM LAN should be configured as a single IP subnet. Consequently, the ATM interfaces of all *ForeRunner* switches in the ATM LAN should be in the same IP subnet. Consult your systems administrator for help if you are unsure of how to do so.

2.9 AMI Security

The administrative password on your *ForeRunner* ATM switch may be changed to provide password-protected access to AMI. FORE Systems recommends that you do this to prevent unauthorized users from accessing your *ForeRunner* ATM switch. This option is available in AMI at the operation level. Be sure that you want to change the password because upon entering the command string **operation password**, the user is prompted to enter a new password immediately.

For complete information about how to assign or change the password, please refer to the *ATM Management Interface Manual*.

2.10 Subsequent Operation

After its initial configuration is complete, a *ForeRunner* switch *DOES NOT* require a terminal for normal operation.



FORE Systems strongly recommends that you disconnect the serial cable once you have configured the switch and then access the switch over the ATM network or over Ethernet.

All further communication with your *ForeRunner* switch can be performed over the ATM network or over Ethernet. For example, you can access AMI using **telnet**.

WARNING!



Once installed, before any service is performed on the unit, the power should be turned off and the power cord disconnected, except when following the hot-swap instructions in this manual.



On an ASX-200, if you leave a terminal (or modem) attached to the ASX-200 via the serial port, turning off the power to the terminal (or modem) may halt the operation of the ASX-200.



On an ASX-200, if you leave a workstation attached to the ASX-200 via the serial port, rebooting the workstation may halt the operation of the ASX-200.



On an ASX-200, do not turn the power off without first halting the ASX-200. You may halt the ASX-200 via AMI at the operation level.

2.11 Verifying the Installation

To verify that your switch is up and running, log in to AMI and open a session on the switch. Enter the following parameters at the `localhost :>` prompt to show the configuration of all of the ports on an individual switch fabric:

```
configuration port show
```

2.12 Product Registration Information

After you have successfully completed the installation process, please fill out the enclosed product registration card for your *ForeRunner* ATM switch, and return it to FORE Systems immediately.

Switch Setup

CHAPTER 3

Hardware Maintenance Procedures

This chapter discusses various hardware maintenance procedures for the *ForeRunner* ATM switches. Items discussed include the following:

- **Section 3.1** - Network Module Replacement
- **Section 3.2** - Power Supply Replacement
- **Section 3.3** - Fan Tray Replacement
- **Section 3.4** - Switch Control Processor Replacement
- **Section 3.5** - Switch Board Replacement

3.1 Network Module Replacement

3.1.1 Overview

The network modules in all *ForeRunner* ATM switches are hot-swappable, meaning that they can be removed and replaced with the unit under power. Network modules should only be hot-swapped for purposes of replacing a failed unit. Therefore, they should be replaced with a network module of the same type, the same Series, and with the same number of ports. A network module's type is the class to which the network module belongs (e.g., DS1, OC-3, E3, TAXI, etc.).

If a network module is removed and replaced by a network module of another type or by a network module with fewer ports, all configuration information for that network module's slot will be deleted, and the new network module will be configured with the defaults for its type. For example, if a 4-port Series A OC-3c is replaced by a 4-port Series C OC-3c, the Series C network module will use the same configuration of the Series A network module. Any additional configurable variables will contain OC-3c defaults. If a 4-port OC-3c is replaced by a 4-port DS1, all configuration information for that slot will be deleted and the DS1 will be initialized with DS1 defaults. If a 6-port DS1 is replaced by a 2-port DS1, all configuration information for the slot will be deleted, and the new DS1 initialized with DS1 defaults. If a network module is placed into a previously vacant slot, it will be initialized into the default state appropriate to that type of network module.

3.1.2 Multicast Mode

When hot-inserting or hot-swapping a network module, the mode in which the switch is running must also be considered. A *ForeRunner* 200 Series switch can operate in one of two multicast modes: extended mode or non-extended mode.

- Extended mode - The added features of Series C network modules give *ForeRunner* switches greater flexibility when choosing VCIs for multicast connections. This flexibility provides more successful multicast (point-to-multipoint, or PMP) connection setups. If a switch fabric is empty or if it contains only Series C or Series LC network modules, the switch will operate in extended mode.
- Non-extended mode - If a switch fabric contains at least one Series A or B network module, that switch fabric will operate in non-extended (or mixed) mode.



Series A and B network modules can not operate in the same switch fabric as Series LC network modules.



The mode in which the switch operates is determined each time the SCP restarts. If a switch is running in extended mode and a Series A or B network module is hot-inserted, the switch will not automatically revert to non-extended mode. The switch must be restarted immediately so that it operates in non-extended mode. If it is not restarted, all multicast connections fail on the Series A or B network module.

You can display the multicast mode in which your switch is operating by using the **configuration board show** command in the ATM Management Interface (AMI).



If a switch is running in non-extended mode, originating path 0 should always exist on port 1 of each Series C network module for multicast connection setups to succeed. Multicast connection information for all of the ports of Series C network modules is stored in the space allocated for port 1 and path 0 on each Series C network module.

3.1.3 Hot-swapping Network Modules

When removing or replacing network modules, use the following procedure:

WARNING!



To reduce risk to the user and to prevent damage to equipment, it is recommended that you use the included grounding strap when handling this or any other component.

NOTE



All AMI sessions should be terminated before swapping network modules of different types.

1. Label and remove all network connections from the ports on the network module.
2. Loosen the two captive fasteners on either edge of the network module using a straight screwdriver.
3. Pull firmly but carefully on the captive fasteners, removing the network module from the switch as shown in Figure 3.1.




Figure 3.1 - Removal of Network Modules

4. Insert the replacement module by sliding it into the card guides. Push firmly to seat the network module so that the faceplate is flush with the switch. Re-tighten the captive fasteners.

CAUTION



To ensure safety, tighten the captive fasteners with a straight screwdriver.

5. Restore the network connections from Step 1.

3.2 Power Supply Module Replacement

The power supplies in the ASX-200BX and the ASX-1000 are hot-swappable, meaning that they can be removed /replaced without having to shut down the switch.

WARNING!



DO NOT attempt to replace a power supply module without reading this section. Serious injury to the user or damage to the equipment may result if proper replacement procedures are not followed.

3.2.1 ASX-200BX Power Supply Module Replacement

3.2.1.1 Replacing an ASX-200BX AC Power Supply

The procedure for hot-swapping an ASX-200BX AC power supply module is as follows:

WARNING!



To reduce risk to the user and to prevent damage to the equipment, it is recommended that you use the included grounding strap when handling this or any other component.



A replacement AC power supply will not function in a DC-equipped ASX-200BX, and vice-versa. However, no damage will result if this occurs.

1. Determine which power supply is defective by either consulting *ForeView* to tell which is the bad supply, or by examining the power supplies themselves. A red LED or an extinguished LED indicates the failed supply. Power supply “1” is on the left-hand side of the unit, and power supply “2” is on the right-hand side (while facing the front of the unit).

WARNING!



Failure to perform Step 2 can result in serious injury to the user or damage to the equipment.

2. Turn OFF the power switch on the front of the defective power supply.
3. Unplug and remove the power cord from the rear of the unit that corresponds to the failed supply. When facing the front of the unit, power supply 1 (on the left) corresponds to the top power cord in the rear.
4. Unscrew the two captive fasteners on the front of the unit using a straight blade screwdriver.
5. Pull forward on the handle to remove the sliding tray.
6. Unscrew the four nuts securing the inner tray to the sliding tray.
7. Lift the inner tray from the sliding tray.
8. Place the new power supply inner tray assembly in the sliding tray and screw down the four nuts securing the inner tray.
9. Check to see that the fuses on the new unit are of the same type and rating as the fuses in the replaced power supply. The fuses should be 4A, 240V.

WARNING!



Failure to perform Step 10 can result in serious injury to the user or damage to the equipment.

10. Ensure that the power switch on the new power supply is turned OFF before inserting it into the enclosure.
11. Push the sliding tray back into the enclosure, being careful to align the card guides.
12. To ensure maximum safety, and to ensure that the connectors have seated properly, re-tighten the captive fasteners using a straight blade screwdriver.
13. Once the new supply is completely installed, re-insert and plug in the power cord, and turn the power switch to the ON position.

3.2.1.2 Replacing an ASX-200BX DC Power Supply

The procedure for hot-swapping an ASX-200BX DC power supply module is as follows:

WARNING!



To reduce risk to the user and to prevent damage to the equipment, it is recommended that you use the included grounding strap when handling this or any other component.



A replacement DC power supply will not function in an AC-equipped ASX-200BX, and vice-versa. However, no damage will result if this occurs.

1. Determine which power supply is defective by either consulting *ForeView* or by examining the power supplies themselves. A red LED or an extinguished LED indicates the failed supply. Power supply “1” is on the left-hand side of the unit, and power supply “2” is on the right-hand side (while facing the front of the unit).

WARNING!



Failure to perform Steps 2 or 3 can result in serious injury to the user or damage to the equipment.

2. Turn OFF the power switch on the front of the failed power supply. Wait for 10 seconds before moving on to Step 3.
3. Shut off DC power to the feed wires of the failed supply. Typically, each ASX-200BX resides in its own circuit on a Breaker Interface Panel (BIP). Turning off the top circuit breaker on the BIP will remove DC power to the feed wires.
4. On the rear of the unit, remove the protective plastic cover from the terminal block, exposing the DC feed wires.
5. Remove the feed wires from the terminal corresponding to the failed supply. The terminal strip on the right side (while facing the rear of the unit) corresponds with power supply 1 (on the left side while facing the front of the unit).
6. Unscrew the two captive fasteners on the front of the failed supply using a straight blade screwdriver.

7. Pull forward on the handle to remove the sliding tray.
8. Unscrew the four nuts securing the inner tray to the sliding tray, then lift the inner tray from the sliding tray.
9. Place the new power supply inner tray assembly in the sliding tray and screw down the four nuts securing the inner tray.

WARNING!

Failure to perform Step 10 can result in serious injury to the user or damage to the equipment.



10. Ensure that the power switch on the new power supply is turned OFF before inserting it into the enclosure.
11. Push the sliding tray back into the enclosure, being careful to align the card guides.
12. To ensure maximum safety, and to ensure that the connectors have seated properly, re-tighten the two captive fasteners using a straight blade screwdriver.

WARNING!

Be sure to observe polarity in the following step. Failure to observe polarity may cause permanent damage to the unit and may cause injury to the user.



13. Once completely installed, reconnect the feed wires to the terminal strip on the rear of the unit. Ensure that #16 AWG or larger wire is used for the DC feed wires. The screw terminals are #6 screws. The 48-volt feed wires should be attached to the terminal strips using wire terminals designed to fit #6 studs. FORE Systems recommends the use of either ring terminals or locking forked tongue terminals.

The higher potential wire should be connected to the positive (+) terminal, and the lower potential wire to the negative (-) terminal. A third, chassis ground wire should also be connected to the center terminal ($\perp$) and connected to an earth ground.

14. Once the feed wires have been connected, replace the protective cover on the terminal block.
15. Return DC power to the feed wires coming into the supply by turning on the top breaker on the BIP.
16. Turn the circuit breaker switch on the front of the power supply to ON (up).

3.2.2 ASX-1000 Power Supply Module Replacement

3.2.2.1 Replacing an ASX-1000 AC Power Supply (Model A)

A model A AC power supply module for an ASX-1000 is shown in Figure 3.2.




Figure 3.2 - Model A ASX-1000 AC Power Supply

The procedure for hot-swapping a model A ASX-1000 AC power supply is as follows:

WARNING!

A replacement DC power supply should never be placed in an ASX-1000 that already contains an AC power supply, and vice-versa. If these instructions are not heeded, there is a risk of electrical shock, danger to personal health, and serious damage to the equipment.

WARNING!

It is highly recommended that you use the included grounding strap when handling this or any other component.

1. Determine which power supply is defective by either consulting *ForeView* to tell which is the bad supply or by examining the power supplies themselves. A red LED or an extinguished LED indicates the failed supply. On an ASX-1000, power supply “1” is in the slot labeled PS1 on the chassis, while power supply “2” is in the slot labeled PS2 on the chassis.

WARNING!

Failure to perform Step 2 can result in serious injury to the user or damage to the equipment.

2. Turn OFF the power switch on the front of the defective power supply. Wait for the yellow SHUTDOWN LED to extinguish before moving to Step 3.
3. Unplug and remove the power cord from the failed supply.
4. Unscrew the four retaining screws with a 3/32-inch Allen wrench and pull forward on the handle located below the power cord.
5. Remove the defective supply and prepare to install the new one.

WARNING!



Failure to perform Steps 6 or 7 can result in serious injury to the user or damage to the equipment.

6. Ensure that the power switch on the new power supply is turned OFF before inserting it into the enclosure.
7. Ensure that the fuses on the new unit are rated at 12.5A, 250V.
8. Carefully align the guide rails on the new AC power supply in the slot.
9. Push on the center of the front panel of the power supply to slide it back into the enclosure.
10. To ensure maximum safety and to ensure that the connectors have been seated properly, re-tighten the four retaining screws using a 3/32-inch Allen wrench.
11. Reconnect and plug in the power cord to the new power supply.
12. Turn the power switch on the new supply to the ON position.

3.2.2.2 Replacing an ASX-1000 AC Power Supply (Model B)

A model B AC power supply module for an ASX-1000 is shown in Figure 3.3.




Figure 3.3 - Model B ASX-1000 AC Power Supply

The procedure for replacing a model B ASX-1000 AC power supply module is as follows:

WARNING!



A replacement DC power supply should never be placed in an ASX-1000 that already contains an AC power supply, and vice-versa. If these instructions are not heeded, there is a risk of electrical shock, danger to personal health, and serious damage to the equipment.

WARNING!



It is highly recommended that you use the included grounding strap when handling this or any other component.

1. Determine which power supply is defective by either consulting *ForeView* to tell which is the bad supply or by examining the power supplies themselves. An extinguished “PWR OK” LED or an illuminated “FAULT” LED indicates the failed supply. On an ASX-1000, power supply “1” is in the slot labeled PS1 on the chassis (top), while power supply “2” is in the slot labeled PS2 on the chassis (bottom).

WARNING!



Failure to perform Step 2 can result in serious injury to the user or damage to the equipment.

2. Turn OFF the power switch on the front of the defective power supply. Wait at least one (1) second after turning off the power before moving on to the next step.
3. Disconnect the AC line from the front of the defective power supply.
4. Unscrew the two captive fasteners (one on the upper, left corner of the faceplate and one on the lower, right corner of the faceplate, see Figure 3.3) using a straight blade screwdriver.
5. Pull forward on the power supply’s handle (located below the power switch and AC plug) to remove it from the chassis.
6. Set the failed supply aside and prepare to install the new one.

WARNING!



Failure to perform Steps 7 or 8 can result in serious injury to the user or damage to the equipment.

7. Ensure that the power switch on the new AC power supply is turned OFF before inserting the supply into the metal enclosure.
8. Check to see that the fuses on the new unit are rated at 15A, 250V.
9. Set the supply on the guide rails in the enclosure so that the supply is properly aligned in the slot. Position the supply so that the rear connectors are on top.
10. Once the rails are properly aligned, push on the handle on the front of the supply to slide it back into the chassis. Press firmly to ensure that the connectors on the rear of the supply have mated with those on the backplane.
11. To ensure maximum safety and to ensure that the connectors have mated properly, tighten the two captive fasteners on the front of the supply using a straight blade screwdriver.
12. Once completely installed, you may reconnect the AC line and turn the power switch to the ON position.
13. After a second or two, the PWR OK LED on each supply illuminates green, indicating that the supply is functioning properly.

3.2.2.3 Replacing an ASX-1000 DC Power Supply

The DC power supply module for an ASX-1000 is shown in Figure 3.4.




Figure 3.4 - ASX-1000 DC Power Supply

The procedure for hot-swapping an ASX-1000 DC power supply module is as follows:

WARNING!

To reduce risk to the user and to prevent damage to the equipment, it is recommended that you use the included grounding strap when handling this or any other component.

WARNING!

A replacement DC power supply should never be placed in an ASX-1000 that already contains an AC power supply, and vice-versa. If these instructions are not heeded, there is a risk of electrical shock, danger to personal health, and serious damage to the equipment.

1. Determine which power supply is defective either by consulting *ForeView* or by examining the power supplies themselves. A red LED or an extinguished LED indicates the failed supply. Power supply “1” is in the slot labeled PS1 on the chassis, and power supply “2” is in the slot labeled PS2 on the chassis.

WARNING!

Failure to perform Steps 2 or 3 can result in serious injury to the user or damage to the equipment.

2. Turn OFF (down) the circuit breaker switch on the failed power supply.
3. Shut off DC power to the feed wires of the failed supply. Typically, each ASX-1000 resides in its own circuit on a Breaker Interface Panel (BIP). Turning off the top circuit breaker on the BIP removes DC power to the feed wires.
4. Remove the protective plastic cover from the terminal block, exposing the DC feed wires.
5. Remove the feed wires from the front of the unit.
6. Unscrew the four retaining screws that secure the power supply in the chassis using a 3/32-inch Allen wrench.
7. Pull forward on the ejection / insertion handle to remove the failed supply.

WARNING!



Failure to perform Step 8 can result in serious injury to the user or damage to the equipment.

8. Ensure that the circuit breaker switch on the new power supply is turned OFF (down) before inserting it into the enclosure.
9. Carefully align the guide rails on the new DC power supply in the slot, then push on the ejection / insertion handle to slide it into the enclosure.
10. To ensure maximum safety and to ensure that the connectors have been seated properly, re-tighten the four retaining screws using a 3/32-inch Allen wrench.
11. Once completely installed, reconnect the feed wires to the terminal strip on the front of the unit. Ensure that the DC feed wires are #12 AWG or larger. The screw terminals are #6 screws. The 48-volt feed wires should be attached to the terminal strips using wire terminals designed to fit #6 studs. FORE Systems recommends the use of either ring terminals or locking forked tongue terminals.

CAUTION



Be sure to observe polarity in the following step. Failure to observe polarity may cause permanent damage to the unit and may cause injury to the user.

The higher potential wire should be connected to the positive (+) terminal, and the lower potential wire to the negative (-) terminal. A third, chassis ground wire should also be connected to the center terminal ($\perp$) and connected to an earth ground.

12. Once the feed wires have been connected, replace the protective cover on the terminal block.
13. Return DC power to the feed wires coming into the supply by turning on the top breaker on the BIP.
14. Turn the circuit breaker switch on the front of the new supply to the ON (up) position.

3.3 ASX-1000 Fan Tray Replacement

The ASX-1000 has a removable fan tray with large fans that cool the switch hardware and power supply modules. Located at the base of the upright unit, the fan tray is removable from the front of the unit and is hot-swappable, meaning that it can be replaced with the ASX-1000 under power. The procedure for replacing a fan tray is as follows:

WARNING!

It is highly recommended that you use the included grounding strap when handling this, or any other component.

1. Remove the four retaining screws at the top of the fan tray with a 3/32-inch Allen wrench.
2. Remove the fan tray by pulling it away from the switch unit.
3. Set the old fan tray aside and place the new fan tray in front of the vacant slot in the ASX-1000.
4. Insert a new fan tray in the slot and slide it all the way into the chassis. Seat the connectors by pressing firmly on the unit (this will apply power to the fan tray).
5. Once seated, replace the four screws removed in Step 1 above. This will properly secure the unit in the chassis.

CAUTION

Do not run the unit for any great length of time without the fan tray installed or the unit will shut itself down because of an overtemperature condition.

3.4 Switch Control Processor Replacement

The following procedure explains how to remove an i960 switch control processor (SCP) from a switch fabric and install a new SCP.

WARNING!



It is highly recommended that you use the included grounding strap when handling this or any other component.

CAUTION



Do not attempt to remove or replace an SCP without first removing all connections to the SCP (i.e., serial or Ethernet connections).

Only HA-based SCPs are hot-swappable. If you are replacing an earlier model SCP, you must power down the switch before starting this procedure.

1. If replacing a CF-based SCP, or earlier, turn the power switch on any installed power supplies to the OFF position; unplug and remove all power cords.
2. Loosen the captive fasteners on either edge of the SCP using a straight screwdriver.
3. Pull firmly and carefully on the two captive fasteners, removing the SCP from the switch fabric as shown in Figure 3.5.




Figure 3.5 - Removal of an SCP

4. Set the old SCP aside.

CAUTION



Take care to properly align the SCP in the card guides in the following step.

5. Insert the new SCP into the switch fabric by sliding it into the card guides.
6. Push firmly to seat the SCP so that its faceplate is flush with the front panel of the switch board.
7. Re-tighten the captive fasteners with a straight screwdriver to ensure the SCP is secure.
8. Plug any necessary power cords into the switch, then plug into an approved outlet.
9. Turn power switches on any installed power supplies to the ON position.

Once the SCP has been installed and the switch boots, the PVCs will be re-established provided that none of the network modules were replaced after the SCP was removed and provided that all of these steps have been performed properly.

3.5 Switch Board Replacement

The switch boards in the ASX-1000 are hot-swappable, meaning that they can be removed and replaced with the chassis under power. The proper procedure for hot-swapping a switch board is as follows:

WARNING!



It is highly recommended that you use the included grounding strap when handling this, or any other component.

CAUTION



Ensure that any unpopulated switch board slots are covered with a blank panel before turning on your ASX-1000. Operating the switch with any of these slots left open can cause a significant temperature rise in a very short time.



As a precaution, it is recommended that you back up your CDB before performing this process. Instructions for backing up your CDB can be found in the *ATM Management Interface Manual*.



Replace a switch board **ONLY** with another switch board of the same type (i.e., an ASX-1000 switch board with an ASX-1000 switch board).



To ensure that the switch will work with the previously established network configuration, the relative position of the network modules must not change when you transfer them to the new fabric. For example, an OC-3c network module that is removed from slot A of the old switch fabric must be installed in slot A of the new switch fabric. Therefore, it is recommended that you label all network connections and network modules before removing them.

NOTE

To maintain your CDB, the SCP must be removed before the network modules are removed and it must be installed in the new fabric after the network modules have been installed.

1. Log out of all open AMI sessions on the switch board that is to be replaced.
2. Remove the SCP from the old switch board using the instructions found in Section 3.4, Switch Control Processor Replacement. Place the SCP on a clean, static-free work area.
3. Label and remove all fibers or coaxial cables connected to the ports on the switch board that is to be replaced. Then label and remove all network modules from the old switch board using the instructions found in Section 3.1, Network Module Replacement. Place the network modules on a clean, static-free work area.
4. Unscrew the retaining screws at the top and bottom of the switch board with a 3/32-inch Allen wrench. On an ASX-1000, press the top black locking tab up towards the top and bottom black locking tab down towards the bottom of the chassis until they are parallel with the front panel of the switch.
5. Using the tabs as a handle, pull the switch board out of the chassis.

CAUTION

Make sure the replacement board is properly aligned in the slot in the next step.

6. Carefully slide the replacement board into the chassis using enough force to ensure that the connectors on the board mate with the connectors in the chassis.
7. Be sure to align the holes properly and screw the board into the chassis using the screws at the top and bottom of the board. Tighten until snug, but do not overtighten.
8. Re-install the network modules using the instructions found in Section 3.1, Network Module Replacement. Reconnect all fibers or coaxial cables to the ports.
9. Re-install the SCP using the instructions found in Section 3.4, Switch Control Processor Replacement.

Once the SCP has been installed and the system reboots, the PVCs will be re-established if all of the steps have been performed correctly and in the proper sequence.

This chapter details the steps necessary to upgrade the *ForeThought* software on your *ForeRunner* ATM switch. Some instructions in this chapter apply only when upgrading certain switches in certain situations, and you may or may not have to go through every section. Read the following list to better understand how the instructions are ordered before moving on:

- **Section 4.1** - Obtaining the Software Upgrade File
- **Section 4.2** - Requirements for Upgrading an ASX-200WG
- **Section 4.3** - Performing the Software Upgrade
- **Section 4.4** - Loading the New Software Image onto the ASX-200
- **Section 4.5** - Changing between Multiple Versions of Software
- **Section 4.6** - Booting and Upgrading with Mini Loader
- **Section 4.7** - Using bootp to Download Software to the Switch

CAUTION



As a precaution, it is recommended that you back up your CDB before beginning the upgrade process. For more information, see the *ATM Management Interface Manual*.

NOTE



Each of the SCPs on an ASX-1000 must be upgraded individually.

NOTE



The operation upgrade command can be issued one of two ways, depending on how TFTP is configured on the UNIX workstation that holds the upgrade file. For more information about using this command, see Section 4.3 and Section 4.7.4.

4.1 Obtaining the Software Upgrade File

Before beginning the upgrade process, you will need the upgrade file from FORE Systems. This file can be obtained via FTP or diskette. To obtain the file via FTP, you must have FTP access. To obtain the file from diskette, you will need the distribution diskettes from FORE Systems.

You will also need a UNIX workstation with at least 5 Mbytes of free disk space (12 Mbytes if you are upgrading an ASX-200). If you are upgrading from the distribution diskettes, the UNIX workstation must also be equipped with a floppy drive. The UNIX workstation must be connected (via ATM or Ethernet) to the SCP being upgraded.

4.1.1 Obtaining the Software Upgrade File via FTP

The software upgrade can be retrieved from FORE Systems via anonymous FTP using the following procedure. First, FTP to `ftp.fore.com`. and log in as `anonymous`. Enter your full e-mail address (e.g., `jdoe@somewhere.com`) when you are prompted for a password.



For security reasons, your password is not echoed.

Once you connect to FORE's FTP site (you will see the `ftp>` prompt), you must change to the `/priv/release/sunny` directory. This directory contains the *ForeThought* software upgrade files and the `.readme` files which contain important information about the software release.



Because the contents of this directory cannot be listed, please contact FORE Technical Support to obtain the latest list of file names. If you are upgrading an ASX-200WG, you will need both the switch software upgrade and the Mini Loader software.

The `.readme` files can be retrieved as ASCII text. However, before you retrieve the software files, you must switch the transfer mode to `binary`.

The following script is an example of how you might retrieve the software and `.readme` files. User input is shown in **bold courier** font.

```

server-jdoe:52=> ftp ftp.fore.com
Connected to ftp.fore.com.
220 ftp.fore.com FTP server (Version wu-2.4(4) Tue Apr 11 13:53:34 EDT 1995) ready.
Name (ftp.fore.com:jdoe): anonymous
331 Guest login ok, send your complete e-mail address as password.
Password: TYPE YOUR FULL E-MAIL ADDRESS HERE <ENTER>
230-
230-           WELCOME to the FORE Systems FTP Server!
230-
230- We are currently making many changes to the server to make it easier
230- for you use and search for the files that you are looking for.
230- Announcements regarding these changes will be posted here as they
230- are completed.
230-
230- If you have any problems finding the files that you are looking for,
230- you can contact FORE Systems Technical Support by phone or send email
230- to support@fore.com.
230-
230- Abuse of any FORE Systems Technical Services system is grounds for the
230- immediate removal of all access.
230-
230-
230 Guest login ok, access restrictions apply.
ftp> cd /priv/release/sunny <ENTER>
250 CWD command successful.
ftp> get asx-scp_4.1.0_1.3.readme <ENTER>
200 PORT command successful.
150 Opening ASCII mode data connection for asx-scp_4.1.0_1.3.readme (51578 bytes).
226 Transfer complete.
local: asx-scp_4.1.0_1.3.readme remote: asx-scp_4.1.0_1.3.readme
51578 bytes received in 1 seconds (50 Kbytes/s)
ftp> binary <ENTER>
200 Type set to I.
ftp> get asx-scp_4.1.0_1.3.Z <ENTER>
200 PORT command successful.
150 Opening BINARY mode data connection for asx-scp_4.1.0_1.3.Z (8147013 bytes).
226 Transfer complete.
local: asx-scp_4.1.0_1.3.Z remote: asx-scp_4.1.0_1.3.Z
8147013 bytes received in 2.3e+02 seconds (35 Kbytes/s)
ftp> quit <ENTER>
221 Goodbye.

```

If you have retrieved a software file with a .Z extension, then you need to uncompress the file using the following command:

```
uncompress <filename>
```

where *<filename>* represents the full name of the upgrade file you have retrieved. For example, using the software file from the previous example:

```
uncompress asx-scp_4.1.0_1.3.Z
```



If you have retrieved a software file with a .tar extension, do NOT untar it. The **operation upgrade** command in the ATM Management Interface (AMI) will expect the upgrade file to be in tarfile format.

If you have difficulty retrieving the files or if you have any other questions regarding the FTP site, please contact FORE Systems' Technical Support by sending e-mail to support@fore.com or by calling 800-671-FORE.

Once you have successfully retrieved the software upgrade file via FTP, follow the instructions in Section 4.3.

4.1.2 Obtaining the Software Upgrade File via Diskette

Using the FORE Systems distribution diskettes, the upgrade software must be installed on a workstation attached (via Ethernet or ATM) to the SCP being upgraded. The first disk contains a part of the distribution software, as well as a script that extracts the remaining software from the rest of the disks and builds the upgrade distribution on the workstation. The first disk can be extracted using the **tar** command:

```
tar -xvf <device>
```

where *<device>* is the block device name of the floppy drive. This disk should then be ejected from the floppy drive. On a SunOS system, the following command will eject a disk:

```
eject <device>
```

where *<device>* is the block device name of the floppy drive. On other operating systems, there may be a different command for ejecting a floppy disk or there may be a manual eject button. If there is a manual eject button, eject the disk and proceed. If there is a UNIX command for ejecting the floppy, use that command to eject the floppy and proceed.

At this point, two files should have been created: `fore_extract` and `ASX-200BX_<version>` (where `<version>` is the new software version). This file will be named `ASX-200_<version>` if you are using the distribution diskettes for an ASX-200. The `fore_extract` file is the script that will extract the files from the other floppies. If there is a command to eject a floppy on your system, set the following environment variable so the `fore_extract` script can properly eject the floppies:

```
setenv FORE_EJECT <eject_command> (for csh)
```

or

```
FORE_EJECT=<eject_command>;export FORE_EJECT (for sh)
```

On a Sun running SunOS 4.1.x, set the following environment variable so the `fore_extract` script can properly eject the floppies:

```
setenv FORE_EJECT eject
```

Execute the `fore_extract` script with the following command:

```
./fore_extract <device>
```

Once again, `<device>` is the block device name of the floppy drive. You will be asked to insert the remaining disks in sequence. If these steps are performed correctly, something similar to the following should appear on the screen:

```
filename: ASX-200BX_<version>
directory: <directory from which it was extracted>
```

The `fore_extract` script will create a file called `ASX-200BX_<version>` (or `ASX-200_<version>`, depending on the switch being upgraded) in the current directory. This is the file that the SCP will use to upgrade its software. You will need to provide this filename and path later during the upgrade process.

4.2 Requirements for Upgrading an ASX-200WG



This section applies only to an ASX-200WG upgrade. If you are upgrading an ASX-200BX or an ASX-1000, proceed to Section 4.3. If you are upgrading an ASX-200, proceed to Section 4.4.

If you are using a *ForeRunner* ASX-200WG, certain steps are required before performing the software upgrade. The FLASH on an ASX-200WG is not large enough to hold more than one copy of switch software at a time. Therefore, the following steps are necessary:

1. You should have already downloaded the software upgrade file to a UNIX workstation. If not, see Section 4.1.
2. Download the Mini Loader software to the same UNIX workstation as you did the upgrade file (see Section 4.2.1).
3. Delete everything but the current version of switch software from FLASH (see Section 4.2.2).
4. Upgrade your switch to Mini Loader (see Section 4.2.3).
5. Delete the active version of switch software from FLASH (see Section 4.2.4).
6. Perform the software upgrade (see Section 4.3).

4.2.1 Downloading the Mini Loader Software

You can obtain the Mini Loader software just as you obtained the software upgrade file, via FTP or distribution diskettes. If you are obtaining the Mini Loader software via FTP, follow the same instructions as in Section 4.1.1, but substitute the Mini Loader filename for the upgrade filename. If you are obtaining the Mini Loader software from the FORE Systems distribution diskettes, follow the same instructions as in Section 4.1.2.

4.2.2 Emptying the FLASH

Once you have obtained the software upgrade file and the Mini Loader software, you must open an AMI session and delete everything except your current version of switch software from the FLASH of the switch being upgraded.

For example, if you are running FT 4.1.0 and you still have an image for FT 3.4.3 in FLASH, you must delete the `foreos.exe` file from the `ft343.x` directory, then delete the `ft343.x` directory itself. Enter something similar to the following at the `localhost::>` prompt:

```
operation flash delete ft343.x/foreos.exe
```

```
operation flash delete ft343.x
```

If there are any other files or directories stored in FLASH, EXCEPT the active version of switch software, you should delete them according to the above conventions.

CAUTION



Make sure you do not delete the active version of switch software from FLASH until you reach Section 4.2.4.

4.2.3 Upgrading the Switch to Mini Loader

Once you have deleted any extra items from FLASH, you must upgrade the software on your switch to Mini Loader. Before initiating the upgrade, you must ensure that the Mini Loader software resides in the `/tftpbboot` directory on the UNIX workstation to which you downloaded the software. See Section 4.7.4 for instructions on how to create the `/tftpbboot` directory (if necessary) and how to move the Mini Loader software into that directory.

Once the Mini Loader software is in the `/tftpbboot` directory, enter the following parameters at the `localhost::>` prompt:

```
operation upgrade <remotehost>:<full path to remotefile>
```

In the above example, you must enter the IP address of the UNIX workstation to which you downloaded Mini Loader in place of `<remotehost>`. You must enter the Mini Loader filename in place of `<full path to remotefile>`. Enter something similar to the following at the `localhost::>` prompt:

```
operation upgrade 204.95.89.91:foreworks-loader.tar
```

The switch will initiate a TFTP session with the host workstation, and you will see something similar to the following:

```
Getting /foreworks-loader.tar from 204.95.89.91...
```

```
#####  
#####
```

If the upgrade is successful, the series of # symbols will be followed by “switch upgrade was successful.” You will then be prompted to reboot the switch

```
Reboot the switch [y]?
```

Type **n** and press **<ENTER>** at the prompt.

If the upgrade fails for some reason, try again. First, however, delete the file from FLASH called UPGRADE that will have been created (but is not complete) during the failed upgrade.

If you have problems with the upgrade to Mini Loader, please contact FORE Systems’ Technical Support.



After a successful upgrade, CURRENT points to an image for Mini Loader in FLASH. If something causes your switch to reboot, it will do so using the Mini Loader software.

4.2.4 Deleting the Active Switch Software

Now that Mini Loader is safely loaded on your switch, you can delete the active version of switch software from FLASH. Deleting this file and the directory in which it resides will not affect the operation of your switch. The switch software will continue to run in active memory after its image is deleted from FLASH. Enter something similar to the following at the local-host::> prompt:

```
operation flash delete ft400.x/foreos.exe
```

```
operation flash delete ft400.x
```

These commands will delete the image of the active version of switch software in FLASH, as well as the directory in which it is contained. The parameter `ft400.x` will vary depending on which version of switch software you are currently using.

At this point, you should upgrade your switch to *ForeThought* 4.1.x (see Section 4.3).

4.3 Performing the Software Upgrade

The software upgrade is performed with the **operation upgrade** command in AMI. The underlying file transfer mechanism used in the upgrade is TFTP. TFTP can run in “secure” or “unsecure” mode, and it is assumed that your TFTP server is running in secure mode. Therefore, if TFTP is to run properly between, the file(s) being transferred must reside in the /tftpboot directory on the source machine (see Section 4.7.4 for more information).

To perform an upgrade, the switch initiates a TFTP session with the specified host, which searches for the file requested. The host, which is running TFTP, looks for the file in /tftpboot. The TFTP process on the server automatically appends “/tftpboot” to the path or filename specified by the client.

For example, issuing **operation upgrade 169.144.3.54:asx-scp_4.1.0_1.3** will cause the TFTP server to locate and transfer the file /tftpboot/asx-scp_4.1.0_1.3. For this reason, it is imperative that you place the upgrade file in the /tftpboot directory on the workstation to which you downloaded or extracted the file. If this directory does not already exist, it is likely that TFTP is not running on the workstation. See Section 4.7.4 for instructions on setting up a TFTP server and placing the upgrade file in the /tftpboot directory.

Once you have verified your TFTP server and placed the software upgrade file, you need to invoke the upgrade process on the SCP. Log in to AMI and enter the following parameters at the localhost::> prompt:

operation upgrade ?

This will display the specific parameters that you need to enter as follows:

upgrade <remotehost>:<full path to remotefile>

In the <remotehost> field, enter the remote machine name or IP address of the workstation which holds the upgrade file. In the <full path to remotefile> field, enter ONLY the filename of the upgrade file.

NOTE

If you obtained the upgrade file via FTP, <full path to remotefile> is the name of the uncompressed file. If you obtained the file from diskette, <full path to remotefile> is the name printed during extraction.

Software Upgrade Instructions

For example, if you used FTP, you would enter something similar to the following:

operation upgrade 169.144.3.54:asx-scp_4.1.0_1.3

If you extracted the file from diskette, you would enter something similar to the following:

operation upgrade 169.144.3.54:ASX-200BX_4.1.0_1.3

In either case, you should receive messages similar to the following:

```
Received 688128 bytes in 5.3 seconds
upgrade successful
```

```
Reboot the switch[y]?
```



You have an important decision to make now. At this point, the boot pointer will have the new software's filename in it. A reboot will load the new version of software to FLASH, and the switch will be running the upgraded version when it comes up. If you wish, however, you can still run the old version of software. If you want to use the old version and change to the new version at a later time, enter **n** at the reboot prompt and follow the instructions in Section 4.5



If you are using an ASX-200WG, the above option is not valid since you can only hold one version of switch software in FLASH.

To use the new version of software that you have just loaded, type **y** and press **<ENTER>** or simply press **<ENTER>** to reboot.

```
Reboot the switch[y]? y
```

Once the SCP reboots, all active AMI sessions will be terminated on the SCP. You will need to log in to AMI again if you want to begin another session.

NOTE

If something went wrong during the upgrade process, a new file named **UPGRADE** will appear in the **FLASH** file system and you will not be prompted with the “Reboot the switch [y]?” message.

NOTE

If you are following the instructions for upgrading an **ASX-200WG** and your switch lost power for any reason during the upgrade, your switch will reboot using Mini Loader software. If this happens, see Section 4.6.

If the upgrade is unsuccessful or if you have any other problems with the upgrade, please contact FORE Systems’ Technical Support.

4.4 Loading the New Software Image onto the ASX-200

Once you have loaded the software upgrade file on your workstation, you need to invoke the upgrade process on your ASX-200. Log in to AMI and enter the following parameters at the `localhost::>` prompt:

operation upgrade ?

This will display the specific parameters that you need to enter as follows:

upgrade <remotehost>:<full path to remotefile>

Enter the remote machine name or IP address of the workstation to which you extracted the upgrade or retrieved the upgrade via FTP, and the full path name of the remote upgrade file.



If you obtained the upgrade file via FTP, *<full path to remotefile>* is the name of the uncompressed file. If you obtained the file from diskette, *<full path to remotefile>* is the path name printed during extraction.

For example, you would enter something similar to the following:

operation upgrade 169.144.3.54:asx-200_4.1.0_1.3

Enter your login ID for the workstation to which you extracted the upgrade.

remote userid: **ENTER YOUR LOGIN ID HERE <ENTER>**

Enter your password for the workstation to which you extracted the upgrade.

remote password: **ENTER YOUR PASSWORD HERE <ENTER>**



For security reasons, the switch will not echo your keystrokes when you enter your password.

After the password is entered, the switch will then download the upgrade and install it. The switch will respond with the following script which indicates that the upgrade is taking place:

```
#####

Transfer successful.
Processing the upgrade file...
Installing version 4.1.0 of the ForeThought switch control
software.
The old distribution has been saved in fore4.1.0
Extracting new software...

Installed ForeThought switch control software version 4.1.0
The system must be rebooted in order for the changes to
take effect.
```

Once the system reboots, you will be closed out of all active sessions on the switch. After pressing **<ENTER>** to reboot the system, and then typing **<ENTER>** at the prompt for the system to come up as shown below, you will need to log in to AMI again if you want to begin another session on the switch.

```
Press return in order to reboot the system:
and type return at the prompt for the system to come up.
```

If the upgrade is unsuccessful or if you have any other problems with the upgrade, please contact FORE Systems' Technical Support.

4.5 Changing between Multiple Versions of Software

It is possible to select between multiple versions of installed software at any time (not just during an upgrade procedure). You can display all the versions that are installed by typing the following:

```
localhost::operation flash> dir

FT400.35
CURRENT
FT411.25
```

However, in this list, **CURRENT** is simply a pointer to the version that will be used as the current switch software during a reboot. To display the version to which **CURRENT** is pointing, as well as all the versions that are installed, type the following:

```
localhost::operation> version
Software versions installed : FT400.35 FT410.25
Current software version is FT400.35
```

Notice that no parameter for **version** was specified above. If no parameter is specified, it will list the current and installed versions, but will not change anything.

In this example, to change the current version of software from **FT400.35** to **FT410.25**, type the following:

```
localhost::operation> version FT410.25
Current software version is FT410.25
Software versions installed : FT400.35 FT410.25
```



By using the **operation version** command and specifying a version, you change the version to which **CURRENT** is pointing.

At this point, the switch is still running FT400.35, but CURRENT is pointing to FT410.25. To make the change complete, enter the following:

```
localhost::operation> reboot
```

```
Are you sure you want to reboot this switch [n]? y
```

When the SCP reboots, it will look to see to which version CURRENT is pointing. In this case, it will see FT410.25 and boot using that version.

4.6 Booting and Upgrading with Mini Loader

NOTE

The instructions in this section are only necessary if you have deleted your active version of switch software from FLASH memory AND lost power to your switch before successfully completing a full software upgrade.

A Mini Loader session can only be accessed via the serial port of the switch. This session can be opened on a terminal connected directly to the switch, via a modem connected to the switch's serial port, through a telnet session to a workstation whose serial port is connected to the switch, etc.

If you are connecting to the switch via a terminal connected to the serial port, make sure you are using a true, “dumb” terminal or a true VT-100 terminal emulation program. If you are connecting to the switch via a modem, see Section 2.7 for more information about modem configuration. If you want to telnet to a host whose serial port is connected to the switch, one way to start a session with the switch is by using the **tip** command.

tip establishes a full-duplex terminal connection to a remote host. Once the connection is established, a remote session using **tip** behaves like an interactive session on a local terminal.

Once you telnet to the connected host, enter the following at the host prompt:

```
host# tip -9600 /dev/ttya
```

where 9600 represents the speed to which the switch's serial port has been set (see Section 2.6 and Section 2.7) and the “a” in **ttya** represents the serial port of the workstation having the connection to the serial port of the switch (this value could also be “b,” as in **ttyb**).

If you were already connected to the switch via the serial port before the switch lost power, you should see something similar to the following when Mini Loader boots the switch:

```
Switch Control Processor-16  Jan 17 1995
Copyright 1994, FORE Systems, Inc.
Copyright 1992, Intel Corporation

Adding 2072 symbols for standalone.

VxWorks version: 5.2
Kernel version: WIND version 2.4
CPU: FORE Systems WSCP
BSP version: 1.0
Creation date: Mon Apr 8 13:41:58 EDT 1996

ForeWorks Loader 1.0
Copyright (c) 1996 FORE Systems, Inc.
All Rights Reserved

Attaching network interface lo0... done.
Attaching network interface ei0... done.

loader::>
```

If you connect to the switch via the serial port after the switch has lost power, you will probably see nothing on the terminal you are using. Hit <ENTER> and you should see the loader::> prompt.

If Mini Loader does not boot automatically (i.e., you do not see the loader::> prompt within one minute), see Section B.1.1 of this manual for more information about manually booting the switch from FLASH. If you cannot get the switch to boot from FLASH, see Section 4.7 for information on using bootp.

Once the switch boots successfully, however, you will see the loader::> prompt. Before you can upgrade with Mini Loader, you must configure several parameters on the switch.

4.6.1 Setting the IP Address of the Switch

The first thing you need to do is set the IP address of the switch being upgraded. Enter the following parameters at the loader `:>` prompt:

```
configuration ip <ipaddr> [-n <netmask>] [-b <broadcast>]
```

where *<ipaddr>* is the IP address of the switch to be upgraded, *<netmask>* is the IP netmask of the subnet upon which your switch resides, and *<broadcast>* is the broadcast IP address of your network.

4.6.2 Setting the Gateway Address

If the switch you are trying to upgrade is on a different subnet than the host from which you will load the upgrade file, you must provide a proper gateway address in order for the switch to find the host. Enter the following parameters at the loader `:>` prompt:

```
configuration gateway <ipaddr>
```

where *<ipaddr>* is the IP address of the gateway leading out of the subnet on which the switch resides (see Figure 4.1).




Figure 4.1 - Example of Switch and Host on Different Subnets

4.6.3 Performing the Upgrade

Once you have set the parameters above and cleaned out the FLASH, you may perform the upgrade. Enter the following parameters at the loader :> prompt:

```
upgrade [-d <ftp | tftp>] [-bf <bootfile>] [-h <serverAddr>]
        [-u <user>] [-pw <password>]
```

The parameters in this example have the following meaning:

ftp tftp	Indicates the transfer mechanism used by Mini Loader to perform the upgrade. ftp will force Mini Loader to use FTP. tftp will force Mini Loader to use TFTP.
bootfile	Indicates the full name of the upgrade file (which should be preceded by a backslash).
serverAddr	Indicates the IP address of the UNIX workstation on which the upgrade file resides.
user	Indicates a valid username for logging on to the UNIX workstation containing the upgrade file. user is only needed if FTP is used to transfer the file.
password	Indicates a valid password for logging on to the UNIX workstation containing the upgrade file. password is only needed if FTP is used to transfer the file.

For example, you might enter something similar to the following at the loader :> prompt:

```
upgrade -d tftp -bf /S_ForeThought_4.1.0_1.29.tar -h 169.144.3.54
```

You should see something similar to the following:

```
Doing garbage collection.....
free flash space = 1461726
Transferring file foreos.exe to memory (1060339 bytes)
Transferring file version to memory (9 bytes)
Transferring file sbloader.gz to memory (6631 bytes)
Writing file foreos.exe to flash (1060339 bytes)
Creating flash directory FT410.29
Creating flash file CURRENT
```

Software Upgrade Instructions

Enter the following at the loader : :> prompt to ensure that an image of the upgrade file resides in FLASH:

flash dir

You should see something similar to the following:

```
<DIR> LD100.0  
<DIR> FT410.29  
      CURRENT
```

If the upgrade filename appears above the CURRENT pointer in FLASH, the upgrade was successful. You should now reboot the switch to begin using the new version of *ForeThought* software. Enter the following at the loader : :> prompt:

reboot

The switch will reboot using the upgraded software. If you have any problems with the upgrade, please contact FORE Systems' Technical Support.

4.7 Using bootp to Download Software to the Switch

NOTE

Section 4.7 needs to be performed only if your SCP fails to boot from FLASH.

NOTE

Booting via bootp does not upgrade the software on your switch. If you use bootp to start your switch, then you must upgrade the software image in FLASH memory according to the instructions in Section 4.3.

If your SCP fails to boot from FLASH, and no bootp server is available, the output on your terminal will look similar to the following:

```
Switch Control Processor-16 Jan 17 1995
Copyright 1994, FORE Systems, Inc.
Copyright 1992, Intel Corporation

Attempt Ethernet boot
ie_attach: ie0 ethernet address 00:20:48:20:00:19
BootP:: Waiting 68 seconds.
BootP:: Waiting 142 seconds.
BootP:: Waiting 202 seconds."BootP..." in display
BootP:: Waiting 262 seconds.
BootP:: Waiting 322 seconds.
No response to BootP

Attempt Ethernet boot
ie_attach: ie0 ethernet address 00:20:48:20:00:19
BootP:: Waiting 68 seconds.
...
```

This cycle will continue indefinitely until the switch is powered down or reset. If you see output similar to this after an upgrade, then you will need to set up a bootp server as detailed in the following sections.

4.7.1 Overview

Each SCP on a *ForeRunner* switch comes with its hardware address (Ethernet MAC address) burned in from the factory, but it does not come preconfigured with an IP address. Any time that the switch is turned on, the SCP attempts to boot from FLASH memory.

If an SCP cannot boot from its FLASH (e.g., the FLASH has recently been initialized or the switch software image in the FLASH is corrupt), it attempts to locate a bootp server on its Ethernet interface.

The SCP broadcasts its Ethernet MAC address in a bootp datagram. Bootp servers on the network that receive that broadcast look up that MAC address in their bootptab file. If they find an entry for that MAC address, they broadcast a reply to the SCP that contains a pointer to a switch software image file residing on the bootp server.

When the SCP sees the bootp reply, it initiates a TFTP session with the bootp server using the path and filename returned in the datagram from the server.

4.7.2 Setting Up a bootp Server

If the process described above is to happen, you need to provide the bootp server with the SCP's Ethernet MAC address and the path to the switch software image.

Before the bootp server will work, you must add or uncomment the following line in `/etc/inetd.conf`:

```
bootps dgram udp wait root /etc/bootpd -d4 /etc/bootptab
```

with the `bootpd` and the `bootptab` files in the `/etc` directory. Also, the following line must appear in `/etc/services`:

```
bootp          67/udp          bootps
```

Before any of the above changes can take effect, `inetd` must re-read the configuration file.



If you need to set up a TFTP server, as described in Section 4.7.4, the following process is not necessary at this time. Instead, make `inetd` re-read its configuration file after setting up your server.

Determine the process number of `inetd` by entering the following:

```
host: ps -aux | grep inetd
```

Something similar to the following will be displayed:

```
root      216  0.0  0.0  48   0 ?  IW   Jan 27  0:14 inetd
```

where 216 represents the process number of `inetd`.

Now that you know the process number, enter the following command line to make `inetd` re-read its configuration file:

```
host: kill -HUP 216
```

4.7.3 Adding a Switch Entry in the bootptab File

On the workstation that is the bootp server, add the following lines to `/etc/bootptab`:

NOTE

The lines given here are an example. See the descriptions that follow for an explanation of the values that you need to enter on your SCP.

```
myswitch:\
:ht=ether:\
:ha=002048200019:\
:sm=255.255.255.0:\
:bf=upgrade-file:\
:ip=123.123.123.123:
```

NOTE

Make sure the last line added to `bootptab` ends in a colon (:) and not a backslash (\). Otherwise, that line will merge with the next entry, causing your switch to cycle in its attempts to find a bootp server.

NOTE

If two SCPs are installed in a switch fabric, each SCP must have its own entry in the bootptab file to assign each SCP a unique IP address. Using only one entry (i.e., the same IP address) causes unpredictable Ethernet ARP behavior.

The variables in the previous example are defined as follows:

myswitch	Indicates the name you have assigned to your SCP.
ht	Indicates the hardware type. For the purposes of switch software image loading, this is ether (stands for Ethernet).
ha	Indicates the hardware address. This is the Ethernet MAC address of your SCP that is burned in from the factory. If you connect a terminal device to the SCP's serial port, you will see the Ethernet MAC address displayed during the EPROM boot sequence.
sm	Indicates the subnet mask. This is the subnet mask for your network.
bf	Indicates the bootfile. This is <i><your boot image file name></i> .
ip	Indicates the IP address of the SCP's Ethernet interface.

NOTE

For more information about bootp, please refer to RFC-1048 and RFC-951.

Once these lines are added, the bootp server will be able to tell your SCP where to find the switch software image to be downloaded. The next step in performing the upgrade is to set up a workstation as a tftpboot server and put the upgrade file (the line indicated by bf in the previous example) there.

4.7.4 Setting Up a TFTP Server

To set up a TFTP server, on a SunOS 4.1.x system, perform the following steps:

NOTE

This procedure only has to be performed the first time that the switch is turned on and each SCP is upgraded. The next time that the software is upgraded, put the upgrade file in /tftpboot.

1. In /etc/inetd.conf, uncomment the last line shown below so that the file appears as follows:

```
# Tftp service is provided primarily for booting. Most sites
# run this only on machines acting as "boot servers."
# Since these can be security holes, they are commented out by default.
#
tftp  dgram  udp    wait   root   /usr/etc/in.tftpd   in.tftpd -s /tftpboot
```

NOTE

-s /tftpboot in the line above indicates the server is running secure TFTP. If -s /tftpboot does not appear, many of the command examples in this chapter are invalid.

2. Add the following line to /etc/services:

```
tftp      69/udp
```

3. Set up the tftpboot directory with the following command lines:

```
host: mkdir /tftpboot
host: cp <upgrade-file> /tftpboot
```

4. At the root level, determine the process number of inetd by entering the following:

```
host: ps -aux | grep inetd
```

Something similar to the following will be displayed:

```
root      216  0.0  0.0  48   0 ?  IW   Jan 27  0:14 inetd
```

where 216 represents the process number of inetd.

5. Enter the following command to make inetd re-read its configuration file:

```
host: kill -HUP 216
```

Software Upgrade Instructions

The troubleshooting tests detailed in this appendix will clearly indicate and identify the most common problems in establishing ATM networks. Therefore, before calling FORE Systems' Technical Support, perform these tests to correct or at least pinpoint the problem.

If you need to call Technical Support, please have the results of these tests ready, in addition to the information requested in Section A.3, when reporting your problem.

A.1 Adapter Hardware Troubleshooting

The flowchart in Figure A.1 illustrates the tests used to check the basic hardware functionality of a FORE Systems adapter, with the adapter card isolated from the network. The tools used to perform the tests are provided by FORE Systems and the computer hardware vendor. Each of the tests, indicated by the diamond-shaped blocks in Figure A.1, is described individually in the following subsections.




Figure A.1 - Adapter Hardware Troubleshooting Flowchart

A.1.1 Run Looptest

To determine if an interface is functioning properly, run the **looptest** utility on a host that has been disconnected and isolated from the network.

NOTE

Before running **looptest**, the Receive and Transmit connectors on the backplate of the card must be connected to each other using a short loop of fiber-optic cable. This fiber should remain on throughout this test.

The **looptest** utility uses FORE Systems' ATM user-level Application Programming Interface. For proper operation, **looptest** requires read/write access to the ATM device. To run **looptest**, enter the following command at the system prompt in the working directory:

```
looptest fa0
```

where fa0 is the default device name for a single ATM adapter.

The **looptest** utility verifies that the board of an adapter is operating correctly. Correct operation means that all of the following conditions are true:

1. The self-test has been passed successfully.
2. The firmware has been downloaded successfully.
3. The driver has detected the existence of the hardware.
4. The firmware is running.
5. The physical link is up.

If **looptest** passes, then the board hardware of the adapter is OK. The next step is to test the software as shown in Figure A.3.

If **looptest** fails, the point of failure will be indicated by messages generated for each of the five items above. Refer to the following subsections for instructions about testing the individual items.

A.1.2 Check Self-Test (Automatically Performed)

During a system boot, the ATM adapter automatically performs a self-test of the hardware, running a low-level diagnostic which checks memory read / write capability. Upon completion of the self-test, a message is printed to the console of the workstation indicating whether or not the hardware failed.

If the self-test is successful, proceed to the instructions regarding the firmware download as described in the next subsection.

If the self-test fails, reseal the board by performing the following steps to ensure that failure was not due to improper insertion of the board:

1. Halt the system, being sure to follow the procedures outlined in Chapter 2 of the User's Manual for the adapter.
2. Open the computer as shown in Chapter 2 of the User's Manual for the adapter, and reseal the board.
3. Reboot the system.

If the board still fails after a reseal, then it should be returned for repair. Call FORE Systems' Technical Support for further assistance.

A.1.3 Firmware Download (Automatically Performed)

Before operating as an ATM interface, the firmware is automatically downloaded from the system RAM to the onboard i960 processor during host system boot. A message similar to "XXX-200 initializing..." is displayed on the console, indicating that the board is being initialized. When the initialization is complete, success is indicated with the message "done" and failure is indicated with the message "failed."

If the download is successful, check to see if the hardware has been detected by the driver as described in the next subsection.

If the firmware failed to download, then there is most likely a hardware problem. Call FORE Systems' Technical Support for further assistance.

A.1.4 Hardware Detected by Driver

To determine if the driver software on the host has detected the presence of an ATM adapter board, issue the following command once the host system has come up completely:

```
netstat -i
```

If the driver has located the ATM board, the screen output shows **fa0** in response to the **net-stat** command. If there is more than one adapter card, the next board will be named **fa1**, and so on. If you have configured a Classical IP interface, this will also be shown. The option **-i** shows the state of interfaces that were auto-configured, as happens when the FORE software is loaded and run upon system boot. Interfaces statically configured in a system, but not located at boot time, are not shown.

If the driver does not see the ATM board, no response will be given. Reseat the board by performing the following steps to ensure that failure was not due to improper insertion of the board:

1. Halt the system, being sure to follow the procedures outlined in Chapter 2 of the User's Manual for the adapter.
2. Open the computer as shown in Chapter 2 of the User's Manual for the adapter, and reseat the board.
3. Reboot the system.

If the board still fails after a reseat, then it should be returned for repair. Call FORE Systems' Technical Support for further assistance.

A.1.5 Check Firmware

To check whether or not the firmware is running correctly, issue the following command:

```
atmstat fa0 1
```

In this command, the last parameter "1", causes the command to be repeated at one-second intervals.

If the firmware is running correctly, the response will show Input, Output, and Error Statistics for the adapter in the following format:

PHY/ATM/AAL statistics:

Output		Input		Errors					
ATM	AAL*	ATM	AAL*	4B5B	4B5B	ATM	AAL*	AAL*	
Cells	CS-PDUs	Cells	CS-PDUs	Framing	Hdr-CRC	VPI/VCI	Pay-CRC	Proto	
161747	153692	142289	134685	0	0	20	0	0	

If the firmware is not running correctly, **atmstat** hangs and nothing is returned, indicating either a problem with the firmware, a problem with the board, or a severe software failure. Call FORE Systems' Technical Support for further assistance.

If the output shows zeros for all possible values, the firmware may not have been initialized. Try rebooting the system. If there is still a problem, call FORE Systems' Technical Support for further assistance.

A.1.6 Check Physical Link

To see the carrier state of the board, issue the following command:

```
atmstat -d fa0
```

The **-d** option displays device statistics in the following format:

```
Device statistics:
  Buffer Allocation Failures
    Type 1          Type 2
  Small   Large    Small   Large   Receive Queue Full   Carrier
    0       0        0       0      0           0           0      ON
```

If **ON** is displayed in the Carrier field, then the physical link is fine.

If the board does not see a carrier (**OFF** is displayed in the Carrier field), then there is either a problem with the loopback fiber or there is a hardware problem with the optical drivers on the board. Check the fiber. If the fiber is bad, replace the fiber and run **looptest** again. If the fiber is not bad, then call FORE Systems' Technical Support for further assistance.

Alternatively, if you have access to the back of the host and can see the LED displays on the adapter backplate, a red LED on the R (Receive port) also indicates carrier failure.

A.2 Testing Network Connectivity Using PVCs

The network connectivity tests require that two ATM adapters be connected to an ATM switch fabric with PVCs (as shown in Figure A.2). The carrier lights should be extinguished on the adapters and on the switch fabric, indicating that the fibers are OK.




Figure A.2 - Hardware Configuration for Checking PVCs

The network connectivity test suite, shown in Figure A.3, examines higher level functionality after basic adapter board performance has been verified by passing all the tests and checks shown in Figure A.1.




Figure A.3 - Networking Connectivity Using PVCs

This test sequence requires that the switch fabric be configured with a valid PVC and the endstations to have the proper IP configuration and ATM ARP cache entries. The tests in Figure A.3 assume that there is no IP connectivity between the two endstations. The lack of an IP connection is checked by trying a ping and getting no response (**ping** failed).

The tests in Figure A.3 also require that if a switch fabric is used, it is a FORE Systems switch fabric on which SPANS has been disabled on both the ports of the switch fabric and on the ATM endstations. SPANS must be disabled because it automatically creates ATM connections, which may alter the test results.

All of the failure conditions are the result of running a continuous ping with the following command:

```
ping <IP_address_of_remote_workstation>
```

A.2.1 Verifying the Outgoing ATM ARP Entry

To verify the outgoing ATM ARP cache entry for the endstation originating the ping, enter the following command on the host:

```
atmarp -a
```

The following is an example of a typical ATM ARP cache display:

```
Outgoing connections:
fa0: ws2-atm (198.29.21.74): vpi.vci=0.100 aal=5
    switch.port=-.-
    flags=(PVC) encapsulation=NULL peak rate=(unlimited)
fa0: ws3-atm (198.29.21.94): vpi.vci=0.200 aal=5
    switch.port=-.-
    flags=(PVC) encapsulation=NULL peak rate=(unlimited)
Incoming connections:
fa0: switch.port=-.- vpi.vci=0.100 aal=5 flags=(PVC) decapsulation=NULL
fa0: switch.port=-.- vpi.vci=0.200 aal=5 flags=(PVC) decapsulation=NULL
```

Make sure the ARP cache entry does indeed match the IP address of the remote endstation and is using the PVC configured on the switch fabric.

Troubleshooting

If the prompt is returned with no information displayed, this indicates that the ATM ARP cache is empty.

Use the following two commands to create a PVC on the host:

```
./atmarp -s <hostname> <device> <vpi> <vci> <aal>
```

```
./atmarp -l <device> <vpi> <vci> <aal>
```

If the ATM ARP cache entry is valid, then perform the instructions in the next subsection for **atmstat**.

A.2.2 atmstat

To determine a particular failure state, enter the following command on the remote workstation while continuously pinging:

```
atmstat fa0 1
```

PHY/ATM/AAL statistics:

Output		Input		Errors				
ATM	AAL*	ATM	AAL*	4B5B	4B5B	ATM	AAL*	AAL*
Cells	CS-PDUs	Cells	CS-PDUs	Framing	Hdr-CRC	VPI/VCI	Pay-CRC	Proto
161747	153692	142289	134685	0	0	20	0	0

The failure states are determined by examining the output from the **atmstat fa0 1** command string. The failures are classified by whether or not cells are sent (or received) and whether or not errors are received. The output shown below is typical of the first response from the **atmstat fa0 1** command string. Succeeding lines of data continue in the same column format. Refer to the following subsections for a description of each type of failure.

A.2.2.1 No Cells Received by Remote End

If no cells are received by the remote end (the Input ATM Cells field displays zero), then run the following command on the local machine to verify that cells are going out to the ATM interface:

```
atmstat fa0 1
```

If there are no cells going out (the ATM Output Cells field shows zero), then there is most likely an IP routing problem rather than an ATM problem. Please have your network administrator check the IP configuration.

If cells are going out (the ATM Output Cells field shows a value other than zero), then the PVC on the switch fabric may be configured incorrectly. Check the PVC configuration. If it is not set up properly, then correct the PVC and rerun the test. If the PVC is configured correctly and the error persists, call FORE Systems' Technical Support for further assistance.

A.2.2.2 Cells and VPI/VCI Errors Received by Remote

If the remote workstation is receiving cells and is receiving VPI/VCI errors, then this indicates that cells are coming into the workstation, but are on a VPI/VCI that may not be configured correctly.

Check the PVC configuration. If it is not set up properly, then correct the PVC and rerun the test. If the PVC is configured correctly and the error persists, then the incoming ARP entry on the remote workstation is most likely the problem. List the ATM ARP cache using **atmarp -a** and check the incoming ARP entry for that connection.

If the incoming ARP entry is not configured properly, then correct the configuration and rerun the test. If the incoming ARP entry is configured properly and the error persists, then call FORE Systems' Technical Support for further assistance.

A.2.2.3 Cells and AAL* Errors Received by Remote

If the remote workstation is receiving cells and AAL* errors, it is likely that the AAL types of the outgoing entry on the local workstation and the incoming entry on the remote workstation do not match. Check both ATM AAL types using **atmstat** to see if they match. If they are different, set the AAL parameter to the same type and rerun the test. If they match and the error persists, then call FORE Systems' Technical Support for further assistance.

A.2.2.4 Cells and No Errors Received by Remote and Transmitting No Cells

If the remote workstation is receiving cells with no errors, but is not transmitting any cells, then either the outgoing IP address on the remote end is incorrect or the IP encapsulation does not match on both ends. (A Classical IP PVC uses LLC/SNAP encapsulation while a regular PVC uses AAL5-based, Multiplexing-based (NULL) encapsulation).

First, check the outgoing IP address on the remote end using **atmarp -a**. If it is not configured properly, then correct the configuration and rerun the test. If the outgoing ARP entry is configured properly, then check to see if the IP encapsulation matches on both ends using **atmarp -a**.

If the IP encapsulation does not match on both ends, then correct the configuration and rerun the test. If the IP encapsulation matches on both ends and the error persists, then there may be an IP routing problem on the remote host.

The network administrator should verify the IP routing. If there is still a problem, then call FORE Systems' Technical Support for further assistance.

A.2.2.5 Cells and No Errors Received by Remote and Transmitting Cells

If the remote end is receiving cells with no errors and is transmitting cells in response, then the remote end is OK. Looking at Figure A.2, reverse the direction. From the remote host, start a continuous **ping** and then run these same tests starting again with Section A.2.1. Watch the results of these tests on the local host.

A.3 Collecting Additional Information

Once basic adapter installation and network connectivity have been tested, this section explains how to obtain all of the additional information that you need to have ready before calling FORE Systems Technical Support. This information should exist either on-line (by redirecting the output to a file) or in hard copy form.

A.3.1 Basic Information

The following basic network information is very useful in helping FORE Systems' Technical Support staff troubleshoot your problem:

1. Host platform configuration
 - Vendor name
 - Platform type
 - RAM (MB)
 - Disk drive size (approximate)
2. Patches installed (very important for SunOS and Solaris)
3. Network topology (physical configuration)
 - Sketch and FAX in, if possible

Please have your support contract ID number and serial number ready, also.

A.3.2 Adapter Information

On the host, at a command line, type the following six commands and note the responses:

- **uname -a** (Shows operating system, and platform names and versions)
- **ifconfig fa0** (Shows adapter interface configuration)
- **netstat -nr** (Shows routing table with destinations, gateways, and flags)
- **netstat -in** (Shows device names and addresses, and usage information)
- **adinfo fa0** (Shows adapter device name and version information)
- **atmstat -d fa0** (Shows carrier state and a variety of error counters)

Typical responses are shown under each command. The responses from these commands enable support to gather sufficient information to resolve the majority of problems.

NOTE

The assumed adapter name in the examples is fa0. On your particular system, the adapter may have a different designation. To check the name of your adapter, use the command: **netstat -in**.

uname -a

```
IRIX beluga 5.3 11091812 IP22 mips
```

ifconfig fa0

```
fa0: flags=863<UP,BROADCAST,NOTRAILERS,RUNNING,MULTICAST>
    inet 198.29.38.206 netmask 0xfffff00 broadcast 198.29.38.255
```

netstat -nr

Routing tables

Destination	Gateway	Flags	Refcnt	Use	Interface
127.0.0.1	127.0.0.1	UH	3	2264661	lo0
198.29.24.0	198.29.16.74	UG	1	9751	fa0
default	192.88.243.19	UG	3	123714	ie0
198.29.16.0	198.29.16.54	U	29	10892307	fa0
204.95.89.0	198.29.16.28	UG	0	2080	fa0
198.29.25.0	192.88.243.19	UG	0	0	ie0
198.29.26.0	192.88.243.19	UG	0	2696	ie0
198.29.27.0	192.88.243.19	UG	0	7853	ie0
198.29.19.0	198.29.16.85	UG	0	0	fa0
192.88.243.0	192.88.243.54	U	350	9188789	ie0
204.120.44.0	192.88.243.19	UG	1	1677	ie0
198.29.28.0	198.29.16.8	UG	0	87706	fa0
198.29.29.0	198.29.16.2	UG	0	0	fa0
198.29.31.0	198.29.16.75	UG	5	16417	fa0
198.29.23.0	192.88.243.53	UG	6	122731	ie0

netstat -in

Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Coll
ec0	1500	192.88.243	192.88.243.171	1173050	39926	509363	0	107115
fa0	9188	198.29.38	198.29.38.206	0	0	0	0	0
qaa0	9180	198.29.22	198.29.22.206	0	0	0	0	0
qaa1*9180	none	none	none	0	0	0	0	0
qaa2*9180	none	none	none	0	0	0	0	0
qaa3*9180	none	none	none	0	0	0	0	0
lo0	8304	127	127.0.0.1	32048	0	32048	0	0

adinfo fa0

FORE Systems Release: ForeThought_3.0.1b (1.20)

fa0: esa-200 media=4b5b-100 hw=1.0.0 fw=2.3.0 serial=2 slot=0

atmstat -d fa0

Device statistics:

Buffer Allocation Failures						
Type 1		Type 2		Receive Queue Full	Carrier	
Small	Large	Small	Large			
0	0	0	0	0	ON	

A.3.3 Switch Information

On the host, at a command line, type the following commands and note the responses:

- **atmstat fa0** command
- **netstat -ai** command
- **asxmon** command
- **cport** command

Log in to the ATM Management Interface (AMI) and open a session on the switch fabric to check the following:

- **configuration spans show**
- **configuration port show**
- **configuration uni show**
- Configuration of Network Modules (TAXI, DS3, DS1, SONET, E3, E1, and /or J2)

Typical responses are shown under each command. The responses from these commands enables support to gather sufficient information to resolve the majority of problems.

atmstat fa0

PHY/ATM/AAL statistics:

Output		Input		Errors				
ATM	AAL*	ATM	AAL*	4B5B	4B5B	ATM	AAL*	AAL*
Cells	CS-PDUs	Cells	CS-PDUs	Framing	Hdr-CRC	VPI/VCI	Pay-CRC	Proto
476058	469354	276580	273789	0	0	0	0	0

netstat -ai

Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Coll
ec0	1500	fore	gar-eth	1174803	39928	509563	0	107117
			ALL-SYSTEMS.MCAST.N					
			08:00:69:07:e3:93					
fa0	9188	198.29.38	198.29.38.206	0	0	0	0	0
			ALL-SYSTEMS.MCAST.N					
qaa0	9180	fore-sw	198.29.22.206	0	0	0	0	0
qaa1	*9180	none	none	0	0	0	0	0
lo0	8304	loopback	localhost	32072	0	32072	0	0
			ALL-SYSTEMS.MCAST.N					

asxmon <switch_name>

```
ASX-200 switch up 3:35, 17 ports (9 active), software 2.3.5, hardware 1.1
port name          uptime VPs/max VCs/max   Kb/s   free   max   total Mb
B1 198.29.22.34    2:57  1/1    5/5       0     0 140000    847
B2 198.29.22.18    3:35  1/1    3/3       0     0 140000    141
C1 198.29.22.27    3:35  1/1    4/4       0     0 140000   83035
C2 198.29.22.3     3:35  1/1    4/4       0     0 140000     11
D1 198.29.22.2     3:35  1/1    2/2       0     0 100000     11
D2 198.29.22.11    3:35  1/1    3/3       0     0 100000     11
CTL 198.29.22.37   3:35  1/1   36/36     0     0  80000    203
```



In the output above, the Kb/s and free columns do not contain valid data.

cport <switch_name>

Input				Output								
Port	Type	Mb/s	State	Time	VPs	VCs	BW	Cells	VPs	VCs	BW	Cells
B1	user	100	down	19:08:15	1	2	100	0	1	2	100	137783
B2	user	100	down	19:08:15	1	2	100	0	1	2	100	137784
B3	user	100	up	19:08:15	1	3	100	141332	1	4	100	149078
B4	user	100	down	19:08:15	1	2	100	0	1	2	100	137784
C1	user	140	up	19:08:15	1	4	140	140569	1	3	140	148928
C2	net	140	up	02:44:38	1	7	140	1046 M	1	6	140	193732
C3	net	140	up	19:08:15	1	5	140	1297 M	1	6	140	455400
C4	user	140	up	19:06:57	1	5	140	138800	1	5	140	1046 M
CTL	user	80	up	19:08:13	1	22	80	1 M	1	22	80	1 M

Troubleshooting

The following commands are run by logging in to AMI and opening a session on the switch fabric. Enter the following parameters at the prompt for the type of network modules that are installed in your switch fabric:

configuration spans show

Port	VPI	State	Type	CDVT	Action	RemoteAddress
1C1	0	down	uni	250	tag	
1C2	0	down	uni	250	tag	
1C3	0	down	uni	250	tag	
1C4	0	up	uni	250	tag	169.144.60.108
1D1	0	down	uni	250	tag	
1D2	0	down	uni	250	tag	
1D3	0	down	uni	250	tag	
1D4	0	down	uni	250	tag	
1CTL	0	up	uni	0	tag	10.10.10.48

configuration port show

Port	Carrier	Mbps	CDVT	Policing	VBROB	BuffOB	AIS/RDI	Model
2A1	no	155.0	250	enabled	100	100	disabled	OC3
2A2	no	155.0	250	enabled	100	100	disabled	OC3
2A3	no	155.0	250	enabled	100	100	disabled	OC3
2A4	no	155.0	250	enabled	100	100	disabled	OC3
2C1	no	155.0	250	enabled	100	100	disabled	OC3
2C2	no	155.0	250	enabled	100	100	disabled	OC3
2C3	no	155.0	250	enabled	100	100	disabled	OC3
2C4	no	155.0	250	enabled	100	100	disabled	OC3
2E1	no	2560.0	100	disabled	100	100	disabled	ASX-BP
2E3	no	2560.0	100	disabled	100	100	disabled	ASX-BP
2E4	no	2560.0	100	disabled	100	100	disabled	ASX-BP
2CTL	yes	80.0	5000	enabled	100	100	disabled	ASX-CTL

configuration uni show

Port	VPI	Version	State	ILMI	Side	Type	OperType	RemoteAddress
1D1	0	uni30(a)	up	up	network	auto	FT-PNNI	169.144.64.42
1D2	0	auto (a)	down	down	network	auto	privUNI	
1D3	0	uni30(a)	up	up	user	auto	FT-PNNI	169.144.64.85
1D4	0	auto (a)	down	down	network	auto	privUNI	
1D5	0	uni30(a)	up	up	user	auto	FT-PNNI	169.144.64.232
1D6	0	auto (a)	down	down	network	auto	privUNI	
1CTL	0	uni30(a)	up	down	network	auto	privUNI	

configuration port taxi show

Port	Carrier	State	Loopback
2A1	yes	up	none
2A2	no	down	none
2A3	no	down	none
2A4	no	down	none
2A5	no	down	none
2A6	no	down	none

configuration port ds3 show

Port	Carrier	Status	Mode	Framing	Loopback	Timing	Scrambling	EmptyCells	Length
1A1	yes	0x1	plcp	cbit	none	internal	off	unassigned	Gt225
1A2	yes	0x1	plcp	cbit	none	internal	off	unassigned	Gt225

configuration port ds1 show

Port	Carrier	Status	Mode	Framing	Loopback	Timing	Scrambling	Length	EmptyCells
4C1	no	0x1a0	hcs	ESF	none	internal	off	Lt110	unassigned
4C2	no	0x1a0	hcs	ESF	none	internal	off	Lt110	unassigned
4C3	no	0x1a0	hcs	ESF	none	internal	off	Lt110	unassigned
4C4	no	0x1a0	hcs	ESF	none	internal	off	Lt110	unassigned
4C5	no	0x1a0	hcs	ESF	none	internal	off	Lt110	unassigned
4C6	no	0x1a0	hcs	ESF	none	internal	off	Lt110	unassigned

configuration port cesds1 show

Port	Framing Mode	Carrier State	Line Code	Loopback State	Port Timing	Line Length	Line Status
2A1	down ESF	no	B8ZS	none	internal	<130	64
2A2	down ESF	no	B8ZS	none	internal	<130	64
2A3	down ESF	no	B8ZS	none	internal	<130	64
2A4	down ESF	no	B8ZS	none	internal	<130	64
2A5	down ESF	no	B8ZS	none	internal	<130	64
2A6	down ESF	no	B8ZS	none	internal	<130	64

configuration port sonet show

Port	Width	Line Mode	Mode	Loopback	Timing	Scrambling	EmptyCells
1C1	sts3c	MM	sonet	none	internal	on	unassigned
1C2	sts3c	MM	sonet	none	internal	on	unassigned
1C3	sts3c	MM	sonet	none	internal	on	unassigned
1C4	sts3c	MM	sonet	none	internal	on	unassigned
1D1	sts12c	MM	sonet	none	N/A	on	unassigned

configuration e1 show

Port	Carrier	Status	Mode	LineType	Loopback	Timing	LineLength	EmptyCells
1B1	no	0x262	hcs	CRC	none	internal	Lt110	idle
1B2	no	0x262	hcs	CRC	none	internal	Lt110	idle

configuration port e3 show

Port	Carrier	Status	Mode	Loopback	Timing	Scrambling	EmptyCells
1D1	no	0x58	hcs	none	internal	off	unassigned
1D2	no	0x58	hcs	none	internal	off	unassigned
1D3	no	0x58	hcs	none	internal	off	unassigned
1D4	no	0x58	hcs	none	internal	off	unassigned

configuration port j2 show

Port	LineLength	Loopback	Timing
1B1	short	none	network
1B2	short	none	network
1B3	short	none	network
1B4	short	none	network

The tests provided in this section are very specific diagnostics that are only to be run if you have determined that there is a problem with your SCP. The diagnostics for the ASX-200WG, ASX-200BX, and ASX-1000 are described first. The diagnostics for the ASX-200 begin in Section B.3.

B.1 ASX-200WG, ASX-200BX, ASX-1000 Diagnostics

If you have determined that there is a hardware problem on a switch control processor (SCP), run the SCP diagnostics that are available by connecting a terminal device to that SCP's serial port.

NOTE

These diagnostics will only test the SCP, not the switch fabric.

NOTE

All AMI sessions should be closed before these test are run.

NOTE

It is recommended that you back up your CDB before running any tests that check the FLASH and / or the SRAM. The chips are saved before testing each one and then restored. However, if a power failure would occur or if the switch were rebooted during the test, some of the data may not be restored properly.

B.1.1 Accessing the Monitor Mode

To access the Monitor mode on an i960 SCP to run these tests, perform the following steps:

1. Soft boot the SCP by pressing the RESET button on the front panel of the SCP. Because the RESET button was designed to avoid accidental resets, you will need to use a straightened paper clip to push the RESET button.
2. Press and hold the SELECT button on the front panel of the SCP. The display LED will cycle through the following parameters:

- 12:00 a.m.
- TTY Test
- DRAM 00-15 MB
- DRAM OK
- Timer T
- Clock T
- TEST BUS
- FLASH?

3. When the display LED shows FLASH?, press the NEXT button. ETHERNT? will be shown on the display LED.
4. Press the NEXT button again so that MONITOR? is shown on the display LED.
5. Press the SELECT button. The ? will disappear from MONITOR on the display LED, indicating that MONITOR has been chosen. The terminal device will indicate that user is in the SCP Debug Monitor.
6. Press the RETURN key on your terminal device's keyboard to get to the => prompt.
7. At the => prompt, type ? and press the RETURN key. The following menu will be displayed:

Available commands are:

he [cmd]	- help info for optional cmd
? [cmd]	- help info for optional cmd
ve	- print out version header
rs	- reset board, retaining baud rate
rb	- reset board and autobaud
do [offset]	- download using Xmodem
ps [address]	- single step through program, skipping procedure calls
st [address]	- single step through program
go [address]	- go from start, or continue from breakpoint

```

fr address#times - display one or more real (32 bit) floating
                    point numbers
fl address#times - display one or more long real (64 bit)
                    floating point numbers
fx address#times - display one or more extended real (80 bit)
                    floating point numbers
da address#times - disassemble one or more instructions
db address#bytes - display one or more bytes
ds address#shrts - display one or more shorts
di address#words - display one or more words
dd address#times - display one or more sets of double words
dt address#times - display one or more sets of triple words
dq address#times - display one or more sets of quad words
re                - dump contents of registers
di reg            - display the contents of the register 'reg'
mo reg            - modify a register. Reg can NOT be fp0-fp3,
mo address#words - modify one or more words in memory
mb address        - modify a byte in memory (doesn't read byte first)
fi address address data - fill memory with data value
tr option on/off - turn on or off one of the following trace options
                    branch, call, return or supervisor call
br [address]      - set instruction break. If no address is given,
                    all current breakpoints are displayed
bd [address]      - set data breakpoint. If no address is given,
                    all current breakpoints are displayed
de address        - delete specified instruction or data breakpoint
                    - repeat previous command
test-clock        - test Real Time Clock
test-dram         - test DRAM
test-dc <bank> <chip> - test DRAM chip # <chip> in bank <bank>
test-ethernet     - test Ethernet
test-flash        - test Flash
test-fc <chip>    - test Flash chip <chip>
test-serial       - test Serial Port
test-sram         - test SRAM
test-timer        - test Timer
test-all         - test all devices, except Flash and SRAM
test-manufact     - test all devices

```

B.1.2 Running the Hardware Tests

This last portion from the displayed list is the group of hardware tests that the user can run on the SCP:

test-clock	- test Real Time Clock
test-dram	- test DRAM
test-dc <bank> <chip>	- test DRAM chip # <chip> in bank <bank>
test-ethernet	- test Ethernet
test-flash	- test Flash
test-fc <chip>	- test Flash chip <chip>
test-serial	- test Serial Port
test-sram	- test SRAM
test-timer	- test Timer
test-all	- test all devices, except Flash and SRAM
test-manufact	- test all devices

Type the test command at the prompt to run the individual test. A test that completes correctly will be reported as “OK” on both the terminal connected to the serial port and on the display LED on the front panel of the SCP. A test that is not successful will be reported as “failure” on the terminal connected to the serial port and as “BAD” on the display LED. If any of the tests fail, contact FORE Systems’ Technical Support.

The following subsections depict an example of how to perform each test through the serial port and the SCP’s confirmation message to the terminal connected to the serial port that the test was successful. The user input is in **bold courier** font and the SCP’s response is shown in *courier* font.

B.1.2.1 Clock Test

This test checks the real time clock to verify that it is ticking correctly. It takes about two seconds to run.

```
=>test-clock  
Clock: OK
```

B.1.2.2 DRAM Test

This test checks the DRAM’s functionality. It takes about two seconds to run.

```
=>test-dram  
DRAM: OK
```

B.1.2.3 DRAM Chip Test

This test checks the functionality of a DRAM chip. It takes about two seconds to run.

```
=>test-dc a
DRAM chip: OK
```

B.1.2.4 Ethernet Test

This test checks the functionality of the Ethernet chip. It takes about two seconds to run.

```
=>test-ethernet
Ethernet: OK
```

B.1.2.5 FLASH Test

This test checks the functionality of each FLASH chip. It takes about five minutes to run.



It is recommended that you back up your CDB before running this test. The chips are saved before testing each one and then restored. However, if a power failure would occur or if the switch were rebooted during the test, some of the data may not be restored properly.

```
=>test-flash
Flash Test
Save Chip 0

Erase Chip
Pattern 0

Erase Chip
Pattern 1

Erase Chip
Pattern 2

Erase Chip
Pattern 3
```

```
.  
. .  
. .  
Erase Chip  
Pattern 1  
  
Erase Chip  
Pattern 2  
  
Erase Chip  
Pattern 3  
Flash: OK
```

B.1.2.6 FLASH Chip Test

This test checks the functionality of an individual FLASH chip. It takes about one and a half minutes to run.



It is recommended that you back up your CDB before running this test. The chip is saved before it is tested and then restored. However, if a power failure would occur or if the switch were rebooted during the test, some of the data may not be restored properly.

```
=>test-fc 1  
Save Chip 1  
  
Erase Chip  
Pattern 0  
  
Erase Chip  
Pattern 1  
  
Erase Chip  
Pattern 2  
  
Erase Chip  
Pattern 3  
Flash: OK
```

B.1.2.7 Serial Port Test

This test checks the serial port's functionality. It takes about two seconds to run.

```
=>test-serial
Serial: OK
```

B.1.2.8 SRAM Test

This test checks the SRAM's functionality. It takes about two seconds to run.



It is recommended that you back up your CDB before running this test. The SRAM is saved before testing and then restored. However, if a power failure would occur or if the switch were rebooted during the test, some of the data may not be restored properly.

```
=>test-sram
SRAM: OK
```

B.1.2.9 Timer Test

This test checks to see if the timer is counting correctly. It takes about two seconds to run.

```
=>test-timer
Timer: OK
```

B.1.2.10 Hardware Test

This series of tests checks the functionality of all of the hardware devices in the SCP, except the FLASH chips and SRAM. It takes about fifteen seconds to run.

```
=>test-all
Clock: OK
DRAM: OK
Ethernet: OK
Timer: OK
}Serial: OK
```

B.1.2.11 Complete Hardware Test

This series of tests checks the functionality of all of the hardware devices, in the SCP including the FLASH chips and SRAM. It takes about six minutes to run.



It is recommended that you back up your CDB before running this test. The chips are saved before testing each one and then restored. However, if a power failure would occur or if the switch were rebooted during the test, some of the data may not be restored properly.

```
=>test-manufact
Clock: OK
DRAM: OK
Ethernet: OK
Timer: OK
      }Serial: OK
SRAM: OK
Flash Test
.
.
.
Erase Chip
Pattern 1

Erase Chip
Pattern 2

Erase Chip
Pattern 3
Flash: OK
```

B.2 SCP-ASXHA Diagnostics

The diagnostics on the SCP-ASXHA SCP provide more test options than the current SCP. The new diagnostic commands are listed below:

bd [addr][mode]	- set data breakpoint. If no address is given, all current breakpoints are displayed default mode is set to ANY access
test-dl	- test DRAM in a longer, more robust test
test-sim <sim>	- test DRAM SIMM # <sim>
march-data <addr>	- test the integrity of the data bus
march-address <addr>	- test the integrity of the address bus
test-sdb	- test SDB
boot-flash	- attempt to boot from the Flash
boot-ethernet	- attempt to boot from the Ethernet
bcopy <src> <dest> <len-in-bytes>	
wbyte <addr> <data>	- write lowest byte of data to addr
wshort <addr> <data>	- write lowest short of data to addr
wint <addr> <data>	- write data to addr
sbyte <addr>	- show the value of the byte at addr
sshort <addr>	- show the value of the short at addr
sint <addr>	- show the value of the int at addr
erase-flash	- Erase entire FLASH memory
erase-fc <chip>	- Erase FLASH chip <chip>

B.3 ASX-200 Diagnostics

If you suspect a hardware problem with your ASX-200, you should run the ASX-200 switch diagnostics by logging into the ATM Management Interface (AMI) and opening a session on the switch.



Network connections should be disconnected from all ports before performing any switch diagnostics.

Enter the following parameters at the prompt to run the ASX-200 diagnostics test suite:

```
operation test <board-number>
```

The *<board-number>* variable indicates the switch fabric number. Enter 1 for the board number, since there is only 1 switch fabric. To test the ASX-200, enter the following parameters:

```
operation test 1
```

The switch will respond with the following warning to verify that you want to take this action:

```
***** WARNING *****  
Testing the switch requires physically disconnecting all  
of its ATM connections thus disrupting all traffic passing  
through this switch. The switch will also be rebooted  
after testing is completed.  
Test switch board 1 [n]?
```

By entering n or pressing the RETURN key, the switch will return with the prompt.

By entering y, this will cause a sequence of tests to run on the ASX-200. A test that completes correctly will be reported as “ok”. If any of the tests report “failed”, contact FORE Systems’ Technical Support.

```

Test switch board 1 [n]? y
Did init_symbol_table
Testing board control logic ..... ok
Testing memory bank 1 ..... ok
Testing memory bank 2 ..... ok
Testing memory bank 3 ..... ok
Testing routing ..... ok
Testing lookups 1..... ok
Testing lookups 2..... ok
Testing lookups 3..... ok
Testing lookups 4..... ok
Testing lookups 5..... ok
Testing lookups 6..... ok
Testing lookups 7..... ok
Testing lookups 8..... ok
Testing lookups 9..... ok
Testing output fifos ..... ok
Test passed.
Switch is operational, you may now reconnect attachments.
Press return to reboot the switch:

```

After the switch reboots, all open AMI sessions will be terminated by the switch.

Connection closed by foreign host.

To begin another session on the switch, log in to AMI again.

This appendix provides information about the hardware for all of FORE Systems' *ForeRunner*™ ATM switch products. Information provided includes fiber-optic and UTP cabling specifications; pinout specifications; and hardware and general operating specifications. The products described in this appendix include the following:

- *ForeRunner* ATM Switches
- *ForeRunner* ATM Network Modules

C.1 *ForeRunner* ATM Switches

FORE Systems offers a complete line of ATM switches that provide scalable ATM connectivity ranging from desktop-to-desktop connections to those spanning wide area networks. *ForeRunner* ATM switches provide high-performance, high-reliability ATM connectivity for LAN workgroup and desktop applications, LAN backbone applications, and LAN/WAN internet-working applications. Together with the *ForeRunner* series of ATM LAN and WAN network modules, these switches meet the networking demands of today's distributed, time-critical applications.

All of the *ForeRunner* ATM switches deliver high-performance switching capacity and speed for ATM applications. A non-blocking switching capacity of 2.5 Gbps is continually available on the ASX-200, the ASX-200WG, or the ASX-200BX. Each switch provides up to 4 ports of connectivity, each running at speeds up to 622 Mbps; or up to 16 ports, each running at speeds up to 155 Mbps; or up to 24 ports, each running at speeds up to 100 Mbps. The ASX-1000 provides 10 Gbps of switching capacity for up to 16 ports of connectivity, each running at speeds up to 622 Mbps; or up to 64 ports, each running at speeds up to 155 Mbps; or up to 96 ports, each running at speeds up to 100 Mbps.

This section provides an overview of the FORE Systems family of *ForeRunner* ATM switches. It details operating, environmental, and general specifications, as well as the hardware requirements necessary to use the different switches.

C.1.1 ForeRunner ASX-200

The ForeRunner ASX-200 ATM switch has the following specifications:

Features	Specification
Switching Fabric	2.5 Gbps, non-blocking
Number of Ports	2 to 24 ports
Traffic Policing	UPC, dual leaky bucket support
Switch Transit Delay	< 10 microseconds
Connection Setup Time	< 10 milliseconds, 100 calls / second
Control Processor	SPARC RISC switch control processor
Maximum Port Speed	622 Mbps (OC-12 / STM-4c)
Ethernet Interface	802.3-compatible, DB-15 female connector
Serial Interface	2 DB-25 female connectors (ports A and B)
Power (nominal)	120VAC @ 60Hz, 2.3 amps maximum (276 watts) 240VAC @ 50Hz, 1.3 amps maximum (312 watts)
Dimensions	H: 5.8" (15 cm), W: 19" (48 cm), D: 23.3" (59 cm)
Weight	40 lbs (18 kg) maximum
General Specifications	
Standards Compliance	ITU I.361 ATM Layer, ATM Forum UNI v3.0
Emissions	FCC Part 15, Class A; CISPR 22, Class A; VCCI Class 1
Safety	US: UL 1950; Canada: CSA 22.2; No. 950-M89; Europe: EN 60950
Electromagnetic Compatibility (EMC)	EN 50082-1 comprised of: ESD Susceptibility - IEC 801-2, Level 3; Radiated Susceptibility - IEC 801-3, Level 2; and Electrical Fast Transient Compatibility - IEC 801-4, Level 2
Operating Temperature	0°C to 40°C up to 5,000 ft
Operating Humidity	0 to 95% relative humidity, non-condensing

C.1.2 ForeRunner ASX-200WG

The ForeRunner ASX-200WG ATM switch has the following specifications:

Features	Specification
Switching Fabric	2.5 Gbps, non-blocking
Number of Ports	12 to 24 ports
Traffic Policing	UPC, dual leaky bucket support
Switch Transit Delay	< 10 microseconds
Connection Setup Time	< 10 milliseconds, 100 calls / second
Control Processor	i960 CA switch control processor
Maximum Port Speed	622 Mbps (OC-12 / STM-4c)
Ethernet Interface	Standard RJ-45 connector
Serial Interface	DB-9 female connector
Power (nominal)	90 - 270VAC @ 47 - 63Hz, 2.2 amps maximum (198 - 594 watts)
Dimensions	H: 4.75" (12.1 cm), W: 17.5" (44.5 cm), D: 18" (45.7 cm)
Weight	17.9 lbs (8.1 kg) maximum
General Specifications	
Standards Compliance	ITU I.361 ATM Layer, ATM Forum UNI v3.0
Emissions	FCC Part 15, Class A; CISPR 22, Class A; VCCI Class 1
Safety	US: UL 1950; Canada: CSA 22.2; No. 950-M89; Europe: EN 60950
Operating Temperature	5°C to 40°C up to 10,000 ft
Operating Humidity	10 - 90% relative humidity, non-condensing
Storage Temperature	-40°C to 70°C up to 30,000 ft
Storage Humidity	5 to 95% relative humidity, non-condensing

C.1.3 ForeRunner ASX-200BX

The ForeRunner ASX-200BX ATM switch has the following specifications:

Features	Specification
Switching Fabric	2.5 Gbps, non-blocking
Number of Ports	2 to 24 ports
Traffic Policing	UPC, dual leaky bucket support
Switch Transit Delay	< 10 microseconds
Connection Setup Time	< 8 milliseconds, 120 calls/second
Control Processor	i960 HA switch control processor
Maximum Port Speed	622 Mbps (OC-12/STM-4c)
Ethernet Interface	Standard RJ-45 connector
Serial Interface	DB-9 female connector
Power (nominal) - AC	90 - 270VAC @ 47 - 63Hz, 2.2 amps maximum (198 - 594 watts)
DC	36 - 76 VDC, 10 amps maximum
Dimensions	H: 4.75" (12.1 cm), W: 17.5" (44.5 cm), D: 18" (45.7 cm)
Weight	24.9 lbs (11.3 kg) maximum
General Specifications	
Standards Compliance	ITU I.361 ATM Layer, ATM Forum UNI v3.1
Emissions	FCC Part 15, Class A; CISPR 22, Class A; VCCI Class 1
Safety	US: UL 1950; Canada: CSA 22.2; No. 950-M89; Europe: EN 60950
Operating Temperature	5°C to 40°C up to 10,000 ft
Operating Humidity	10 - 90% relative humidity, non-condensing
Storage Temperature	-40°C to 70°C up to 30,000 ft
Storage Humidity	5 to 95% relative humidity, non-condensing

C.1.4 ForeRunner ASX-1000

The ForeRunner ASX-1000 ATM switch has the following specifications:

Features	Specification
Switching Fabric	10 Gbps, non-blocking
Number of Ports	2 to 96 ports
Traffic Policing	UPC, dual leaky bucket support
Switch Transit Delay	< 12 microseconds
Connection Setup Time	< 8 milliseconds, 120 calls/second
Control Processor	i960 HA (multiple) switch control processor
Maximum Port Speed	622 Mbps (OC-12/STM-4c)
Ethernet Interface	Standard RJ-45 connector
Serial Interface	DB-9 female connector
Power (nominal) (Model A)	97 - 264VAC @ 47 - 63Hz, 12 amps maximum 36 to 72VDC, 20 amps maximum
Power (nominal) (Model B)	100-120VAC @ 50 - 60Hz, 12 amps maximum 200-240VAC @ 50 - 60Hz, 6.5 amps maximum
Dimensions	H: 24.5" (62.2 cm), W: 19" (48.3 cm), D: 18" (45.7 cm)
Weight	AC: 89.7 lbs (41 kg); DC: 83.1 lbs (38 kg)
General Specifications	
Standards Compliance	ITU I.361 ATM Layer, ATM Forum UNI v3.1
Emissions	FCC Part 15, Class A; CISPR 22, Class A; VCCI Class 1
Safety	US: UL 1950; Canada: CSA 22.2; No. 950-M89; Europe: EN 60950
Operating Temperature	5°C to 40°C up to 10,000 ft
Operating Humidity	10 - 90% relative humidity, non-condensing
Storage Temperature	-40°C to 70°C up to 30,000 ft
Storage Humidity	5 to 95% relative humidity, non-condensing

C.2 ForeRunner ATM Network Modules

The *ForeRunner* LAN and WAN network modules are the physical ATM port interface cards that provide LAN/WAN connectivity to other ATM switches, ATM-compatible desktop computers and servers, hubs, routers, multiplexers, and carrier ATM services. Currently, network modules are available to provide ATM connections ranging from 1.5 Mbps to 622 Mbps over both fiber-optic and copper media.

This section details the technical specifications for each of the network modules. All *ForeRunner* network modules are hot-swappable, reducing network and maintenance downtime. For complete information about hot-swapping *ForeRunner* network modules, please refer to Chapter 3 in this manual.

C.2.1 100 Mbps TAXI Module

The following specifications apply to network modules NM-6/100SCC and NM-6/100STC:

Description	Specification
Port Capacity	Six TAXI ports per module
Data Rate	100 Mbps
Output Buffer	13,312 cell capacity
Media	Multimode fiber
Max. Line Length	~2 km
Connectors	ST or dual SC
Line Encoding	4B/5B
Loopbacks	Transmit and receive loopbacks
Power	-14 to -20 dBm transmit, -14 to -30 dBm receive, 0 to 10 dB path attenuation
Core Diameter	62.5 μm
Fiber Diameter	125 μm
Wavelength	1310 nm
Statistics	TAXI statistics including Header Check Sequence (HCS) errors
Compliance	ATM Forum TAXI UNI v3.1, ITU-T I.432, ANSI X3T9.5, ISO DIS9314-3

C.2.2 155 Mbps OC-3c/STM-1 MM Module

The following specifications apply to network modules NM-4/155MMSCC and NM-4/155MMSTC:

Description	Specification
Port Capacity	Four SONET/SDH ports per module
Data Rate	155.52 Mbps
Output Buffer	32,768 cell capacity
Media	Multimode fiber
Max. Line Length	~2 km
Connectors	ST or dual SC
Line Encoding	Non-Return to Zero (NRZ)
Framing	STS-3c/STM-1
Clock Accuracy	±20 ppm
Timing	Internal timing or per port network timing
Loopbacks	Transmit and receive loopbacks
Power	-14 to -20 dBm transmit, -14 to -30 dBm receive, 0 to 10 dB path attenuation
Core Diameter	62.5 μm
Fiber Diameter	125 μm
Wavelength	1310 nm
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity errors (Line BIP-24, Section BIP-8, Path BIP-8), Header Check Sequence (HCS) errors
Compliance	ATM Forum STS-3c UNI v3.1, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ITU-T G.957, Bellcore TR-NWT-000253

C.2.3 155 Mbps STS-3c/STM-1 UTP Module

The following specifications apply to network modules NM-4/155UTP5EC and NM-4/155UTP5C:

Description	Specification
Port Capacity	Four SONET/SDH ports per module
Data Rate	155.52 Mbps
Output Buffer	2,560 or 32,768 cell capacity
Media	Category 5 Unshielded Twisted Pair (UTP)
Max. Line Length	100 m
Connectors	RJ-45
Line Encoding	Non-Return to Zero (NRZ)
Framing	STS-3c/STM-1
Clock Accuracy	±20 ppm
Timing	Internal timing or per port network timing
Loopbacks	Transmit and receive loopbacks
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity errors (Line BIP-24, Section BIP-8, Path BIP-8), Header Check Sequence (HCS) errors
Compliance	ATM Forum STS-3c UNI v3.1, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ATM Forum AF-PHY-0015.000

C.2.3.1 155 Mbps UTP Pinout Specifications


155 Mbps UTP network modules have a standard RJ-45 female connector and use RJ-45 network equipment pinouts as illustrated in the table below:

Pin Number	Signal Mnemonic	Signal Name
1	RX+	Receive Data +
2	RX-	Receive Data -
3		Not Used
4		Not Used
5		Not Used
6		Not Used
7	TX+	Transmit Data +
8	TX-	Transmit Data -

C.2.3.2 Connecting Switches with 155 Mbps UTP Network Modules

When connecting switches using 155 Mbps UTP network modules, you need to use a category 5 UTP crossover cable with the following specifications:

- Pin 1 to pin 7 in both directions.
- Pin 2 to pin 8 in both directions.



C.2.4 622 Mbps OC-12c/STM-4c MM Module

The following specifications apply to network module NM-1 / 622MMSCC:

Description	Specification
Port Capacity	One SONET/SDH port per module
Data Rate	622.08 Mbps
Output Buffer	65,536 cell capacity
Media	Multimode fiber
Max. Line Length	300 m
Connectors	SC
Line encoding	Non-Return to Zero (NRZ)
Framing	STS-12c / STM-4c
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Power	-20 to -14 dBm transmit power, -26 to -14 dBm receive sensitivity, 0 to 6 dB path attenuation for 62.5 μm fiber, 0 to 2 dB path attenuation for 50 μm fiber
Core Diameter	62.5 μm, 50 μm
Fiber Diameter	125 μm
Wavelength	1270 - 1380 nm
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity (Line BIP-24, Section BIP-8, Path BIP-8) errors, Header Check Sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells)
Compliance	ATM Forum AF-PHY-0046.000, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ITU-T G.957, Bellcore TR-NWT-000253

C.2.5 1.5 Mbps DS1 Module

The following specifications apply to network modules NM-2/DS1C and NM-6/DS1C:

Description	Specification
Port Capacity	Two or six DS1 ports per module
Data Rate	1.544 Mbps
Output Buffer	13,312 cell capacity
Media	Unshielded Twisted Pair (UTP)
Max. Line Length	~655 ft
Connector	RJ-45
Line Encoding	B8ZS
Framing	ESF, optionally PLCP
Clock Accuracy	±32 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Impedance	100 ohms nominal
Statistics/Alarms	Line Code Violations (LCV), framing bit errors(FER), CRC-6 Bit Error Events (BEE), Out Of Frame events (OOF), Header Check Sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), signal/clock detection, and AIS indication
Compliance	ATM Forum AF-PHY-0016.000, ANSI/Bellcore T1.102, T1.107, T1.408, TR-TSY-000009, ITU-T G.703, G.704, G.804

C.2.6 1.5 Mbps DS1 Circuit Emulation Services Module

The following specifications apply to network module NMCE-6/DS1A:

Description	Specification
Port Capacity	Six DS1 CES ports per module
Data Rate	1.544 Mbps
Output Buffer	13,312 cell capacity
Max. Connections	127
Media	Unshielded Twisted Pair (UTP)
Max. Line Length	~655 ft
Connector	RJ-48c
Line Encoding	B8ZS or AMI (user-configurable)
Framing	ESF or SF (user-configurable)
Clock Accuracy	±32 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Impedance	100 ohms nominal
Statistics/Alarms	Line Code Violations (LCV), framing bit errors(FER), CRC-6 Bit Error Events (BEE), Out Of Frame events (OOF), Header Check Sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), signal/clock detection, and AIS indication
Compliance	ATM Forum 94-0033R8, ANSI/Bellcore T1.102, T1.107, T1.408, TR-TSY-000009, ITU-T G.703, G.704, G.804

C.2.6.1 DS1 Pinout Specifications

DS1 network modules have a standard RJ-45 female connector that uses RJ-48C CPE pinouts as illustrated in the table below:

Pin Number	Signal Mnemonic	Signal Name
1	RX+	Receive Data +
2	RX-	Receive Data -
3		Not Used
4	TX+	Transmit Data +
5	TX-	Transmit Data -
6		Not Used
7		Not Used
8		Not Used

C.2.7 2 Mbps E1 Module

The following specifications apply to network modules NM-2/E1C and NM-6/E1C:

Description	Specification
Port Capacity	Two or six E1 ports per module
Data Rate	2.048 Mbps
Output Buffer	13,312 cell capacity
Media	Unshielded Twisted Pair (UTP)
Max. Line Length	~655 ft
Connector	RJ-48c
Line Encoding	HDB3
Framing	CRC-4 Multiframe
Clock Accuracy	±32 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Impedance	120 ohms nominal
Statistics/Alarms	Line Code Violations (LCV), framing bit errors (FER), Far End Block Errors (FEBE), CRC error events, Header Check Sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), signal/clock detection, and AIS indication
Compliance	ATM Forum AF-PHY-94-0422 R5, ITU-T G.703, G.704, G.804, I.432

C.2.7.1 E1 Pinout Specifications

E1 network modules have a standard RJ-45 female connector that uses RJ-48C CPE pinouts as illustrated in the table below:

Pin Number	Signal Mnemonic	Signal Name
1	RX+	Receive Data +
2	RX-	Receive Data -
3		Not Used
4	TX+	Transmit Data +
5	TX-	Transmit Data -
6		Not Used
7		Not Used
8		Not Used

C.2.8 6 Mbps J2 Module

The following specifications apply to network module NM-4/J2C:

Description	Specification
Port Capacity	Four J2 ports per module
Data Rate	6.312 Mbps
Output Buffer	13,312 cell capacity
Media	Coaxial
Max. Line Length	~1300 ft
Connector	BNC
Line Encoding	B8ZS
Framing	Per ITU-T G.704
Clock Accuracy	±30 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Impedance	75 ohms nominal
Statistics/Alarms	Line Code Violations (LCV), framing bit errors (FER), CRC error events, Header Check Sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), signal/clock detection, and AIS indication
Compliance	ATM Forum AF-PHY-0029.000, NTT Technical Reference of Cell Relay Interface v1, ITU-T G.703, G.704, G.804

C.2.9 25 Mbps TP25 Module


The following specifications apply to network module NM-6/25UTPEC:

Description	Specification
Port Capacity	Six TP25 ports per module
Data Rate	25.6 Mbps
Output Buffer	2,560 cell capacity
Media	Cat. 3, 4, or 5 Unshielded Twisted Pair (UTP)
Max. Line Length	100 m
Connector	RJ-45
Line Encoding	4B/5B with NRZI
Clock Accuracy	±100 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Receive loopback
Impedance	100 ohms
Statistics/Alarms	Header Check Sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), and symbol errors
Compliance	ATM Forum 25.6 Mbps specification AF-PHY-0040.000

C.2.9.1 Connecting Switches with TP25 Network Modules

The TP25 network modules have a standard RJ45 connector that uses pins 1, 2, 7 and 8. When connecting switches using TP25 network modules, you will need to use a UTP crossover cable with the following specification:


- Pin 1 to pin 7 in both directions.
- Pin 2 to pin 8 in both directions.



C.2.9.2 Connecting Switches with Token Ring Pinouts to *ForeRunner* Switches

Although FORE Systems' Switches use the 1, 2, 7 and 8 pin assignment recommended by the ATM Forum, some switches use pins 3, 4, 5 and 6. Connecting one of these switches to a *ForeRunner* Switch would require the connections to be mapped as follows:

- Pin 3 to pin 7 in both directions.
- Pin 4 to pin 1 in both directions.
- Pin 5 to pin 2 in both directions.
- Pin 6 to pin 8 in both directions.



C.2.9.3 Connecting Adapters with Token Ring Pinouts to *ForeRunner* Switches

Like switches, some adapters use different pin assignments than those mentioned before. Connecting one of these adapters to a *ForeRunner* Switch would require the connections to be mapped as follows:

- Pin 3 to pin 1 in both directions.
- Pin 4 to pin 7 in both directions.
- Pin 5 to pin 8 in both directions.
- Pin 6 to pin 2 in both directions.

Alternative adapter	Pin	Pin	<i>ForeRunner</i> Switch
	1	1	RX+
	2	2	RX-
TX+	3	3	
RX+	4	4	
RX-	5	5	
TX-	6	6	
	7	7	TX+
	8	8	TX-



The cable used in the connections shown in Section C.2.9.2 and Section C.2.9.3 must be either a UTP-3 or UTP-5 bidirectional crossover cable, with 8-pin male RJ-45 modular connectors at each end.

C.2.10 34 Mbps E3 Module

The following specifications apply to network modules NM-2/E3C and NM-4/E3C:

Description	Specification
Port Capacity	Two or four E3 ports per module
Data Rate	34.368 Mbps
Output Buffer	13,312 cell capacity
Media	Coaxial
Max. Line Length	~450 ft
Connector	BNC
Line Encoding	HDB3
Framing	Per ITU-T G.832 or G.751
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Impedance	75 ohms nominal
Statistics/Alarms	Line code violations (LCV), framing bit errors (FER), P-bit and C-bit errors, header check sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), signal/clock detection, code violations, bit errors, parity errors, and AIS indication
Compliance	ATM Forum AF-PHY-94-0406 R5, ITU-T G.703, G.751, G.832, G.804

C.2.11 45 Mbps DS3 Module

The following specifications apply to network modules NM-2/DS3C and NM-4/DS3C:

Description	Specification
Port Capacity	Two or four DS3 ports per module
Data Rate	44.736 Mbps
Output Buffer	13,312 cell capacity
Media	Coaxial
Max. Line Length	~450 ft
Connector	BNC
Line Encoding	B3ZS
Framing	C-bit parity or clear channel, optionally PLCP
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Impedance	75 ohms nominal
Statistics/Alarms	Line code violations (LCV), framing bit errors (FER), P-bit and C-bit errors, header check sequence (HCS) errors, cells received (RxCells), cells transmitted (TxCells), signal/clock detection, and AIS indication
Compliance	ATM Forum DS3 UNI v3.1, ANSI/Bellcore T1.102, T1.107, TR-TSY-000009

C.2.12 155 Mbps OC-3c/STM-1 SM Module

The following specifications apply to network modules NM-4/155SMSRC and NM-4/155SMLRC:

Description	Specification
Port Capacity	Four SONET/SDH ports per module
Data Rate	155.52 Mbps
Output Buffer	32,768 cell capacity
Media	Short or long reach single mode fiber
Max. Line Length	~2 km (short reach); ~40 km (long reach)
Connectors	FC
Line Encoding	Non-Return to Zero (NRZ)
Framing	STS-3c/STM-1
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Power - Short Reach	-8 to -15 dBm transmit power, -8 to -23 dBm receive sensitivity, 0 to 8 dB path attenuation
Power - Long Reach	0 to -5 dBm transmit power, -10 to -34 dBm receive sensitivity, 10 to 29 dB path attenuation
Core Diameter	10 µm
Fiber Diameter	125 µm
Wavelength	1310 nm
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity errors (Line BIP-24, Section BIP-8, Path BIP-8), Header Check Sequence errors (HCS)
Compliance	ATM Forum STS-3c UNI v3.1, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ITU-T G.957, Bellcore TR-NWT-000253

C.2.13 155 Mbps OC-3c/STM-1 3MM/1SM Module

The 155 Mbps OC-3c/STM-1 3MM/1SM network module contains one SONET/SDH single mode port (port 4) and three SONET/SDH multimode ports (ports 1, 2, and 3) per module.

The following specifications apply to port 4 on network modules NM-4/155SR3SCC and NM-4/155LR3SCC:

Description	Specification
Data Rate	155.52 Mbps
Output Buffer	32,768 cell capacity
Media	Short or long reach single mode fiber
Max. Line Length	~2 km (short reach); ~40km (long reach)
Connectors	FC
Line Encoding	Non-Return to Zero (NRZ)
Framing	STS-3c/STM-1
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Power - Short Reach	-8 to -15 dBm transmit power, -8 to -23 dBm receive sensitivity, 0 to 8 dB path attenuation
Power - Long Reach	0 to -5 dBm transmit power, -10 to -34 dBm receive sensitivity, 10 to 29 dBm path attenuation
Core Diameter	10 μm
Fiber Diameter	125 μm
Wavelength	1310 nm
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity errors (Line BIP-24, Section BIP-8, Path BIP-8), Header Check Sequence errors (HCS)
Compliance	ATM Forum STS-3c UNI v3.1, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ITU-T G.957, Bellcore TR-NWT-000253

Hardware Specifications

The following specifications apply to ports 1, 2, and 3 on network modules NM-4/155SR3SCC and NM-4/155LR3SCC:

Description	Specification
Data Rate	155.52 Mbps
Output Buffer	32,768 cell capacity
Media	Multimode fiber
Max. Line Length	~2 km
Connectors	SC
Line Encoding	Non-Return to Zero (NRZ)
Framing	STS-3c/STM-1
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Power	-14 to -20 dBm transmit power, -14 to -30 dBm receive sensitivity, 0 to 10 dB path attenuation
Core Diameter	62.5 μm
Fiber Diameter	125 μm
Wavelength	1310 nm
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity errors (Line BIP-24, Section BIP-8, Path BIP-8), Header Check Sequence errors (HCS)
Compliance	ATM Forum STS-3c UNI v3.1, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ITU-T G.957, Bellcore TR-NWT-000253

C.2.14 622 Mbps OC-12c/STM-4c SM Module

The following specifications apply to network module NM-1 / 622SMIRC:

Description	Specification
Port Capacity	One SONET/SDH port per module
Data Rate	622.08 Mbps
Output Buffer	65,536 cell capacity
Media	Single mode fiber
Max. Line Length	~14 km
Connectors	FC
Line Encoding	Non-Return to Zero (NRZ)
Framing	STS-12c / STM-4c
Clock Accuracy	±20 ppm
Timing	Primary and secondary 8kHz reference from internal (default) or network
Loopbacks	Transmit and receive loopbacks
Power	-8 to -15 dBm transmit power, -8 to -28 dBm receive sensitivity, 0 to 13 dB path attenuation
Core Diameter	10 μm
Fiber Diameter	125 μm
Wavelength	1310 nm
Statistics/Alarms	SONET/SDH statistics include Loss of Signal (LOS), Loss of Frame (LOF), Loss of Pointer (LOP), Far End Block Errors (FEBE), Alarm Indication Signal (AIS), Far End Receive Failure (FERF), Yellow Alarm, Bit Interleaved Parity errors (Line BIP-24, Section BIP-8, Path BIP-8), Header Check Sequence errors (HCS), cells received (RxCells), cells transmitted (TxCells)
Compliance	ATM Forum STS-12c UNI v3.1, ITU-T I.432, ANSI T1E1.2/93-020, T1S1/92-185, ITU-T G.957, Bellcore TR-NWT-000253

Acronyms

The networking terms in the following list are defined in the Glossary of this manual. Glossary items are listed alphabetically according to the full term.

AAL	ATM Adaptation Layer
ABR	Available Bit Rate
ACM	Address Complete Message
ACR	Allowable Cell Rate
ADPCM	Adaptive Differential Pulse Code Modulation
AHFG	ATM-attached Host Functional Group
AIMUX	ATM Inverse Multiplexing
AIS	Alarm Indication Signal
AMI	Alternate Mark Inversion
AMI	ATM Management Interface
ANSI	American National Standards Institute
APCM	Adaptive Pulse Code Modulation
API	Application Program Interface
APP	Application Program
APS	Automatic Protection Switching
ARP	Address Resolution Protocol
ASCII	American Standard Code for Information Interchange
ATDM	Asynchronous Time Division Multiplexing
ATM	Asynchronous Transfer Mode
AUI	Attachment User Interface
B8ZS	Bipolar 8 Zero Substitution
BCOB	Broadband Connection Oriented Bearer
BCOB-A	Bearer Class A
BCOB-C	Bearer Class C
BCOB-X	Bearer Class X
BECN	Backward Explicit Congestion Notification
BER	Bit Error Rate
BES	Bursty Errored Seconds
BGP	Border Gateway Protocol
B-ICI	B-ISDN Inter-Carrier Interface.
BIP	Bit Interleaved Parity
B-ISDN	Broadband Integrated Services Digital Network
B-ISUP	Broadband ISDN User's Part

BITS	Building Integrated Timing Supply
BNC	Bayonet-Neill-Concelman
BPDU	Bridge Protocol Data Unit
bps	Bits per Second
BPV	Bipolar Violation
B-TE	Broadband Terminal Equipment
BUS	Broadcast and Unknown Server
CAC	Connection Admission Control
CAS	Channel Associated Signaling
CBDS	Connectionless Broadband Data Service
CBR	Constant Bit Rate
CCITT	International Telephone and Telegraph Consultative Committee
CCS	Common Channel Signaling
CDV	Cell Delay Variation
CE	Connection Endpoint
CEI	Connection Endpoint Identifier
CES	Circuit Emulation Service
CGA	Carrier Group Alarm
CIP	Carrier Identification Parameter
CIR	Committed Information Rate
CLIP	Classical IP
CLP	Cell Loss Priority
CLR	Cell Loss Ratio-1-15
CLS	Connectionless service
CMIP	Common Management Interface Protocol
CMR	Cell Misinsertion Rate
CPE	Customer Premise Equipment
CRA	Cell Rate Adaptation
CRC	Cyclic Redundancy Check
CRS	Cell Relay Service
CS	Controlled Slip, or Convergence Sublayer
CSU	Channel Service Unit
CTD	Cell Transfer Delay
CTS	Clear To Send
DACS	Digital Access and Cross-Connect System
DARPA	Defense Advanced Research Projects Agency
DCC	Data Country Code
DCE	Data Communications Equipment
DCS	Digital Cross-connect System
DES	Destination End Station
DFA	DXI Frame Address
DLCI	Data Link Connection Identifier

DNS	Domain Naming System
DSn	Digital Standard n (n=0, 1, 1C, 2, and 3)
DSR	Data Set Ready
DTE	Data Terminal Equipment
DTR	Data Terminal Ready
EEPROM	Electrically Erasable Programmable Read Only Memory
EFCI	Explicit Forward Congestion Indication
EGP	Exterior Gateway Protocol
EIA	Electronics Industries Association
EISA	Extended Industry Standard Architecture
ELAN	Emulated Local Area Network
EMI	Electromagnetic Interference
EPROM	Erasable Programmable Read Only Memory
EQL	Equalization
ER	Explicit Rate
ES	End System, or Errored Second
ESF	Extended Super Frame
ESI	End System Identifier
EXZ	Excessive Zeroes (Error Event)
FC	Face Contact
FCC	Federal Communications Commission
FCS	Frame Check Sequence
FDDI	Fiber Distributed Data Interface
FDM	Frequency Division Multiplexing
FEBE	Far End Block Error
FEC	Forward Error Correction
FECN	Forward Explicit Congestion Notification
FERF	Far End Receive Failure
FIFO	First-In, First-Out
FRS	Frame-Relay Service
FTP	File Transfer Protocol
FT-PNNI	ForeThought PNNI
FUNI	Frame-Based UNI
GCAC	Generic Connection Admission Control
GCRA	Generic Cell Rate Algorithm
GFC	Generic Flow Control
HDB3	High Density Bipolar
HDLC	High Level Data Link Control
HEC	Header Error Control
HIPPI	High Performance Parallel Interface
HSSI	High-Speed Serial Interface
ICMP	Internet Control Message Protocol

IDU	Interface Data Unit
IEEE	Institute of Electrical and Electronics Engineers
IETF	Internet Engineering Task Force
ILMI	Interim Local Management Interface
IP	Internet Protocol
IPX	Internetwork Packet Exchange
IS	Intermediate system
ISDN	Integrated Services Digital Network
ISO	International Standards Organization
ITU-T	International Telecommunication Union Telecommunication
IWF	Interworking Function
IXC	Interexchange Carriers
JPEG	Joint Photographic Experts Group
Kbps	Kilobits per second
LAN	Local Area Network
LANE	LAN Emulation
LAPB	Link Access Procedure, Balanced
LATA	Local Access and Transport Area
LBO	Line Build Out
LCV	Line Code Violations
LE_ARP	LAN Emulation Address Resolution Protocol
LEC	LAN Emulation Client
LECS	LAN Emulation Configuration Server
LES	LAN Emulation Server
LLC	Logical Link Control
LOF	Loss Of Frame
LOP	Loss Of Pointer
LOS	Loss Of Signal
LSB	Least Significant Bit
MAC	Media Access Control
MAN	Metropolitan Area Network
MAU	Media Attachment Unit
MBS	Maximum Burst Size
MCDV	Maximum Cell Delay Variance
MCLR	Maximum Cell Loss Ratio
MCR	Minimum Cell Rate
MCTD	Maximum Cell Transfer Delay
MIB	Management Information Base
MIC	Media Interface Connector
MID	Message Identifier
MMF	Multimode Fiber Optic Cable
MPEG	Motion Picture Experts Group
MPOA	Multiprotocol over ATM

MSB	Most Significant Bit
MTU	Maximum Transmission Unit
NM	Network Management Entity
NML	Network Management Layer
NMS	Network Management Station
NNI	Network-to-Network Interface or Network Node Interface
NPC	Network Parameter Control
NRZ	Non Return to Zero
NRZI	Non Return to Zero Inverted
NSAP	Network Service Access Point
NTSC	National TV Standards Committee
OAM	Operation and Maintenance Cell
OC-n	Optical Carrier level-n
OID	Object Identifier
OOF	Out-of-Frame
OSI	Open Systems Interconnection
OSPF	Open Shortest Path First Protocol
OUI	Organizationally Unique Identifier
PAD	Packet Assembler Disassembler
PAL	Phase Alternate Line
PBX	Private Branch Exchange
PCI	Peripheral Component Interconnect
PCM	Pulse Code Modulation
PCR	Peak Cell Rate
PDN	Public Data Network
PDU	Protocol Data Unit
PHY	Physical Layer
ping	Packet Internet Groper
PLCP	Physical Layer Convergence Protocol
PLP	Packet Level Protocol
PM	Physical Medium
PMD	Physical Medium Dependent
PNNI	Private Network Node Interface or Private Network-to-Network Interface
PPP	Point-to-Point Protocol
PROM	Programmable Read-Only Memory
PRS	Primary Reference Source
PSN	Packet Switched Network
PT	Payload Type
PVC	Permanent Virtual Circuit (or Channel)
PVCC	Permanent Virtual Channel Connection
PVPC	Permanent Virtual Path Connection
QD	Queuing Delay
QoS	Quality of Service

RD	Routing Domain
RFCs	Requests For Comment
RFI	Radio Frequency Interference
RIP	Routing Information Protocol
RISC	Reduced Instruction Set Computer
RTS	Request To Send
SA	Source Address
SA	Source MAC Address
SAP	Service Access Point
SAR	Segmentation And Reassembly
SC	Structured Cabling, or Structured Connectors, or Stick and Click
SCR	Sustainable Cell Rate
SCSI	Small Computer Systems Interface
SDLC	Synchronous Data Link Control
SDU	Service Data Unit
SEAL	Simple and Efficient Adaptation Layer
SECAM	Système En Couleur Avec Mémoire
SEL	Selector
SES	Severely Errored Seconds
SF	Super Frame
SGMP	Simple Gateway Management Protocol
SIR	Sustained Information Rate
SLIP	Serial Line IP
SMDS	Switched Multimegabit Data Service
SMF	Single Mode Fiber
SMTP	Simple Mail Transfer Protocol
SNA	Systems Network Architecture
SNAP	SubNetwork Access Protocol
SNI	Subscriber Network Interface
SNMP	Simple Network Management Protocol
SONET	Synchronous Optical Network
SPANS	Simple Protocol for ATM Network Signalling
SPARC	Scalable Processor Architecture Reduced instruction set Computer
SPE	Synchronous Payload Envelope
SPVC	Smart PVC
SS7	Signaling System No. 7
SSCOP	Service Specific Connection Oriented Protocol
SSCS	Service Specific Convergence Sublayer
ST	Straight Tip, or Stick and Turn
STM	Synchronous Transfer Mode

STP	Shielded Twisted Pair, Spanning Tree Protocol
STS	Synchronous Transport Signal
SVC	Switched Virtual Circuit (or Channel)
SVCC	Switched Virtual Channel Connection
SVPC	Switched Virtual Path Connection
TAXI	Transparent Asynchronous Transmitter/Receiver Interface
TC	Transmission Convergence
TCP	Transmission Control Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
TCR	Tagged Cell Rate
TCS	Transmission Convergence Sublayer
TDM	Time Division Multiplexing
TE	Terminal Equipment
TFTP	Trivial File Transfer Protocol
TM	Traffic Management
UAS	Unavailable Seconds
UBR	Unspecified Bit Rate
UDP	User Datagram Protocol
UNI	User-to-Network Interface
UPC	Usage Parameter Control
UTOPIA	Universal Test & Operations Interface for ATM
UTP	Unshielded Twisted Pair
VBR	Variable Bit Rate
VC	Virtual Channel (or Circuit)
VCC	Virtual Channel Connection
VCI	Virtual Channel Identifier
VCL	Virtual Channel Link
VINES	Virtual Network Software
VLAN	Virtual Local Area Network
VP	Virtual Path
VPC	Virtual Path Connection
VPDN	Virtual Private Data Network
VPI	Virtual Path Identifier
VPL	Virtual Path Link
VPN	Virtual Private Network
VPT	Virtual Path Terminator
VS/VD	Virtual Source/Virtual Destination
VT	Virtual Tributary
WAN	Wide-Area Network
ZBTSI	Zero Byte Time Slot Interchange

Glossary

10Base-T - a 10 Mbps baseband Ethernet specification utilizing twisted-pair cabling (Category 3, 4, or 5). 10BaseT, which is part of the IEEE 802.3 specification, has a distance limit of approximately 100 meters per segment.

802.1d Spanning Tree Bridging - the IEEE standard for bridging; a MAC layer standard for transparently connecting two or more LANs (often called subnetworks) that are running the same protocols and cabling. This arrangement creates an extended network, in which any two workstations on the linked LANs can share data.

802.3 Ethernet - the IEEE standard for Ethernet; a physical-layer standard that uses the CSMA / CD access method on a bus-topology LAN.

802.5 Token Ring - the IEEE physical-layer standard that uses the token-passing access method on a ring-topology LAN.

AAL Connection - an association established by the AAL between two or more next higher layer entities.

Adapter - A fitting that supplies a passage between two sets of equipment when they cannot be directly interconnected.

Adaptive Differential Pulse Code Modulation (ADPCM) - A technique that allows analog voice signals to be carried on a 32K bps digital channel. Sampling is done at 8Hz with 4 bits used to describe the difference between adjacent samples.

Adaptive Pulse Code Modulation (APCM) - A technique that effectively reduces occupied bandwidth per active speaker by reducing sampling rates during periods of overflow peak traffic.

Address - A unique identity of each network station on a LAN or WAN.

Address Complete Message (ACM) - A B-ISUP call control message from the receiving exchange to sending exchange indicating the completion of address information.

Address Mask - a bit mask used to identify which bits in an address (usually an IP address) are network significant, subnet significant, and host significant portions of the complete address. This mask is also known as the subnet mask because the subnetwork portion of the address can be determined by comparing the binary version of the mask to an IP address in that subnet. The mask holds the same number of bits as the protocol address it references.

Address Prefix - A string of 0 or more bits up to a maximum of 152 bits that is the lead portion of one or more ATM addresses.

Address Resolution - The procedure by which a client associates a LAN destination with the ATM address of another client or the BUS.

Address Resolution Protocol (ARP) - a method used to resolve higher level protocol addressing (such as IP) into the appropriate header data required for ATM; i.e., port, VPI, and VCI; also defines the AAL type to be used.

Agent - a component of network- and desktop-management software, such as SNMP, that gathers information from MIBs.

alarm - an unsolicited message from a device, typically indicating a problem with the system that requires attention.

Alarm Indication Signal (AIS) - In T1, an all ones condition used to alert a receiver that its incoming signal (or frame) has been lost. The loss of signal or frame is detected at the receiving end, and the failed signal is replaced by all the ones condition which the receiver interprets as an AIS. The normal response to this is AIS is for the receiving end to generate a yellow alarm signal as part of its transmission towards the faulty end. (The AIS itself is sometimes called a Blue Signal).

A-Law - The PCM coding and companding standard used in Europe.

Allowable Cell Rate (ACR) - parameter defined by the ATM Forum for ATM traffic management. ACR varies between the MCR and the PCR, and is dynamically controlled using congestion control mechanisms.

Alternate Mark Inversion (AMI) - A line coding format used on T1 facilities that transmits ones by alternate positive and negative pulses.

Alternate Routing - A mechanism that supports the use of a new path after an attempt to set up a connection along a previously selected path fails.

American National Standards Institute (ANSI) - a private organization that coordinates the setting and approval of some U.S. standards. It also represents the United States to the International Standards Organization.

American Standard Code for Information Interchange (ASCII) - a standard character set that (typically) assigns a 7-bit sequence to each letter, number, and selected control characters.

AppleTalk - a networking protocol developed by Apple Computer for communication between Apple's products and other computers. Independent of the network layer, AppleTalk runs on LocalTalk, EtherTalk and TokenTalk.

Application Layer - Layer seven of the ISO reference model; provides the end-user interface.

Application Program (APP) - a complete, self-contained program that performs a specific function directly for the user.

Application Program Interface (API) - a language format that defines how a program can be made to interact with another program, service, or other software; it allows users to develop custom interfaces with FORE products.

Assigned Cell - a cell that provides a service to an upper layer entity or ATM Layer Management entity (ATMM-entity).

asxmon - a FORE program that repeatedly displays the state of the switch and its active ports.

Asynchronous Time Division Multiplexing (ATDM) - a multiplexing technique in which a transmission capability is organized into a priori, unassigned time slots. The time slots are assigned to cells upon request of each application's instantaneous real need.

Asynchronous Transfer Mode (ATM) - a transfer mode in which the information is organized into cells. It is asynchronous in the sense that the recurrence of cells containing information from an individual user is not necessarily periodic.

ATM Adaptation Layer (AAL) - the AAL divides user information into segments suitable for packaging into a series of ATM cells. AAL layer types are used as follows:

AAL-1 - constant bit rate, time-dependent traffic such as voice and video

AAL-2 - still undefined; a placeholder for variable bit rate video transmission

AAL-3/4 - variable bit rate, delay-tolerant data traffic requiring some sequencing and/or error detection support (originally two AAL types, connection-oriented and connectionless, which have been combined)

AAL-5 - variable bit rate, delay-tolerant, connection-oriented data traffic requiring minimal sequencing or error detection support

ATM Address - Defined in the UNI Specification as 3 formats, each having 20 bytes in length.

ATM Forum - an international non-profit organization formed with the objective of accelerating the use of ATM products and services through a rapid convergence of interoperability specifications. In addition, the Forum promotes industry cooperation and awareness.

ATM Inverse Multiplexing (AIMUX) - A device that allows multiple T1 or E1 communications facilities to be combined into a single broadband facility for the transmission of ATM cells.

ATM Layer link - a section of an ATM Layer connection between two adjacent active ATM Layer entities (ATM-entities).

ATM Link - a virtual path link (VPL) or a virtual channel link (VCL).

ATM Management Interface (AMI) - the user interface to FORE Systems' *ForeThought* switch control software (SCS). AMI lets users monitor and change various operating configurations of FORE Systems switches and network module hardware and software, IP connectivity, and SNMP network management.

ATM Peer-to-Peer Connection - a virtual channel connection (VCC) or a virtual path connection (VPC) directly established, such as workstation-to-workstation. This setup is not commonly used in networks.

ATM Traffic Descriptor - a generic list of parameters that can be used to capture the intrinsic traffic characteristics of a requested ATM connection.

ATM User-to-User Connection - an association established by the ATM Layer to support communication between two or more ATM service users (i.e., between two or more next higher layer entities or between two or more ATM entities). The communication over an ATM Layer connection may be either bidirectional or unidirectional. The same Virtual Channel Identifier (VCI) is used for both directions of a connection at an interface.

atmarp - a FORE program that shows and manipulates ATM ARP entries maintained by the given device driver. This is also used to establish PVC connections.

ATM-attached Host Functional Group (AHFG) - The group of functions performed by an ATM-attached host that is participating in the MPOA service.

atmconfig - a FORE program used to enable or disable SPANS signaling.

atmstat - a FORE program that shows statistics gathered about a given adapter card by the device driver. These statistics include ATM layer and ATM adaptation layer cell and error counts. This can also be used to query other hosts via SNMP.

Attachment User Interface (AUI) - IEEE 802.3 interface between a media attachment unit (MAU) and a network interface card (NIC). The term AUI can also refer to the rear panel port to which an AUI cable might attach.

Auto-logout - a feature that automatically logs out a user if there has been no user interface activity for a specified length of time.

Automatic Protection Switching (APS) - Equipment installed in communications systems to detect circuit failures and automatically switch to redundant, standby equipment.

Available Bit Rate (ABR) - a type of traffic for which the ATM network attempts to meet that traffic's bandwidth requirements. It does not guarantee a specific amount of bandwidth and the end station must retransmit any information that did not reach the far end.

Backbone - the main connectivity device of a distributed system. All systems that have connectivity to the backbone connect to each other, but systems can set up private arrangements with each other to bypass the backbone to improve cost, performance, or security.

Backplane - High-speed communications line to which individual components are connected.

Backward Explicit Congestion Notification (BECN) - A Resource Management cell type generated by the network or the destination, indicating congestion or approaching congestion for traffic flowing in the direction opposite that of the BECN cell.

Bandwidth - usually identifies the capacity or amount of data that can be sent through a given circuit; may be user-specified in a PVC.

Baud - unit of signalling speed, equal to the number of discrete conditions or signal events per second. If each signal event represents only one bit, the baud rate is the same as bps; if each signal event represents more than one bit (such as a dibit), the baud rate is smaller than bps.

Bayonet-Neill-Concelman (BNC) - a bayonet-locking connector used to terminate coaxial cables. BNC is also referred to as Bayonet Network Connector.

Bipolar 8 Zero Substitution (B8ZS) - a technique used to satisfy the ones density requirements of digital T-carrier facilities in the public network while allowing 64 Kbps clear channel data. Strings of eight consecutive zeroes are replaced by an eight-bit code representing two intentional bipolar pulse code violations (000V10V1).

Bipolar Violation (BPV) - an error event on a line in which the normal pattern of alternating high (one) and low (zero) signals is disrupted. A bipolar violation is noted when two high signals occur without an intervening low signal, or vice versa.

B-ISDN Inter-Carrier Interface (B-ICI) - An ATM Forum defined specification for the interface between public ATM networks to support user services across multiple public carriers.

Bit Error Rate (BER) - A measure of transmission quality, generally shown as a negative exponent, (e.g., 10^{-7} which means 1 out of 10^7 bits [1 out of 10,000,000 bits] are in error).

Bit Interleaved Parity (BIP) - an error-detection technique in which character bit patterns are forced into parity, so that the total number of one bits is always odd or always even. This is accomplished by the addition of a one or zero bit to each byte, as the byte is transmitted; at the other end of the transmission, the receiving device verifies the parity (odd or even) and the accuracy of the transmission.

Bit Robbing - The use of the least significant bit per channel in every sixth frame for signaling.

Bit Stuffing - A process in bit-oriented protocols where a zero is inserted into a string of ones by the sender to prevent the receiver from interpreting valid user data (the string of ones) as control characters (a Flag character for instance).

Border Gateway Protocol (BGP) - used by gateways in an internet connecting autonomous networks. It is derived from experiences learned using the EGP.

bps - bits per second

Bridge - a device that expands a Local Area Network by forwarding frames between data link layers associated with two separate cables, usually carrying a common protocol. Bridges can usually be made to filter certain packets (to forward only certain traffic).

Bridge Protocol Data Unit (BPDU) - A message type used by bridges to exchange management and control information.

Broadband - a service or system requiring transmission channels capable of supporting rates greater than the Integrated Services Digital Network (ISDN) primary rate.

Broadband Access - an ISDN access capable of supporting one or more broadband services.

Broadband Connection Oriented Bearer (BCOB) - Information in the SETUP message that indicates the type of service requested by the calling user.

BCOB-A (Bearer Class A) - Indicated by ATM end user in SETUP message for connection-oriented, constant bit rate service. The network may perform internetworking based on AAL information element (IE).

BCOB-C (Bearer Class C) - Indicated by ATM end user in SETUP message for connection-oriented, variable bit rate service. The network may perform internetworking based on AAL information element (IE).

BCOB-X (Bearer Class X) - Indicated by ATM end user in SETUP message for ATM transport service where AAL, traffic type and timing requirements are transparent to the network.

Broadband Integrated Services Digital Network (B-ISDN) - a common digital network suitable for voice, video, and high-speed data services running at rates beginning at 155 Mbps.

Broadband ISDN User's Part (B-ISUP) - A protocol used to establish, maintain and release broadband switched network connections across an SS7/ATM network.

Broadband Terminal Equipment (B-TE) - An equipment category for B-ISDN which includes terminal adapters and terminals.

Broadcast - Data transmission to all addresses or functions.

Broadcast and Unknown Server (BUS) - in an emulated LAN, the BUS is responsible for accepting broadcast, multicast, and unknown unicast packets from the LECs to the broadcast MAC address (FFFFFFFFFFFF) via dedicated point-to-point connections, and forwarding the packets to all of the members of the ELAN using a single point-to-multipoint connection.

Router (bridging/router) - a device that routes some protocols and bridges others based on configuration information.

Buffer - A data storage medium used to compensate of a difference in rate of data flow or time of occurrence of events when transmitting data from one device to another.

Building Integrated Timing Supply (BITS) - a master timing supply for an entire building, which is a master clock and its ancillary equipment. The BITS supplies DS1 and/or composite clock timing references for synchronization to all other clocks and timing sources in that building.

Bursty Errored Seconds (BES) - a BES contains more than 1 and fewer than 320 path coding violation error events, and no severely errored frame or AIS defects. Controlled slips are not included in determining BESs.

Bursty Second - a second during which there were at least the set number of BES threshold event errors but fewer than the set number of SES threshold event errors.

Byte - A computer-readable group of bits (normally 8 bits in length).

Call - an association between two or more users or between a user and a network entity that is established by the use of network capabilities. This association may have zero or more connections.

Carrier - a company, such as any of the "baby Bell" companies, that provide network communications services, either within a local area or between local areas.

Carrier Group Alarm (CGA) - A service alarm generated by a channel bank when an out-of-frame (OOF) condition exists for some predetermined length of time (generally 300 milliseconds to 2.5 seconds). The alarm causes the calls using a trunk to be dropped and trunk conditioning to be applied.

Carrier Identification Parameter (CIP) - A 3 or 4 digit code in the initial address message identifying the carrier to be used for the connection.

cchan - a FORE program that manages virtual channels on a *ForeRunner* switch running asxd.

Cell - an ATM Layer protocol data unit (PDU). The basic unit of information transported in ATM technology, each 53-byte cell contains a 5-byte header and a 48-byte payload.

Cell Delay Variation (CDV) - a quantification of cell clumping for a connection. The cell clumping CDV (y_k) is defined as the difference between a cell's expected reference arrival time (ck) and its actual arrival time (ak). The expected reference arrival time (ck) of cell k of a specific connection is $\max. T$ is the reciprocal of the negotiated peak cell rate.

Cell Delineation - the protocol for recognizing the beginning and end of ATM cells within the raw serial bit stream.

Cell Header - ATM Layer protocol control information.

Cell Loss Priority (CLP) - the last bit of byte four in an ATM cell header; indicates the eligibility of the cell for discard by the network under congested conditions. If the bit is set to 1, the cell may be discarded by the network depending on traffic conditions.

Cell Loss Ratio - In a network, cell loss ratio is $(1-x/y)$, where y is the number of cells that arrive in an interval at an ingress of the network; and x is the number of these y cells that leave at the egress of the network element.

Cell Loss Ratio (CLR) - CLR is a negotiated QoS parameter and acceptable values are network specific. The objective is to minimize CLR provided the end-system adapts the traffic to the changing ATM layer transfer characteristics. The Cell Loss Ratio is defined for a connection as: Lost Cells/Total Transmitted Cells. The CLR parameter is the value of CLR that the network agrees to offer as an objective over the lifetime of the connection. It is expressed as an order of magnitude, having a range of 10⁻¹ to 10⁻¹⁵ and unspecified.

Cell Misinsertion Rate (CMR) - the ratio of cells received at an endpoint that were not originally transmitted by the source end in relation to the total number of cells properly transmitted.

Cell Rate Adaptation (CRA) - a function performed by a protocol module in which empty cells (known as unassigned cells) are added to the output stream. This is because there always must be a fixed number of cells in the output direction; when there are not enough cells to transmit, unassigned cells are added to the output data stream.

Cell Relay Service (CRS) - a carrier service which supports the receipt and transmission of ATM cells between end users in compliance with ATM standards and implementation specifications.

Cell Transfer Delay - the transit delay of an ATM cell successfully passed between two designated boundaries. See CTD.

Cell Transfer Delay (CTD) - This is defined as the elapsed time between a cell exit event at the measurement point 1 (e.g., at the source UNI) and the corresponding cell entry event at the measurement point 2 (e.g., the destination UNI) for a particular connection. The cell transfer delay between two measurement points is the sum of the total inter-ATM node transmission delay and the total ATM node processing delay.

Channel - A path or circuit along which information flows.

Channel Associated Signaling (CAS) - a form of circuit state signaling in which the circuit state is indicated by one or more bits of signaling status sent repetitively and associated with that specific circuit.

Channel Bank - A device that multiplexes many slow speed voice or data conversations onto high speed link and controls the flow.

Channel Service Unit (CSU) - An interface for digital leased lines which performs loopback testing and line conditioning.

Channelization - capability of transmitting independent signals together over a cable while still maintaining their separate identity for later separation.

Circuit - A communications link between points.

Circuit Emulation Service (CES) - The ATM Forum circuit emulation service interoperability specification specifies interoperability agreements for supporting Constant Bit Rate (CBR) traffic over ATM networks that comply with the other ATM Forum interoperability agreements. Specifically, this specification supports emulation of existing TDM circuits over ATM networks.

Classical IP (CLIP) - IP over ATM which conforms to RFC 1577.

Clear to Send (CTS) - and RS-232 modem interface control signal (sent from the modem to the DTE on pin 5) which indicates that the attached DTE may begin transmitting; issuance in response to the DTE's RTS.

Clocking - Regularly timed impulses.

Closed User Group - A subgroup of network users that can be its own entity; any member of the subgroup can only communicate with other members of that subgroup.

Coaxial Cable - Coax is a type of electrical communications medium used in the LAN environment. This cable consists of an outer conductor concentric to an inner conductor, separated from each other by insulating material, and covered by some protective outer material. This medium offers large bandwidth, supporting high data rates with high immunity to electrical interference and a low incidence of errors. Coax is subject to distance limitations and is relatively expensive and difficult to install.

Cold Start Trap - an SNMP trap which is sent after a power-cycle (see *trap*).

Collision - Overlapping transmissions that occur when two or more nodes on a LAN attempt to transmit at or about the same time.

Committed Information Rate (CIR) - CIR is the information transfer rate which a network offering Frame Relay Services (FRS) is committed to transfer under normal conditions. The rate is averaged over a minimum increment of time.

Common Channel Signaling (CCS) - A form signaling in which a group of circuits share a signaling channel. Refer to SS7.

Common Management Interface Protocol (CMIP) - An ITU-TSS standard for the message formats and procedures used to exchange management information in order to operate, administer maintain and provision a network.

Concatenation - The connection of transmission channels similar to a chain.

Concentrator - a communications device that offers the ability to concentrate many lower-speed channels into and out of one or more high-speed channels.

Configuration - The phase in which the LE Client discovers the LE Service.

Congestion Management - traffic management feature that helps ensure reasonable service for VBR connections in an ATM network, based on a priority, sustained cell rate (SCR), and peak cell rate (PCR). During times of congestion, bandwidth is reduced to the SCR, based on the priority of the connection.

Connection - the concatenation of ATM Layer links in order to provide an end-to-end information transfer capability to access points.

Connection Admission Control (CAC) - the procedure used to decide if a request for an ATM connection can be accepted based on the attributes of both the requested connection and the existing connections.

Connection Endpoint (CE) - a terminator at one end of a layer connection within a SAP.

Connection Endpoint Identifier (CEI) - an identifier of a CE that can be used to identify the connection at a SAP.

Connectionless Broadband Data Service (CBDS) - A connectionless service similar to Bellcore's SMDS defined by European Telecommunications Standards Institute (ETSI).

Connectionless Service - a type of service in which no pre-determined path or link has been established for transfer of information, supported by AAL 4.

Connectionless Service (CLS) - A service which allows the transfer of information among service subscribers without the need for end-to-end establishment procedures.

Connection-Oriented Service - a type of service in which information always traverses the same pre-established path or link between two points, supported by AAL 3.

Constant Bit Rate (CBR) - a type of traffic that requires a continuous, specific amount of bandwidth over the ATM network (e.g., digital information such as video and digitized voice).

Controlled Slip (CS) - a situation in which one frame's worth of data is either lost or replicated. A controlled slip typically occurs when the sending device and receiving device are not using the same clock.

Convergence Sublayer (CS) - a portion of the AAL. Data is passed first to the CS where it is divided into rational, fixed-length packets or PDUs (Protocol Data Units). For example, AAL 4 processes user data into blocks that are a maximum of 64 kbytes long.

Corresponding Entities - peer entities with a lower layer connection among them.

cpath - a FORE program used to manage virtual paths on a *ForeRunner* switch running asxd.

cport - a FORE program that monitors and changes the state of ports on a *ForeRunner* switch running asxd.

Cross Connection - a mapping between two channels or paths at a network device.

Customer Premise Equipment (CPE) - equipment that is on the customer side of the point of demarcation, as opposed to equipment that is on a carrier side. See also point of demarcation.

Cut Through - Establishment of a complete path for signaling and/or audio communications.

Cyclic Redundancy Check (CRC) - an error detection scheme in which a number is derived from the data that will be transmitted. By recalculating the CRC at the remote end and comparing it to the value originally transmitted, the receiving node can detect errors.

D3/D4 - Refers to compliance with AT&T TR (Technical Reference) 62411 definitions for coding, supervision, and alarm support. D3/D4 compatibility ensures support of digital PBXes, M24 services, Megacom services, and Mode 3 D3/D4 channel banks at DS-1 level.

D4 Channelization - refers to compliance with AT&T Technical Reference 62411 regarding DS1 frame layout (the sequential assignment of channels and time slot numbers within the DS1).

D4 Framed/Framing Format - in T1, a 193-bit frame format in which the 193rd bit is used for framing and signaling information (the frame/framing bit). To be considered in support of D4 Framing, a device must be able to synchronize and frame-up on the 193rd bit.

Data Communications Equipment (DCE) - a definition in the RS232C standard that describes the functions of the signals and the physical characteristics of an interface for a communication device such as a modem.

Data Country Code (DCC) - This specifies the country in which an address is registered. The codes are given in ISO 3166. The length of this field is two octets. The digits of the data country code are encoded in Binary Coded Decimal (BCD) syntax. The codes will be left justified and padded on the right with the hexadecimal value "F" to fill the two octets.

Data Link - Communications connection used to transmit data from a source to a destination.

Data Link Connection Identifier (DLCI) - connection identifier associated with frame relay packets that serves the same functions as, and translates directly to, the VPI/VCI on an ATM cell.

Data Link Layer - Layer 2 of the OSI model, responsible for encoding data and passing it to the physical medium. The IEEE divides this layer into the LLC (Logical Link Control) and MAC (Media Access Control) sublayers.

Data Set Ready (DSR) - an RS-232 modem interface control signal (sent from the modem to the DTE on pin 6) which indicates that the modem is connected to the telephone circuit. Usually a prerequisite to the DTE issuing RTS.

Data Terminal Equipment (DTE) - generally user devices, such as terminals and computers, that connect to data circuit-terminating equipment. They either generate or receive the data carried by the network.

Data Terminal Ready (DTR) - an RS232 modem interface control signal (sent from the DTE to the modem on pin 20) which indicates that the DTE is ready for data transmission and which requests that the modem be connected to the telephone circuit.

Datagram - a packet of information used in a connectionless network service that is routed to its destination using an address included in the datagram's header.

DECnet - Digital Equipment Corporation's proprietary LAN.

Defense Advanced Research Projects Agency (DARPA) - the US government agency that funded the ARPANET.

Demultiplexing - a function performed by a layer entity that identifies and separates SDUs from a single connection to more than one connection (see *multiplexing*).

Destination End Station (DES) - An ATM termination point which is the destination for ATM messages of a connection and is used as a reference point for ABR services. See SES.

Digital Access and Cross-Connect System (DACS) - Digital switching system for routing T1 lines, and DS-0 portions of lines, among multiple T1 ports.

Digital Cross-connect System (DCS) - an electronic patch panel used to route digital signals in a central office.

Digital Standard n (0, 1, 1C, 2, and 3) (DSn) - a method defining the rate and format of digital hierarchy, with asynchronous data rates defined as follows:

DS0	64kb/s	1 voice channel
DS1	1.544Mb/s	24 DS0s
DS1C	3.152 Mb/s	2 DS1s
DS2	6.312 Mb/s	4 DS1s
DS3	44.736 Mb/s	28 DS1s

Synchronous data rates (SONET) are defined as:

STS-1/OC-1	51.84 Mb/s	28 DS1s or 1 DS3
STS-3/OC-3	155.52 Mb/s	3 STS-1s byte interleaved
STS-3c/OC-3c	155.52 Mb/s	Concatenated, indivisible payload
STS-12/OC-12	622.08 Mb/s	12 STS-1s, 4 STS-3cs, or any mixture
STS-12c/OC-12c	622.08 Mb/s	Concatenated, indivisible payload
STS-48/OC-48	2488.32 Mb/s	48 STS-1s, 16 STS-3cs, or any mixture

DIP (Dual In-line Package) Switch - a device that has two parallel rows of contacts that let the user switch electrical current through a pair of those contacts to on or off. They are used to reconfigure components and peripherals.

Domain Name Server - a computer that converts names to their corresponding Internet numbers. It allows users to telnet or FTP to the name instead of the number.

Domain Naming System (DNS) - the distributed name and address mechanism used in the Internet.

Duplex - Two way communication.

DXI - a generic phrase used in the full names of several protocols, all commonly used to allow a pair of DCE and DTE devices to share the implementation of a particular WAN protocol. The protocols define the packet formats used to transport data between DCE and DTE devices.

DXI Frame Address (DFA) - a connection identifier associated with ATM DXI packets that serves the same functions as, and translates directly to, the VPI/VCI on an ATM cell.

Dynamic Allocation - A technique in which the resources assigned for program execution are determined by criteria applied at the moment of need.

E.164 - A public network addressing standard utilizing up to a maximum of 15 digits. ATM uses E.164 addressing for public network addressing.

E1 - Wide-area digital transmission scheme used predominantly in Europe that carries data at a rate of 2.048 Mbps. E1 lines can be leased for private use from common carriers.

E3 - Wide-area digital transmission scheme used predominantly in Europe that carries data at a rate of 34.368 Mbps. E3 lines can be leased for private use from common carriers.

Edge Device - A physical device which is capable of forwarding packets between legacy interworking interfaces (e.g., Ethernet, Token Ring, etc.) and ATM interfaces based on data-link and network layer information but which does not participate in the running of any network layer routing protocol. An Edge Device obtains forwarding descriptions using the route distribution protocol.

elarp - a FORE program that shows and manipulates MAC and ATM address mappings for LAN Emulation Clients (LECs).

elconfig - a FORE program that shows and modifies LEC configuration. Lets the user set the NSAP address of the LAN Emulation Configuration Server, display the list of Emulated LANs configured in the LECS for this host, display the list of ELANs locally configured along with the membership state of each, and locally administer ELAN membership.

Electrically Erasable Programmable Read Only Memory (EEPROM) - an EPROM that can be cleared with electrical signals rather than the traditional ultraviolet light.

Electromagnetic Interference (EMI) - signals generated and radiated by an electronic device that cause interference with radio communications, among other effects.

Electronics Industries Association (EIA) - a USA trade organization that issues its own standards and contributes to ANSI; developed RS-232. Membership includes USA manufacturers.

Embedded SNMP Agent - an SNMP agent can come in two forms: embedded or proxy. An embedded SNMP agent is integrated into the physical hardware and software of the unit.

Emulated Local Area Network (ELAN) - A logical network initiated by using the mechanisms defined by LAN Emulation. This could include ATM and legacy attached end stations.

End System (ES) - a system where an ATM connection is terminated or initiated (an originating end system initiates the connection; a terminating end system terminates the connection).

End System Identifier (ESI) - This identifier distinguishes multiple nodes at the same level in case the lower level peer group is partitioned.

End-to-End Connection - when used in reference to an ATM network, a connection that travels through an ATM network, passing through various ATM devices and with endpoints at the termination of the ATM network.

Enterprise - Terminology generally referring to customers with multiple, non-contiguous geographic locations.

Equalization (EQL) - the process of compensating for line distortions.

Erasable Programmable Read Only Memory (EPROM) - A PROM which may be erased and rewritten to perform new or different functions (normally done with a PROM burner).

Errored Second (ES) - a second during which at least one code violation occurred.

Ethernet - a 10-Mbps, coaxial standard for LANs in which all nodes connect to the cable where they contend for access.

Excessive Zeroes (EXZ) Error Event - An Excessive Zeroes error event for an AMI-coded signal is the occurrence of more than fifteen contiguous zeroes. For a B8ZS coded signal, the defect occurs when more than seven contiguous zeroes are detected.

Explicit Forward Congestion Indication (EFCI) - the second bit of the payload type field in the header of an ATM cell, the EFCI bit indicates network congestion to receiving hosts. On a congested switch, the EFCI bit is set to "1" by the transmitting network module when a certain number of cells have accumulated in the network module's shared memory buffer. When a cell is received that has its EFCI bit set to "1," the receiving host notifies the sending host, which should then reduce its transmission rate.

Explicit Rate (ER) - The Explicit Rate is an RM-cell field used to limit the source ACR to a specific value. It is initially set by the source to a requested rate (such as PCR). It may be subsequently reduced by any network element in the path to a value that the element can sustain. ER is formatted as a rate.

Extended Industry Standard Architecture (EISA) - bus architecture for desktop computers that provides a 32-bit data passage and maintains compatibility with the ISA or AT architecture.

Extended Super Frame (ESF) - a T1 framing format that utilizes the 193rd bit as a framing bit, but whose Superframe is made up of 24 frames instead of 12 as in D4 format. ESF also provides CRC error detection and maintenance data link functions.

Exterior Gateway Protocol (EGP) - used by gateways in an internet, connecting autonomous networks.

Fairness - related to Generic Flow Control, fairness is defined as meeting all of the agreed quality of service requirements by controlling the order of service for all active connections.

Far End Block Error (FEBE) - an error detected by extracting the 4-bit FEBE field from the path status byte (G1). The legal range for the 4-bit field is between 0000 and 1000, representing zero to eight errors. Any other value is interpreted as zero errors.

Far End Receive Failure (FERF) - a line error asserted when a 110 binary pattern is detected in bits 6, 7, 8 of the K2 byte for five consecutive frames. A line FERF is removed when any pattern other than 110 is detected in these bits for five consecutive frames.

Far-End - in a relationship between two devices in a circuit, the far-end device is the one that is remote.

Face Contact (FC) - Designation for fiber optic connector designed by Nippon Telegraph and Telephone which features a movable anti-rotation key allowing good repeatable performance despite numerous mating. Normally referred to as Fiber Connector, FC actually stands for Face Contact and sometimes linked with PC (Point Contact), designated as FC or FC-PC.

FCC Part 68 - The FCC rules regulating the direct connection of non-telephone company provided equipment to the public telephone network.

Federal Communications Commission (FCC) - a board of commissioners appointed by the President under the Communications Act of 1934, with the authority to regulate all interstate telecommunications originating in the United States, including transmission over phone lines.

Fiber Distributed Data Interface (FDDI) - high-speed data network that uses fiber-optic as the physical medium. Operates in similar manner to Ethernet or Token Ring, only faster.

File Transfer Protocol (FTP) - a TCP/IP protocol that lets a user on one computer access, and transfer data to and from, another computer over a network. ftp is usually the name of the program the user invokes to accomplish this task.

First-In, First-Out (FIFO) - method of coordinating the sequential flow of data through a buffer.

Flag - a bit pattern of six binary "1"s bounded by a binary "0" at each end (forms a 0111 1110 or Hex "7E"). It is used to mark the beginning and/or end of a frame.

Flow Control - The way in which information is controlled in a network to prevent loss of data when the receiving buffer is near its capacity.

ForeThought PNNI (FT-PNNI) - a FORE Systems routing and signalling protocol that uses private ATM (NSAP) addresses; a precursor to ATM Forum PNNI (see PNNI).

Forward Error Correction (FEC) - A technique used by a receiver for correcting errors incurred in transmission over a communications channel without requiring retransmission of any information by the transmitter; typically involves a convolution of the transmitted bits and the appending of extra bits by both the receiver and transmitter using a common algorithm.

Forward Explicit Congestion Notification (FECN) - Bit set by a Frame Relay network to inform data terminal equipment (DTE) receiving the frame that congestion was experienced in the path from source to destination. DTE receiving frames with the FECN bit set can request that higher-level protocols take flow control action as appropriate.

Fractional T1 - the use of bandwidth in 64Kbps increments up to 1.544Mbps from a T1 facility.

Frame - a variable length group of data bits with a specific format containing flags at the beginning and end to provide demarcation.

Frame Check Sequence (FCS) - In bit-oriented protocols, a 16-bit field that contains transmission error checking information, usually appended to the end of the frame.

Frame Relay - a fast packet switching protocol based on the LAPD protocol of ISDN that performs routing and transfer with less overhead processing than X.25.

Frame Synchronization Error - an error in which one or more time slot framing bits are in error.

Frame-Based UNI (FUNI) - An ATM switch-based interface which accepts frame-based ATM traffic and converts it into cells.

Frame-Relay Service (FRS) - A connection oriented service that is capable of carrying up to 4096 bytes per frame.

Framing - a protocol that separates incoming bits into identifiable groups so that the receiving multiplexer recognizes the grouping.

Frequency Division Multiplexing (FDM) - a method of dividing an available frequency range into parts with each having enough bandwidth to carry one channel.

Gbps - gigabits per second (billion)

Generic Cell Rate Algorithm (GCRA) - an algorithm which is employed in traffic policing and is part of the user / network service contract. The GCRA is a scheduling algorithm which ensures that cells are marked as conforming when they arrive when expected or later than expected and non-conforming when they arrive sooner than expected.

Generic Connection Admission Control (GCAC) - This is a process to determine if a link has potentially enough resources to support a connection.

Generic Flow Control (GFC) - the first four bits of the first byte in an ATM cell header. Used to control the flow of traffic across the User-to-Network Interface (UNI), and thus into the network. Exact mechanisms for flow control are still under investigation and no explicit definition for this field exists at this time. (This field is used only at the UNI; for NNI-NNI use (between network nodes), these four bits provide additional network address capacity, and are appended to the VPI field.)

GIO - a proprietary bus architecture used in certain Silicon Graphics, Inc. workstations.

Header - protocol control information located at the beginning of a protocol data unit.

Header Error Control (HEC) - a CRC code located in the last byte of an ATM cell header that is used for checking cell header integrity only.

High Density Bipolar (HDB3) - A bipolar coding method that does not allow more than 3 consecutive zeroes.

High Level Data Link Control (HDLC) - An ITU-TSS link layer protocol standard for point-to-point and multi-point communications.

High Performance Parallel Interface (HIPPI) - ANSI standard that extends the computer bus over fairly short distances at speeds of 800 and 1600 Mbps.

High-Speed Serial Interface (HSSI) - a serial communications connection that operates at speeds of up to 1.544 Mbps.

Host - In a network, the primary or controlling computer in a multiple computer installation.

HPUX - the Hewlett-Packard version of UNIX.

Hub - a device that connects several other devices, usually in a star topology.

I/O Module - FORE's interface cards for the LAX-20 LAN Access Switch, designed to connect Ethernet, Token Ring, and FDDI LANs to *ForeRunner* ATM networks.

Institute of Electrical and Electronics Engineers (IEEE) - the world's largest technical professional society. Based in the U.S., the IEEE sponsors technical conferences, symposia & local meetings worldwide, publishes nearly 25% of the world's technical papers in electrical, electronics & computer engineering, provides educational programs for members, and promotes standardization.

IEEE 802 - Standards for the interconnection of LAN computer equipment. Deals with the Data Link Layers of the ISO Reference Model for OSI.

IEEE 802.1 - Defines the high-level network interfaces such as architecture, internetworking and network management.

IEEE 802.2 - Defines the Logical Link Control interface between the Data Link and Network Layers.

IEEE 802.3 - Defines CSMA / CD (Ethernet).

IEEE 802.4 - Defines the token-passing bus.

IEEE 802.5 - Defines the Token Ring access methodology. This standard incorporates IBM's Token Ring specifications.

IEEE 802.6 - Defines Metropolitan Area Networks.

IEEE 802.7 - The broadband technical advisory group.

IEEE 802.8 - The fiber optics technical advisory group.

IEEE 802.9 - Defines integrated data and voice networks.

Integrated Services Digital Network (ISDN) - an emerging technology that is beginning to be offered by the telephone carriers of the world. ISDN combines voice and digital network services into a single medium or wire.

Interexchange Carriers (IXC) - Long-distance communications companies that provide service between Local Access Transport Areas (LATAs).

Interface Data - the unit of information transferred to / from the upper layer in a single interaction across a SAP. Each Interface Data Unit (IDU) controls interface information and may also contain the whole or part of the SDU.

Interface Data Unit (IDU) - The unit of information transferred to / from the upper layer in a single interaction across the SAP. Each IDU contains interface control information and may also contain the whole or part of the SDU.

Interim Local Management Interface (ILMI) - the standard that specifies the use of the Simple Network Management Protocol (SNMP) and an ATM management information base (MIB) to provide network status and configuration information.

Intermediate System (IS) - a system that provides forwarding functions or relaying functions or both for a specific ATM connection. OAM cells may be generated and received.

International Standards Organization (ISO) - a voluntary, non treaty organization founded in 1946 that is responsible for creating international standards in many areas, including computers and communications.

International Telephone and Telegraph Consultative Committee (CCITT) - the international standards body for telecommunications.

Internet - (note the capital “I”) the largest internet in the world including large national backbone nets and many regional and local networks worldwide. The Internet uses the TCP/IP suite. Networks with only e-mail connectivity are not considered on the Internet.

internet - while an internet is a network, the term “internet” is usually used to refer to a collection of networks interconnected with routers.

Internet Addresses - the numbers used to identify hosts on an internet network. Internet host numbers are divided into two parts; the first is the network number and the second, or local, part is a host number on that particular network. There are also three classes of networks in the Internet, based on the number of hosts on a given network. Large networks are classified as Class A, having addresses in the range 1-126 and having a maximum of 16,387,064 hosts. Medium networks are classified as Class B, with addresses in the range 128-191 and with a maximum of 64,516 hosts. Small networks are classified as Class C, having addresses in the range 192-254 with a maximum of 254 hosts. Addresses are given as dotted decimal numbers in the following format:

nnn.nnn.nnn.nnn

In a Class A network, the first of the numbers is the network number, the last three numbers are the local host address.

In a Class B network, the first two numbers are the network, the last two are the local host address.

In a Class C network, the first three numbers are the network address, the last number is the local host address.

The following table summarizes the classes and sizes:

Class	First #	Max# Hosts
A	1-126	16,387,064
B	129-191	64,516
C	192-223	254

Network mask values are used to identify the network portion and the host portion of the address. Default network masks are as follows:

Class A - 255.0.0.0

Class B - 255.255.0.0

Class C - 255.255.255.0

Subnet masking is used when a portion of the host ID is used to identify a subnetwork. For example, if a portion of a Class B network address is used for a subnetwork, the mask could be set as 255.255.255.0. This would allow the third byte to be used as a subnetwork address. All hosts on the network would still use the IP address to get on the Internet.

Internet Control Message Protocol (ICMP) - the protocol that handles errors and control messages at the IP layer. ICMP is actually a part of the IP protocol layer. It can generate error messages, test packets, and informational messages related to IP.

Internet Engineering Task Force (IETF) - a large, open, international community of network designers, operators, vendors and researchers whose purpose is to coordinate the operation, management and evolution of the Internet to resolve short- and mid-range protocol and architectural issues.

Internet Protocol (IP) - a connectionless, best-effort packet switching protocol that offers a common layer over dissimilar networks.

Internetwork Packet Exchange (IPX) Protocol - a NetWare protocol similar to the Xerox Network Systems (XNS) protocol that provides datagram delivery of messages.

Interoperability - The ability of software and hardware on multiple machines, from multiple vendors, to communicate.

Interworking Function (IWF) - provides a means for two different technologies to interoperate.

IP Address - a unique 32-bit integer used to identify a device in an IP network. You will most commonly see IP addresses written in “dot” notation (e.g., 192.228.32.14).

IP Netmask - a 32-bit pattern that is combined with an IP address to determine which bits of an IP address denote the network number and which denote the host number. Netmasks are useful for sub-dividing IP networks. IP netmasks are written in “dot” notation (e.g., 255.255.0.0).

ISA Bus - a bus standard developed by IBM for expansion cards in the first IBM PC. The original bus supported a data path only 8 bits wide. IBM subsequently developed a 16-bit version for its AT class computers. The 16-bit AT ISA bus supports both 8- and 16-bit cards. The 8-bit bus is commonly called the PC/XT bus, and the 16-bit bus is called the AT bus.

Isochronous - signals carrying embedded timing information or signals that are dependent on uniform timing; usually associated with voice and/or video transmission.

International Telecommunications Union Telecommunications (ITU-T) - an international body of member countries whose task is to define recommendations and standards relating to the international telecommunications industry. The fundamental standards for ATM have been defined and published by the ITU-T (Previously CCITT).

J2 - Wide-area digital transmission scheme used predominantly in Japan that carries data at a rate of 6.312 Mbps.

Jitter - analog communication line distortion caused by variations of a signal from its reference timing position.

Joint Photographic Experts Group (JPEG) - An ISO Standards group that defines how to compress still pictures.

Jumper - a patch cable or wire used to establish a circuit, often temporarily, for testing or diagnostics; also, the devices, shorting blocks, used to connect adjacent exposed pins on a printed circuit board that control the functionality of the card.

Kbps - kilobits per second (thousand)

LAN Access Concentrator - a LAN access device that allows a shared transmission medium to accommodate more data sources than there are channels currently available within the transmission medium.

LAN Emulation Address Resolution Protocol (LE_ARP) - A message issued by a LE client to solicit the ATM address of another function.

LAN Emulation Client (LEC) - the component in an end system that performs data forwarding, address resolution, and other control functions when communicating with other components within an ELAN.

LAN Emulation Configuration Server (LECS) - the LECS is responsible for the initial configuration of LECs. It provides information about available ELANs that a LEC may join, together with the addresses of the LES and BUS associated with each ELAN.

LAN Emulation Server (LES) - the LES implements the control coordination function for an ELAN by registering and resolving MAC addresses to ATM addresses.

LAN Emulation (LANE) - technology that allows an ATM network to function as a LAN backbone. The ATM network must provide multicast and broadcast support, address mapping (MAC-to-ATM), SVC management, and a usable packet format. LANE also defines Ethernet and Token Ring ELANs.

lane - a program that provides control over the execution of the LAN Emulation Server (LES), Broadcast/Unknown Server (BUS), and LAN Emulation Configuration Server (LECS) on the local host.

Latency - The time interval between a network station seeking access to a transmission channel and that access being granted or received.

Layer Entity - an active layer within an element.

Layer Function - a part of the activity of the layer entities.

Layer Service - a capability of a layer and the layers beneath it that is provided to the upper layer entities at the boundary between that layer and the next higher layer.

Layer User Data - the information transferred between corresponding entities on behalf of the upper layer or layer management entities for which they are providing services.

le - a FORE program that implements both the LAN Emulation Server (LES) and the Broadcast/Unknown Server (BUS).

Leaky Bucket - informal cell policing term for the Generic Cell Rate Algorithm which in effect receives cells into a bucket and leaks them out at the specified or contracted rate (i.e., PCR).

Least Significant Bit (LSB) - lowest order bit in the binary representation of a numerical value.

lecs - a FORE program that implements the assignment of individual LECs to different emulated LANs.

leq - a FORE program that provides information about an ELAN. This information is obtained from the LES, and includes MAC addresses registered on the ELAN together with their corresponding ATM addresses.

Line Build Out (LBO) - Because T1 circuits require the last span to lose 15-22.5 dB, a selectable output attenuation is generally required of DTE equipment (typical selections include 0.0, 7.5 and 15 dB of loss at 772 KHz).

Line Code Violations (LCV) - Error Event. A Line Coding Violation (LCV) is the occurrence of either a Bipolar Violation (BPV) or Excessive Zeroes (EXZ) Error Event.

Link - An entity that defines a topological relationship (including available transport capacity) between two nodes in different subnetworks. Multiple links may exist between a pair of subnetworks. Synonymous with logical link.

Link Access Procedure, Balanced (LAPB) - Data link protocol in the X.25 protocol stack. LAPB is a bit-oriented protocol derived from HDLC. See also HDLC and X.25.

Link Down Trap - an SNMP trap, sent when an interface changes from a normal state to an error state, or is disconnected.

Link Layer - layer in the OSI model regarding transmission of data between network nodes.

Link Up Trap - an SNMP trap, sent when an interface changes from an error condition to a normal state.

Load Sharing - Two or more computers in a system that share the load during peak hours. During periods of non peak hours, one computer can manage the entire load with the other acting as a backup.

Local Access and Transport Area (LATA) - Geographic boundaries of the local telephone network, specified by the FCC, in which a single LEC may perform its operations. Communications outside or between LATAs are provided by IXC's.

Local Area Network (LAN) - a data network intended to serve an area of only a few square kilometers or less. Because the network is known to cover only a small area, optimizations can be made in the network signal protocols that permit higher data rates.

Logical Link Control (LLC) - protocol developed by the IEEE 802 committee for data-link-layer transmission control; the upper sublayer of the IEEE Layer 2 (OSI) protocol that complements the MAC protocol; IEEE standard 802.2; includes end-system addressing and error checking.

Loopback - a troubleshooting technique that returns a transmitted signal to its source so that the signal can be analyzed for errors. Typically, a loopback is set at various points in a line until the section of the line that is causing the problem is discovered.

looptest - program that tests an interface for basic cell reception and transmission functionality, usually used for diagnostic purposes to determine if an interface is functioning properly.

Loss Of Frame (LOF) - a type of transmission error that may occur in wide-area carrier lines.

Loss Of Pointer (LOP) - a type of transmission error that may occur in wide-area carrier lines.

Loss Of Signal (LOS) - a type of transmission error that may occur in wide-area carrier lines, or a condition declared when the DTE senses a loss of a DS1 signal from the CPE for more the 150 milliseconds (the DTE generally responds with an all ones "Blue or AIS" signal).

Management Information Base (MIB) - the set of parameters that an SNMP management station can query or set in the SNMP agent of a networked device (e.g., router).

Maximum Burst Size (MBS) - the Burst Tolerance (BT) is conveyed through the MBS which is coded as a number of cells. The BT together with the SCR and the GCRA determine the MBS that may be transmitted at the peak rate and still be in conformance with the GCRA.

Maximum Burst Tolerance - the largest burst of data that a network device is guaranteed to handle without discarding cells or packets. Bursts of data larger than the maximum burst size may be subject to discard.

Maximum Cell Delay Variance (MCDV) - This is the maximum two-point CDV objective across a link or node for the specified service category.

Maximum Cell Loss Ratio (MCLR) - This is the maximum ratio of the number of cells that do not make it across the link or node to the total number of cells arriving at the link or node.

Maximum Cell Transfer Delay (MCTD) - This is the sum of the fixed delay component across the link or node and MCDV.

Maximum Transmission Unit (MTU) - the largest unit of data that can be sent over a type of physical medium.

Mbps - megabits per second (million)

Media Access Control (MAC) - a media-specific access control protocol within IEEE 802 specifications; currently includes variations for Token Ring, token bus, and CSMA/CD; the lower sublayer of the IEEE's link layer (OSI), which complements the Logical Link Control (LLC).

Media Attachment Unit (MAU) - device used in Ethernet and IEEE 802.3 networks that provides the interface between the AUI port of a station and the common medium of the Ethernet. The MAU, which can be built into a station or can be a separate device, performs physical layer functions including conversion of the digital data from the Ethernet interface, collision detection, and injection of bits onto the network.

- Media Interface Connector (MIC)** - fiber optic connector that joins fiber to the FDDI controller.
- Message Identifier (MID)** - message identifier used to associate ATM cells that carry segments from the same higher layer packet.
- Metasignalling** - an ATM Layer Management (LM) process that manages different types of signalling and possibly semipermanent virtual channels (VCs), including the assignment, removal, and checking of VCs.
- Metasignalling VCs** - the standardized VCs that convey metasignalling information across a User-to-Network Interface (UNI).
- Metropolitan Area Network (MAN)** - network designed to carry data over an area larger than a campus such as an entire city and its outlying area.
- MicroChannel** - a proprietary 16- or 32-bit bus developed by IBM for its PS/2 computers' internal expansion cards; also offered by others.
- Minimum Cell Rate (MCR)** - parameter defined by the ATM Forum for ATM traffic management, defined only for ABR transmissions and specifying the minimum value for the ACR.
- Most Significant Bit (MSB)** - highest order bit in the binary representation of a numerical value.
- Motion Picture Experts Group (MPEG)** - ISO group dealing with video and audio compression techniques and mechanisms for multiplexing and synchronizing various media streams.
- MPOA Client** - A device which implements the client side of one or more of the MPOA protocols, (i.e., is a SCP client and/or an RDP client. An MPOA Client is either an Edge Device Functional Group (EDFG) or a Host Behavior Functional Group (HBFG).
- MPOA Server** - An MPOA Server is any one of an ICFG or RSFG.
- MPOA Service Area** - The collection of server functions and their clients. A collection of physical devices consisting of an MPOA server plus the set of clients served by that server.
- MPOA Target** - A set of protocol address, path attributes, (e.g., internetwork layer QoS, other information derivable from received packet) describing the intended destination and its path attributes that MPOA devices may use as lookup keys.
- Mu-Law** - The PCM coding and companding standard used in Japan and North America.
- Multicasting** - The ability to broadcast messages to one node or a select group of nodes.
- Multi-homed** - a device having both an ATM and another network connection, like Ethernet.
- Multimode Fiber Optic Cable (MMF)** - fiber optic cable in which the signal or light propagates in multiple modes or paths. Since these paths may have varying lengths, a transmitted pulse of light may be received at different times and smeared to the point that pulses may interfere with surrounding pulses. This may cause the signal to be difficult or impossible to receive. This pulse dispersion sometimes limits the distance over which a MMF link can operate.
- Multiplexing** - a function within a layer that interleaves the information from multiple connections into one connection (see demultiplexing).

Multipoint Access - user access in which more than one terminal equipment (TE) is supported by a single network termination.

Multipoint-to-Multipoint Connection - a collection of associated ATM VC or VP links, and their associated endpoint nodes, with the following properties:

1. All N nodes in the connection, called Endpoints, serve as a Root Node in a Point-to-Multipoint connection to all of the (N-1) remaining endpoints.
2. Each of the endpoints can send information directly to any other endpoint, but the receiving endpoint cannot distinguish which of the endpoints is sending information without additional (e.g., higher layer) information.

Multipoint-to-Point Connection - a Point-to-Multipoint Connection may have zero bandwidth from the Root Node to the Leaf Nodes, and non-zero return bandwidth from the Leaf Nodes to the Root Node. Such a connection is also known as a Multipoint-to-Point Connection.

Multiprotocol over ATM (MPOA) - An effort taking place in the ATM Forum to standardize protocols for the purpose of running multiple network layer protocols over ATM.

Narrowband Channel - sub-voicegrade channel with a speed range of 100 to 200 bps.

National TV Standards Committee (NTSC) - Started in the US in 1953 from a specification laid down by the National Television Standards Committee. It takes the B-Y and R-Y color difference signals, attenuates them to I and Q, then modulates them using double-sideband suppressed subcarrier at 3.58MHz. The carrier reference is sent to the receiver as a burst during the back porch. An industry group that defines how television signals are encoded and transmitted in the US. (See also PAL, SECAM for non-U.S. countries).

Near-End - in a relationship between two devices in a circuit, the near-end device is the one that is local.

Network Layer - Layer three In the OSI model, the layer that is responsible for routing data across the network.

Network Management Entity (NM) - body of software in a switching system that provides the ability to manage the PNNI protocol. NM interacts with the PNNI protocol through the MIB.

Network Management Layer (NML) - an abstraction of the functions provided by systems which manage network elements on a collective basis, providing end-to-end network monitoring.

Network Management Station (NMS) - system responsible for managing a network or portion of a network by talking to network management agents, which reside in the managed nodes.

Network Module - ATM port interface cards which may be individually added to or removed from any *ForeRunner* ATM switch to provide a diverse choice of connection alternatives.

Network Parameter Control (NPC) - Defined as the set of actions taken by the network to monitor and control traffic from the NNI. Its main purpose is to protect network resources from malicious as well as unintentional misbehavior which can affect the QoS of other already established connections by detecting violations of negotiated parameters and taking appropriate actions. Refer to UPC.

Network Redundancy - Duplicated network equipment and/or data which can provide a backup in case of network failures.

Network Service Access Point (NSAP) - OSI generic standard for a network address consisting of 20 octets. ATM has specified E.164 for public network addressing and the NSAP address structure for private network addresses.

Network-to-Network Interface or Network Node Interface (NNI) - the interface between two public network pieces of equipment.

Node - A computer or other device when considered as part of a network.

Non Return to Zero (NRZ) - a binary encoding scheme in which ones and zeroes are represented by opposite and alternating high and low voltages and where there is no return to a zero (reference) voltage between encoded bits.

Non Return to Zero Inverted (NRZI) - A binary encoding scheme that inverts the signal on a “1” and leaves the signal unchanged for a “0”. (Also called transition encoding.)

Nonvolatile Storage - Memory storage that does not lose its contents when power is turned off.

NuBus - a high-speed bus used in Macintosh computers, structured so users can put a card into any slot on the board without creating conflict over the priority between those cards.

nx64K - This refers to a circuit bandwidth or speed provided by the aggregation of nx64 kbps channels (where n= integer > 1). The 64K or DS0 channel is the basic rate provided by the T Carrier systems.

Nyquist Theorem - In communications theory, a formula stating that two samples per cycle is sufficient to characterize a bandwidth limited analog signal; in other words, the sampling rate must be twice the highest frequency component of the signal (i.e., sample 4 KHz analog voice channels 8000 times per second).

Object Identifier (OID) - the address of a MIB variable.

Octet - a grouping of 8 bits; similar, but not identical to, a byte.

One's Density - The requirement for digital transmission lines in the public switched telephone network that eight consecutive “0”s cannot be in a digital data stream; exists because repeaters and clocking devices within the network will lose timing after receiving eight “0”s in a row; a number of techniques are used to insert a “1” after every seventh-consecutive “0” (see Bit Stuffing).

Open Shortest Path First (OSPF) Protocol - a routing algorithm for IP that incorporates least-cost, equal-cost, and load balancing.

Open Systems Interconnection (OSI) - the 7-layer suite of protocols designed by ISO committees to be the international standard computer network architecture.

OpenView - Hewlett-Packard's network management software.

Operation and Maintenance (OAM) Cell - a cell that contains ATM LM information. It does not form part of the upper layer information transfer.

Optical Carrier level-n (OC-n) - The optical counterpart of STS-n (the basic rate of 51.84 Mbps on which SONET is based is referred to as OC-1 or STS-1).

Organizationally Unique Identifier (OUI) - Part of RFC 1483. A three-octet field in the SubNetwork Attachment Point (SNAP) header, identifying an organization which administers the meaning of the following two octet Protocol Identifier (PID) field in the SNAP header. Together they identify a distinct routed or bridged protocol.

Out-of-Band Management - refers to switch configuration via the serial port or over Ethernet, not ATM.

Out-of-Frame (OOF) - a signal condition and alarm in which some or all framing bits are lost.

Packet - An arbitrary collection of data grouped and transmitted with its user identification over a shared facility.

Packet Assembler Disassembler (PAD) - interface device that buffers data sent to/from character mode devices, and assembles and disassembles the packets needed for X.25 operation.

Packet Internet Groper (ping) - a program used to test reachability of destinations by sending them an ICMP echo request and waiting for a reply.

Packet Level Protocol (PLP) - Network layer protocol in the X.25 protocol stack. Sometimes called X.25 Level 3 or X.25 Protocol.

Packet Switched Network (PSN) - a network designed to carry data in the form of packets. The packet and its format is internal to that network.

Packet Switching - a communications paradigm in which packets (messages) are individually routed between hosts with no previously established communications path.

Payload Scrambling - a technique that eliminates certain bit patterns that may occur within an ATM cell payload that could be misinterpreted by certain sensitive transmission equipment as an alarm condition.

Payload Type (PT) - bits 2...4 in the fourth byte of an ATM cell header. The PT indicates the type of information carried by the cell. At this time, values 0...3 are used to identify various types of user data, values 4 and 5 indicate management information, and values 6 and 7 are reserved for future use.

Peak Cell Rate - at the PHY Layer SAP of a point-to-point VCC, the Peak Cell Rate is the inverse of the minimum inter-arrival time T0 of the request to send an ATM-SDU.

Peak Cell Rate (PCR) - parameter defined by the ATM Forum for ATM traffic management. In CBR transmissions, PCR determines how often data samples are sent. In ABR transmissions, PCR determines the maximum value of the ACR.

Peer Entities - entities within the same layer.

Peripheral Component Interconnect (PCI) - a local-bus standard created by Intel.

Permanent Virtual Channel Connection (PVCC) - A Virtual Channel Connection (VCC) is an ATM connection where switching is performed on the VPI/VCI fields of each cell. A Permanent VCC is one which is provisioned through some network management function and left up indefinitely.

Permanent Virtual Circuit (or Channel) (PVC) - a circuit or channel through an ATM network provisioned by a carrier between two endpoints; used for dedicated long-term information transport between locations.

Permanent Virtual Path Connection (PVPC) - A Virtual Path Connection (VPC) is an ATM connection where switching is performed on the VPI field only of each cell. A PVPC is one which is provisioned through some network management function and left up indefinitely.

Phase Alternate Line (PAL) - Largely a German/British development in the late 60s, used in the UK and much of Europe. The B-Y and R-Y signals are weighted to U and V, then modulated onto a double-sideband suppressed subcarrier at 4.43MHz. The V (R-Y) signal's phase is turned through 180 degrees on each alternate line. This gets rid of NTSC's hue changes with phase errors at the expense of de-saturation. The carrier reference is sent as a burst in the back porch. The phase of the burst is alternated every line to convey the phase switching of the V signal. The burst's average phase is -V. (see NTSC for U.S.).

Physical Layer (PHY) - the actual cards, wires, and /or fiber-optic cabling used to connect computers, routers, and switches.

Physical Layer Connection - an association established by the PHY between two or more ATM-entities. A PHY connection consists of the concatenation of PHY links in order to provide an end-to-end transfer capability to PHY SAPs.

Physical Layer Convergence Protocol (PLCP) - a framing protocol that runs on top of the T1 or E1 framing protocol.

Physical Medium (PM) - Refers to the actual physical interfaces. Several interfaces are defined including STS-1, STS-3c, STS-12c, STM-1, STM-4, DS1, E1, DS2, E3, DS3, E4, FDDI-based, Fiber Channel-based, and STP. These range in speeds from 1.544Mbps through 622.08 Mbps.

Physical Medium Dependent (PMD) - a sublayer concerned with the bit transfer between two network nodes. It deals with wave shapes, timing recovery, line coding, and electro-optic conversions for fiber based links.

Plesiochronous - two signals are plesiochronous if their corresponding significant instants occur at nominally the same rate, with variations in rate constrained to specified limits.

Point of Demarcation - the dividing line between a carrier and the customer premise that is governed by strict standards that define the characteristics of the equipment on each side of the demarcation. Equipment on one side of the point of demarcation is the responsibility of the customer. Equipment on the other side of the point of demarcation is the responsibility of the carrier.

Point-to-Multipoint Connection - a collection of associated ATM VC or VP links, with associated endpoint nodes, with the following properties:

1. One ATM link, called the Root Link, serves as the root in a simple tree topology. When the Root node sends information, all of the remaining nodes on the connection, called Leaf nodes, receive copies of the information.
2. Each of the Leaf Nodes on the connection can send information directly to the Root Node. The Root Node cannot distinguish which Leaf is sending information without additional (higher layer) information. (See the following note for Phase 1.)
3. The Leaf Nodes cannot communicate directly to each other with this connection type.

Note: Phase 1 signalling does not support traffic sent from a Leaf to the Root.

Point-to-Point Connection - a connection with only two endpoints.

Point-to-Point Protocol (PPP) - Provides a method for transmitting packets over serial point-to-point links.

Policing - the function that ensures that a network device does not accept traffic that exceeds the configured bandwidth of a connection.

Port Identifier - The identifier assigned by a logical node to represent the point of attachment of a link to that node.

Presentation Layer - Sixth layer of the OSI model, providing services to the application layer.

Primary Reference Source (PRS) - Equipment that provides a timing signal whose long-term accuracy is maintained at 1×10^{-11} or better with verification to universal coordinated time (UTC) and whose timing signal is used as the basis of reference for the control of other clocks within a network.

Primitive - an abstract, implementation-independent interaction between a layer service user and a layer service provider.

Priority - the parameter of ATM connections that determines the order in which they are reduced from the peak cell rate to the sustained cell rate in times of congestion. Connections with lower priority (4 is low, 1 is high) are reduced first.

Private Branch Exchange (PBX) - a private phone system (switch) that connects to the public telephone network and offers in-house connectivity. To reach an outside line, the user must dial a digit like 8 or 9.

Private Network Node Interface or Private Network-to-Network Interface (PNNI) - a protocol that defines the interaction of private ATM switches or groups of private ATM switches

Programmable Read-Only Memory (PROM) - a chip-based information storage area that can be recorded by an operator but erased only through a physical process.

Protocol - a set of rules and formats (semantic and syntactic) that determines the communication behavior of layer entities in the performance of the layer functions.

Protocol Control Information - the information exchanged between corresponding entities using a lower layer connection to coordinate their joint operation.

Protocol Data Unit (PDU) - a unit of data specified in a layer protocol and consisting of protocol control information and layer user data.

Proxy - the process in which one system acts for another system to answer protocol requests.

Proxy Agent - an agent that queries on behalf of the manager, used to monitor objects that are not directly manageable.

Public Data Network (PDN) - a network designed primarily for data transmission and intended for sharing by many users from many organizations.

Pulse Code Modulation (PCM) - a modulation scheme that samples the information signals and transmits a series of coded pulses to represent the data.

Q.2931 - Derived from Q.93B, the narrowband ISDN signalling protocol, an ITU standard describing the signalling protocol to be used by switched virtual circuits on ATM LANs.

Quality of Service (QoS) - Quality of Service is defined on an end-to-end basis in terms of the following attributes of the end-to-end ATM connection:

- Cell Loss Ratio

- Cell Transfer Delay

- Cell Delay Variation

Queuing Delay (QD) - refers to the delay imposed on a cell by its having to be buffered because of unavailability of resources to pass the cell onto the next network function or element. This buffering could be a result of oversubscription of a physical link, or due to a connection of higher priority or tighter service constraints getting the resource of the physical link.

Radio Frequency Interference (RFI) - the unintentional transmission of radio signals. Computer equipment and wiring can both generate and receive RFI.

Real-Time Clock - a clock that maintains the time of day, in contrast to a clock that is used to time the electrical pulses on a circuit.

Red Alarm - In T1, a red alarm is generated for a locally detected failure such as when a condition like OOF exists for 2.5 seconds, causing a CGA, (Carrier Group Alarm).

Reduced Instruction Set Computer (RISC) - a generic name for CPUs that use a simpler instruction set than more traditional designs.

Redundancy - In a data transmission, the fragments of characters and bits that can be eliminated with no loss of information.

Registration - The address registration function is the mechanism by which Clients provide address information to the LAN Emulation Server.

Relaying - a function of a layer by means of which a layer entity receives data from a corresponding entity and transmits it to another corresponding entity.

Request To Send (RTS) - an RS-232 modem interface signal (sent from the DTE to the modem on pin 4) which indicates that the DTE has data to transmit.

Requests For Comment (RFCs) - IETF documents suggesting protocols and policies of the Internet, inviting comments as to the quality and validity of those policies. These comments are collected and analyzed by the IETF in order to finalize Internet standards.

RFC1483 - Multiprotocol Encapsulation over ATM Adaptation Layer 5.

RFC1490 - Multiprotocol Interconnect over Frame Relay.

RFC1577 - Classical IP and ARP over ATM.

RFC1755 - ATM Signaling Support for IP over ATM.

Robbed-Bit Signaling - In T1, refers to the use of the least significant bit of every word of frames 6 and 12 (D4), or 6, 12, 18, and 24 (ESF) for signaling purposes.

Route Server - A physical device that runs one or more network layer routing protocols, and which uses a route query protocol in order to provide network layer routing forwarding descriptions to clients.

Router - a device that forwards traffic between networks or subnetworks based on network layer information.

Routing Domain (RD) - A group of topologically contiguous systems which are running one instance of routing.

Routing Information Protocol (RIP) - a distance vector-based protocol that provides a measure of distance, or hops, from a transmitting workstation to a receiving workstation.

Routing Protocol - A general term indicating a protocol run between routers and/or route servers in order to exchange information used to allow computation of routes. The result of the routing computation will be one or more forwarding descriptions.

SBus - hardware interface for add-in boards in later-version Sun 3 workstations.

Scalable Processor Architecture Reduced instruction set Computer (SPARC) - a powerful workstation similar to a reduced-instruction-set-computing (RISC) workstation.

Segment - a single ATM link or group of interconnected ATM links of an ATM connection.

Segmentation And Reassembly (SAR) - the SAR accepts PDUs from the CS and divides them into very small segments (44 bytes long). If the CS-PDU is less than 44 bytes, it is padded to 44 with zeroes. A two-byte header and trailer are added to this basic segment. The header identifies the message type (beginning, end, continuation, or single) and contains sequence numbering and message identification. The trailer gives the SAR-PDU payload length, exclusive of pad, and contains a CRC check to ensure the SAR-PDU integrity. The result is a 48-byte PDU that fits into the payload field of an ATM cell.

Selector (SEL) - A subfield carried in SETUP message part of ATM endpoint address Domain specific Part (DSP) defined by ISO 10589, not used for ATM network routing, used by ATM end systems only.

Semipermanent Connection - a connection established via a service order or via network management.

Serial Line IP (SLIP) - A protocol used to run IP over serial lines, such as telephone circuits or RS-232 cables, interconnecting two systems.

Service Access Point (SAP) - the point at which an entity of a layer provides services to its LM entity or to an entity of the next higher layer.

Service Data Unit (SDU) - a unit of interface information whose identity is preserved from one end of a layer connection to the other.

Service Specific Connection Oriented Protocol (SSCOP) - an adaptation layer protocol defined in ITU-T Specification: Q.2110.

Service Specific Convergence Sublayer (SSCS) - The portion of the convergence sublayer that is dependent upon the type of traffic that is being converted.

Session Layer - Layer 5 in the OSI model that is responsible for establishing and managing sessions between the application programs running in different nodes.

Severely Errored Seconds (SES) - a second during which more event errors have occurred than the SES threshold (normally 10-3).

Shaping Descriptor - n ordered pairs of GCRA parameters (I,L) used to define the negotiated traffic shape of an APP connection. The traffic shape refers to the load-balancing of a network, where load-balancing means configuring data flows to maximize network efficiency.

Shielded Pair - Two insulated wires in a cable wrapped with metallic braid or foil to prevent interference and provide noise free transmission.

Shielded Twisted Pair (STP) - two or more insulated wires, twisted together and then wrapped in a cable with metallic braid or foil to prevent interference and offer noise-free transmissions.

Signaling System No. 7 (SS7) - The SS7 protocol has been specified by ITU-T and is a protocol for interexchange signaling.

Simple and Efficient Adaptation Layer (SEAL) - also called AAL 5, this ATM adaptation layer assumes that higher layer processes will provide error recovery, thereby simplifying the SAR portion of the adaptation layer. Using this AAL type packs all 48 bytes of an ATM cell information field with data. It also assumes that only one message is crossing the UNI at a time. That is, multiple end-users at one location cannot interleave messages on the same VC, but must queue them for sequential transmission.

Simple Gateway Management Protocol (SGMP) - the predecessor to SNMP.

Simple Mail Transfer Protocol (SMTP) - the Internet electronic mail protocol used to transfer electronic mail between hosts.

Simple Network Management Protocol (SNMP) - the Internet standard protocol for managing nodes on an IP network.

Simple Protocol for ATM Network Signalling (SPANS) - FORE Systems' proprietary signalling protocol used for establishing SVCs between FORE Systems equipment.

Single Mode Fiber (SMF) - Fiber optic cable in which the signal or light propagates in a single mode or path. Since all light follows the same path or travels the same distance, a transmitted pulse is not dispersed and does not interfere with adjacent pulses. SMF fibers can support longer distances and are limited mainly by the amount of attenuation. Refer to MMF.

Small Computer Systems Interface (SCSI) - a standard for a controller bus that connects hardware devices to their controllers on a computer bus, typically used in small systems.

Smart PVC (SPVC) - a generic term for any communications medium which is permanently provisioned at the end points, but switched in the middle. In ATM, there are two kinds of SPVCs: smart permanent virtual path connections (SPVPCs) and smart permanent virtual channel connections (SPVCCs).

snmpd - an SNMP agent for a given adapter card.

Source - Part of communications system which transmits information.

Source Address (SA) - The address from which the message or data originated.

Source MAC Address (SA) - A six octet value uniquely identifying an end point and which is sent in an IEEE LAN frame header to indicate source of frame.

Source Traffic Descriptor - a set of traffic parameters belonging to the ATM Traffic Descriptor used during the connection set-up to capture the intrinsic traffic characteristics of the connection requested by the source.

Spanning Tree Protocol - provides loop-free topology in a network environment where there are redundant paths.

Static Route - a route that is entered manually into the routing table.

Statistical Multiplexing - a technique for allowing multiple channels and paths to share the same link, typified by the ability to give the bandwidth of a temporarily idle channel to another channel.

Stick and Click (SC) - Designation for an Optical Connector featuring a 2.5 mm physically contacting ferrule with a push-pull mating design. Commonly referred to as Structured Cabling, Structured Connectors or Stick and Click

Stick and Turn (ST) - A fiber-optic connector designed by AT&T which uses the bayonet style coupling rather than screw-on as the SMA uses. The ST is generally considered the eventual replacement for the SMA type connector.

Store-and-Forward - the technique of receiving a message, storing it until the proper outgoing line is available, then retransmitting it, with no direct connection between incoming and outgoing lines.

Straight Tip (ST) - see *Stick and Turn*.

Structured Cabling (SC) - see *Stick and Click*.

Structured Connectors (SC) - see *Stick and Click*.

Sublayer - a logical subdivision of a layer.

SubNetwork Access Protocol (SNAP) - a specially reserved variant of IEEE 802.2 encoding SNAP indicates to look further into the packet where it will find a Type field.

Subscriber Network Interface (SNI) - the interface between an SMDS end user's CPE and the network directly serving the end user, supported by either a DS1 or DS3 access arrangement.

Super Frame (SF) - a term used to describe the repeating 12 D4 frame format that composes a standard (non-ESF) T1 service.

Super User - a login ID that allows unlimited access to the full range of a device's functionality, including especially the ability to reconfigure the device and set passwords.

Sustainable Cell Rate (SCR) - ATM Forum parameter defined for traffic management. For VBR connections, SCR determines the long-term average cell rate that can be transmitted.

Sustained Information Rate (SIR) - In ATM this refers to the long-term average data transmission rate across the User-to-Network Interface. In SMDS this refers to the committed information rate (similar to CIR for Frame Relay Service).

Switch - Equipment used to interconnect lines and trunks.

Switched Connection - A connection established via signaling.

Switched Multimegabit Data Service (SMDS) - a high-speed, datagram-based, public data network service expected to be widely used by telephone companies in their data networks.

Switched Virtual Channel Connection (SVCC) - A Switched VCC is one which is established and taken down dynamically through control signaling. A Virtual Channel Connection (VCC) is an ATM connection where switching is performed on the VPI/VCI fields of each cell.

Switched Virtual Circuit (or Channel) (SVC) - a channel established on demand by network signalling, used for information transport between two locations and lasting only for the duration of the transfer; the datacom equivalent of a dialed telephone call.

Switched Virtual Path Connection (SVPC) - a connection which is established and taken down dynamically through control signaling. A Virtual Path Connection (VPC) is an ATM connection where switching is performed on the VPI field only of each cell.

Switching System - A set of one or more systems that act together and appear as a single switch for the purposes of PNNI routing.

Symmetric Connection - a connection with the same bandwidth specified for both directions.

Synchronous - signals that are sourced from the same timing reference and hence are identical in frequency.

Synchronous Data Link Control (SDLC) - IBM's data link protocol used in SNA networks.

Synchronous Optical Network (SONET) - a body of standards that defines all aspects of transporting and managing digital traffic over optical facilities in the public network.

Synchronous Payload Envelope (SPE) - the payload field plus a little overhead of a basic SONET signal.

Synchronous Transfer Mode (STM) - a transport and switching method that depends on information occurring in regular, fixed patterns with respect to a reference such as a frame pattern.

Synchronous Transport Signal (STS) - a SONET electrical signal rate.

Système En Couleur Avec Mémoire (SECAM) - Sequential and Memory Color Television - Started in France in the late 60s, and used by other countries with a political affiliation. This is. The B-Y and R-Y signals are transmitted on alternate lines modulated on an FM subcarrier. The memory is a one line delay line in the receiver to make both color difference signals available at the same time on all lines. Due to FM, the signal is robust in difficult terrain.

Systems Network Architecture (SNA) - a proprietary networking architecture used by IBM and IBM-compatible mainframe computers.

T1 - a specification for a transmission line. The specification details the input and output characteristics and the bandwidth. T1 lines run at 1.544 Mbps and provide for 24 data channels. In common usage, the term “T1” is used interchangeably with “DS1.”

T1 Link - A wideband digital carrier facility used for transmission of digitized voice, digital data, and digitized image traffic. This link is composed of two twisted-wire pairs that can carry 24 digital channels, each operating at 64K bps at the aggregate rate of 1.544M bps, full duplex. Also referred to as DS-1.

T3 - a specification for a transmission line, the equivalent of 28 T1 lines. T3 lines run at 44.736 Mbps. In common usage, the term “T3” is used interchangeably with “DS3.”

Tachometer - in *ForeView*, the tachometer shows the level of activity on a given port. The number in the tachometer shows the value of a chosen parameter in percentage, with a colored bar providing a semi-logarithmic representation of that percentage.

Tagged Cell Rate (TCR) - An ABR service parameter, TCR limits the rate at which a source may send out-of-rate forward RM-cells. TCR is a constant fixed at 10 cells/second.

Telephony - The conversion of voices and other sounds into electrical signals which are then transmitted by telecommunications media.

Telnet - a TCP/IP protocol that defines a client/server mechanism for emulating directly-connected terminal connections.

Terminal Equipment (TE) - Terminal equipment represents the endpoint of ATM connection(s) and termination of the various protocols within the connection(s).

Throughput - Measurement of the total useful information processed or communicated by a computer during a specified time period, i.e. packets per second.

Time Division Multiplexing (TDM) - a method of traditional digital multiplexing in which a signal occupies a fixed, repetitive time slot within a higher-rate signal.

Token Ring - a network access method in which the stations circulate a token. Stations with data to send must have the token to transmit their data.

topology - a program that displays the topology of a FORE Systems ATM network. An updated topology can be periodically re-displayed by use of the interval command option.

Traffic - the calls being sent and received over a communications network. Also, the packets that are sent on a data network.

Traffic Management (TM) - The traffic control and congestion control procedures for ATM. ATM layer traffic control refers to the set of actions taken by the network to avoid congestion conditions. ATM layer congestion control refers to the set of actions taken by the network to minimize the intensity, spread and duration of congestion. The following functions form a framework for managing and controlling traffic and congestion in ATM networks and may be used in appropriate combinations:

- Connection Admission Control
- Feedback Control
- Usage Parameter Control
- Priority Control
- Traffic Shaping
- Network Resource Management
- Frame Discard
- ABR Flow Control

Traffic Parameter - A parameter for specifying a particular traffic aspect of a connection.

Trailer - the protocol control information located at the end of a PDU.

Transit Delay - the time difference between the instant at which the first bit of a PDU crosses one designated boundary, and the instant at which the last bit of the same PDU crosses a second designated boundary.

Transmission Control Protocol (TCP) - a specification for software that bundles and unbundles sent and received data into packets, manages the transmission of packets on a network, and checks for errors.

Transmission Control Protocol/Internet Protocol (TCP/IP) - a set of communications protocols that has evolved since the late 1970s, when it was first developed by the Department of Defense. Because programs supporting these protocols are available on so many different computer systems, they have become an excellent way to connect different types of computers over networks.

Transmission Convergence (TC) - generates and receives transmission frames and is responsible for all overhead associated with the transmission frame. The TC sublayer packages cells into the transmission frame.

Transmission Convergence Sublayer (TCS) - This is part of the ATM physical layer that defines how cells will be transmitted by the actual physical layer.

Transparent Asynchronous Transmitter/Receiver Interface (TAXI) - Encoding scheme used for FDDI LANs as well as for ATM; supports speed typical of 100 Mbps over multimode fiber.

Transport Layer - Layer Four of the OSI reference model that is responsible for maintaining reliable end-to-end communications across the network.

trap - a program interrupt mechanism that automatically updates the state of the network to remote network management hosts. The SNMP agent on the switch supports these SNMP traps.

Trivial File Transfer Protocol (TFTP) - Part of IP, a simplified version of FTP that allows files to be transferred from one computer to another over a network.

Twisted Pair - Insulated wire in which pairs are twisted together. Commonly used for telephone connections, and LANs because it is inexpensive.

Unassigned Cells - a generated cell identified by a standardized virtual path identifier (VPI) and virtual channel identifier (VCI) value, which does not carry information from an application using the ATM Layer service.

Unavailable Seconds (UAS) - a measurement of signal quality. Unavailable seconds start accruing when ten consecutive severely errored seconds occur.

UNI 3.0/3.1 - the User-to-Network Interface standard set forth by the ATM Forum that defines how private customer premise equipment interacts with private ATM switches.

Unicasting - The transmit operation of a single PDU by a source interface where the PDU reaches a single destination.

Universal Test & Operations Interface for ATM (UTOPIA) - Refers to an electrical interface between the TC and PMD sublayers of the PHY layer.

Unshielded Twisted Pair (UTP) - a cable that consists of two or more insulated conductors in which each pair of conductors are twisted around each other. There is no external protection and noise resistance comes solely from the twists.

Unspecified Bit Rate (UBR) - a type of traffic that is not considered time-critical (e.g., ARP messages, pure data), allocated whatever bandwidth is available at any given time. UBR traffic is given a “best effort” priority in an ATM network with no guarantee of successful transmission.

Uplink - Represents the connectivity from a border node to an upnode.

Usage Parameter Control (UPC) - mechanism that ensures that traffic on a given connection does not exceed the contracted bandwidth of the connection, responsible for policing or enforcement. UPC is sometimes confused with congestion management (see *congestion management*).

User Datagram Protocol (UDP) - the TCP/IP transaction protocol used for applications such as remote network management and name-service access; this lets users assign a name, such as “RVAX*2,S,” to a physical or numbered address.

User-to-Network Interface (UNI) - the physical and electrical demarcation point between the user and the public network service provider.

V.35 - ITU-T standard describing a synchronous, physical layer protocol used for communications between a network access device and a packet network. V.35 is most commonly used in the United States and Europe, and is recommended for speeds up to 48 Kbps.

Variable Bit Rate (VBR) - a type of traffic that, when sent over a network, is tolerant of delays and changes in the amount of bandwidth it is allocated (e.g., data applications).

Virtual Channel (or Circuit) (VC) - a communications path between two nodes identified by label rather than fixed physical path.

Virtual Channel Connection (VCC) - a unidirectional concatenation of VCLs that extends between the points where the ATM service users access the ATM Layer. The points at which the ATM cell payload is passed to, or received from, the users of the ATM Layer (i.e., a higher layer or ATM entity) for processing signify the endpoints of a VCC.

Virtual Channel Identifier (VCI) - the address or label of a VC; a value stored in a field in the ATM cell header that identifies an individual virtual channel to which the cell belongs. VCI values may be different for each data link hop of an ATM virtual connection.

Virtual Channel Link (VCL) - a means of unidirectional transport of ATM cells between the point where a VCI value is assigned and the point where that value is translated or removed.

Virtual Channel Switch - a network element that connects VCLs. It terminates VPCs and translates VCI values. The Virtual Channel Switch is directed by Control Plane functions and relays the cells of a VC.

Virtual Connection - an endpoint-to-endpoint connection in an ATM network. A virtual connection can be either a virtual path or a virtual channel.

Virtual Local Area Network (VLAN) - Work stations connected to an intelligent device which provides the capabilities to define LAN membership.

Virtual Network Software (VINES) - Banyan's network operating system based on UNIX and its protocols.

Virtual Path (VP) - a unidirectional logical association or bundle of VCs.

Virtual Path Connection (VPC) - a concatenation of VPLs between virtual path terminators (VPTs). VPCs are unidirectional.

Virtual Path Identifier (VPI) - the address or label of a particular VP; a value stored in a field in the ATM cell header that identifies an individual virtual path to which the cell belongs. A virtual path may comprise multiple virtual channels.

Virtual Path Link (VPL) - a means of unidirectional transport of ATM cells between the point where a VPI value is assigned and the point where that value is translated or removed.

Virtual Path Switch - a network element that connects VPLs, it translates VPI (not VCI) values and is directed by Control Plane functions. The Virtual Path Switch relays the cells of a Virtual Path.

Virtual Path Terminator (VPT) - a system that unbundles the VCs of a VP for independent processing of each VC.

Virtual Private Data Network (VPDN) - a private data communications network built on public switching and transport facilities rather than dedicated leased facilities such as T1s.

Virtual Private Network (VPN) - a private voice communications network built on public switching and transport facilities rather than dedicated leased facilities such as T1s.

Virtual Source/Virtual Destination (VS/VD) - An ABR connection may be divided into two or more separately controlled ABR segments. Each ABR control segment, except the first, is sourced by a virtual source. A virtual source implements the behavior of an ABR source endpoint. Backwards RM-cells received by a virtual source are removed from the connection. Each ABR control segment, except the last, is terminated by a virtual destination. A virtual destination assumes the behavior of an ABR destination endpoint. Forward RM-cells received by a virtual destination are turned around and not forwarded to the next segment of the connection.

Virtual Tributary (VT) - a structure used to carry payloads such as DS1s that run at significantly lower rates than STS-1s.

Warm Start Trap - an SNMP trap which indicates that SNMP alarm messages or agents have been enabled.

Wide-Area Network (WAN) - a network that covers a large geographic area.

Wideband Channel - Communications channel with more capacity (19.2K bps) than the standard capacity of a voice grade line.

X.21 - ITU-T standard for serial communications over synchronous digital lines. The X.21 protocol is used primarily in Europe and Japan.

X.25 - a well-established data switching and transport method that relies on a significant amount of processing to ensure reliable transport over metallic media.

Yellow Alarm - An alarm signal sent back toward the source of a failed signal due to the presence of an AIS (may be used by APS equipment to initiate switching).

Zero Byte Time Slot Interchange (ZBTSI) - A technique used with the T carrier extended super-frame format (ESF) in which an area in the ESF frame carries information about the location of all-zero bytes (eight consecutive "0"s) within the data stream.

Zero Code Suppression - The insertion of a "1" bit to prevent the transmission of eight or more consecutive "0" bits. Used primarily with T1 and related digital telephone company facilities, which require a minimum "1's density" in order to keep the individual subchannels of a multiplexed, high speed facility active.

Zero-Bit Insertion - A technique used to achieve transparency in bit-oriented protocols. A zero is inserted into sequences of one bits that cause false flag direction.

Index

A

- ABORT switch 1 - 5
- AC power supply
 - ASX-1000 1 - 16, 1 - 18
 - ASX-200BX 1 - 13
 - hot-swapping, ASX-1000 ... 3 - 8, 3 - 11
 - hot-swapping, ASX-200BX 3 - 4
- alarm relay contacts 1 - 24
- ASX-200 SCP
 - front panel 1 - 4
- Auto mode
 - accessing 1 - 8

C

- Common Equipment Card (CEC) 1 - 22
 - AL1 and AL2 1 - 24
 - alarm indicators 1 - 24
 - alarm LEDs 1 - 26
 - alarm relay contacts 1 - 23
 - Ethernet port 1 - 27
 - Ethernet port LEDs 1 - 27
 - front panel 1 - 22
 - front panel (model A) 1 - 22
 - front panel (model B) 1 - 23
 - model A 1 - 22
 - model B 1 - 22
 - power supply LEDs 1 - 27
 - status LEDs (model A) 1 - 25
 - status LEDs (model B) 1 - 26

- switch board LEDs 1 - 27
- control port 1 - 8

D

- DC power supply
 - ASX-1000 1 - 20
 - ASX-200BX 1 - 14
 - hot-swapping, ASX-1000 3 - 14
 - hot-swapping, ASX-200BX 3 - 6
- diagnostics
 - for an ASX-200 B - 10
 - for i960 SCPs B - 1
- diagnostics display
 - on an ASX-200 1 - 5
- display LED 1 - 6, 1 - 8
 - reading ATM Switch 1 - 8
- dual SCPs
 - adding a standby SCP 1 - 10
 - dual SCP mode 1 - 9
 - Ethernet connection 1 - 11
 - rebooting 1 - 11
 - SCP failover 1 - 9
 - SCP heartbeat 1 - 9

E

- Ethernet 10BaseT port 1 - 6, 1 - 7
- Ethernet AUI port 1 - 6
- Ethernet mode
 - accessing 1 - 8
- extended mode 3 - 2



Index

F

fan tray 1 - 21
 hot-swapping on an ASX-1000 ... 3 - 17

FLASH mode

 accessing 1 - 8

ForeRunner Hardware Specifications C - 1

H

hardware

 ASX-1000 1 - 3

 ASX-200 1 - 2

 ASX-200BX 1 - 3

 ASX-200WG 1 - 2

humidity

operating

 ASX-1000 C - 5

 ASX-200 C - 2

 ASX-200BX C - 4

 ASX-200WG C - 3

storage

 ASX-1000 C - 5

 ASX-200BX C - 4

 ASX-200WG C - 3

I

install serial cable 2 - 9

installation

 verifying 2 - 15

inventorying the unit 2 - 2

IP address

 configuring 2 - 12

M

Mini Loader upgrade

 gateway addresses 4 - 18

 setting the switch IP address 4 - 18

mixed mode 3 - 2

modem access 2 - 10

modem configuration 2 - 10

Monitor mode

 accessing 1 - 8, B - 2

multicast mode 3 - 2

N

network module specifications

 155 Mbps UTP module C - 8

 DS1 module C - 11, C - 12

 DS3 module C - 21

 E1 module C - 14

 E3 module C - 20

 J2 module C - 16

 OC-12c multimode module C - 10

 OC-12c single mode module C - 25

 OC-3c mixed mode module C - 23

 OC-3c multimode module C - 7

 OC-3c single mode module C - 22

 TAXI module C - 6

 TP25 module C - 17

network modules

 hot-swapping 3 - 1

 port numbering 1 - 11

 replacing 3 - 1

NEXT pushbutton 1 - 6, 1 - 8

non-extended mode 3 - 2

O

overcurrent protection 2 - 3

P

pinouts

 serial port 1 - 6, 1 - 7

port numbering 1 - 12

power LED 1 - 6, 1 - 9

power switch 1 - 9

product registration 2 - 15

R

- rack-mount kit 2 - 2
- rack-mounting
 - ASX-1000 2 - 7
 - ASX-200BX 2 - 4
- RESET button 1 - 6
- RESET switch 1 - 5
- RS-232 serial port 1 - 5, 1 - 6
- RUN/RESET LED 1 - 5

S**SCP**

- replacing an i960 SCP 3 - 18
- SELECT pushbutton 1 - 6, 1 - 8
- serial cable 2 - 9
- serial port 1 - 6
 - configuring on an ASX-200 2 - 10
 - pinouts 1 - 6, 1 - 7
- STATUS LED 1 - 5
- switch board 1 - 4
 - hot-swapping on an ASX-1000 ... 3 - 20
- switch control processor 1 - 4
- switch fabric 1 - 4
- switch software
 - changing between versions 4 - 14
 - changing the current version 4 - 14
 - displaying current version 4 - 14
- switch software upgrade
 - ASX-200WG 4 - 6
 - booting/upgrading with
 - Mini Loader 4 - 16
 - deleting current software ... 4 - 8
 - downloading Mini Loader .. 4 - 6
 - emptying the FLASH 4 - 7
 - upgrading to Mini Loader ... 4 - 7

downloading with bootp

- /etc/services 4 - 25
- adding a switch entry 4 - 23
- inetd.conf 4 - 25
- overview 4 - 22
- setting up a bootp server ... 4 - 22
- setting up a TFTP server ... 4 - 25
- tftpboot directory 4 - 25

instructions 4 - 1

obtaining the upgrade

- via diskette 4 - 4
- via ftp 4 - 2

placing the upgrade file 4 - 9

requirements 4 - 2

upgrading an ASX-200 4 - 12

upgrading an ASX-200BX or
ASX-1000 4 - 9

switch specifications

- ASX-1000 C - 5
- ASX-200 C - 2
- ASX-200BX C - 4
- ASX-200WG C - 3, C - 4, C - 5

T

Technical Support ii

temperature

operating

- ASX-1000 C - 5
- ASX-200 C - 2
- ASX-200BX C - 4
- ASX-200WG C - 3

storage

- ASX-1000 C - 5
- ASX-200BX C - 4
- ASX-200WG C - 3

Index

temperature sensors	1 - 21
test	
AAL* error	A - 11
adapter firmware	A - 4
adapter hardware	A - 4
adapter self-test	A - 4
atmstat	A - 10
carrier	A - 6
driver	A - 4
looptest	A - 3
network connectivity	A - 9
no cell transmission	A - 12
no cells received	A - 11
physical link	A - 6
VPI/VCI error	A - 11
troubleshooting	A - 1
U	
unpacking	2 - 2
V	
VME BM LED	1 - 5